

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rabalux](#) /

› [Rabalux 3239 LED Floor Lamp User Manual](#)

## Rabalux 3239

# Rabalux 3239 LED Floor Lamp User Manual

Model: 3239

## 1. INTRODUCTION

This manual provides comprehensive instructions for the safe assembly, operation, and maintenance of your Rabalux 3239 LED Floor Lamp. Please read this document thoroughly before use and retain it for future reference. Proper use ensures optimal performance and longevity of your product.



Main view of the Rabalux 3239 LED Floor Lamp, featuring a satin chrome finish and two integrated LED light sources.

## 2. SAFETY INSTRUCTIONS

Please observe the following safety precautions to prevent injury or damage to the product:

- Before assembly or maintenance, always disconnect the lamp from the main power supply.
- This product is designed for indoor use only. Do not expose it to moisture, direct water, or extreme temperatures.
- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- Do not attempt to modify the lamp or its electrical components. Any alterations may void the warranty and pose a safety risk.

- Keep the lamp and its power cord out of reach of children and pets.
- If the power cord is damaged, it must be replaced by a qualified electrician to avoid hazards.
- Do not cover the lamp with any materials that could obstruct ventilation, as this may lead to overheating.

### 3. PACKAGE CONTENTS


Verify that all components are present and undamaged upon unpacking:

- Rabalux 3239 LED Floor Lamp (main unit with integrated LED modules)
- Power cable with integrated push-button switches
- Base plate
- Assembly hardware (screws, washers, Allen key - typically pre-attached or included for base assembly)

### 4. SETUP AND ASSEMBLY

Follow these steps to assemble your floor lamp:

1. Carefully unpack all components and place them on a clean, flat, and stable surface.
2. Attach the circular base plate to the bottom of the main lamp pole. Secure it firmly using the provided screws and tools.  
Ensure the pole is centered and stable.
3. Position the assembled lamp in your desired location, ensuring it is on a stable, level surface and the power cord can reach an electrical outlet without being strained or creating a tripping hazard.
4. Plug the power cable into a standard electrical outlet.



This diagram illustrates the overall dimensions of the Rabalux 3239 LED Floor Lamp, with a total height of 1800mm and a base diameter of 255mm. These measurements are crucial for proper placement and assembly.

### 5. OPERATING INSTRUCTIONS

The Rabalux 3239 LED Floor Lamp features two independent light sources: a main uplighter and an adjustable reading light. Each

light source is controlled by its own push-button switch located on the central column of the lamp.

- To turn on or off the main uplighter, press the upper push-button switch.
- To turn on or off the adjustable reading light, press the lower push-button switch.
- The reading light features a flexible arm, allowing you to adjust its direction for focused illumination.
- Note: This lamp is not dimmable. The light output is fixed at 3000K warm white.



The Rabalux 3239 LED Floor Lamp integrated into a modern living space, demonstrating its functional design and ambient lighting capabilities.

## 6. MAINTENANCE

To ensure the longevity and appearance of your lamp, follow these maintenance guidelines:

- Always disconnect the lamp from the power supply before cleaning.
- Clean the lamp's metal surfaces with a soft, dry, lint-free cloth. For glass components, use a slightly damp cloth and then dry thoroughly.
- Do not use abrasive cleaners, solvents, or chemical agents, as these can damage the finish and electrical components.
- The LED modules in this lamp are integrated and are not designed to be replaced by the user. Do not attempt to open the LED housing.

## 7. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

- **Lamp does not turn on:**

- Ensure the power plug is fully inserted into a functional electrical outlet.
- Check if the wall switch (if applicable) is in the 'ON' position.
- Verify that the lamp's integrated push-button switches are pressed correctly.
- Test the outlet with another appliance to confirm it is receiving power.

- **Light flickers or is inconsistent:**

- Ensure the lamp is connected to a stable power supply.
- If the issue persists, disconnect the lamp and contact customer support or a qualified electrician.

- **Physical damage:**

- If any part of the lamp is damaged, especially the power cord or electrical components, discontinue use immediately and contact customer support.

## 8. SPECIFICATIONS

Detailed technical specifications for the Rabalux 3239 LED Floor Lamp:

Feature	Specification
Model	Rabalux 3239
Type	LED Floor Lamp
Main Light Power	18.5 W LED
Reading Light Power	4.5 W LED
Total Luminous Flux	2110 Lumen
Color Temperature	3000 Kelvin (Warm White)
Height	1800 mm (180 cm)
Base Diameter	255 mm (25.5 cm)
Weight	5.1 kg
Material	Metal (Satin Chrome), Glass
Protection Class	IP20 (Indoor use only)
Dimmable	No
Switch Type	Integrated Push-button
Energy Efficiency Class	F
Power Supply	Mains powered (with cable)

## 9. RECYCLING AND DISPOSAL

This product is marked with the WEEE (Waste Electrical and Electronic Equipment) symbol, indicating that it should not be disposed of with general household waste.

Please dispose of this product at a designated collection point for the recycling of electrical and electronic equipment. Proper disposal helps prevent potential negative consequences for the environment and human health.





For specific information regarding the recycling of light bulbs and safe handling of broken lamps, please consult your local waste management authority or relevant environmental protection agencies.


## 10. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the terms and conditions provided at the point of purchase or contact your retailer.

For technical assistance or further inquiries, please visit the official Rabalux website or contact their customer support department. You can also visit the [Rabalux Store on Amazon](#) for more information.

## Related Documents - 3239

	<p><a href="#">Rabalux 74000 Tripod Floor Lamp Assembly Instructions</a> Step-by-step assembly guide for the Rabalux 74000 tripod floor lamp. Includes instructions for setting up the tripod base, attaching the lamp head and shade, and installing the light bulb. Features a modern geometric design. Requires one light bulb (not included).</p>
	<p><a href="#">Rabalux 74166 Floor Lamp Assembly Guide</a> Assembly instructions and product details for the Rabalux 74166 floor lamp, featuring a textual description of the illustration and connection points.</p>
	<p><a href="#">Rabalux 72346/72349/72306 Lighting Fixture Installation and Remote Control Guide</a> Installation and user guide for Rabalux lighting fixtures (models 72346, 72349, 72306) featuring remote control operation for adjustable brightness and color temperature.</p>
	<p><a href="#">Smart Life App: User Guide for Smart Lighting Control</a> Comprehensive guide on how to download, install, connect, control, and share smart lighting devices using the Smart Life application. Covers device pairing, Wi-Fi setup, and app features like dimming, scenes, and scheduling.</p>
	<p><a href="#">Rabalux 71167 Lighting Fixture Assembly Instructions</a> Detailed assembly and installation guide for the Rabalux 71167 lighting fixture, covering mounting, bracket attachment, and electrical connections.</p>



### [Rabalux 72169 Lighting Fixture Assembly Instructions](#)

Step-by-step assembly guide for the Rabalux 72169 lighting fixture, detailing installation steps and component identification.