

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TENMIYA](#) /

› [Tenmiya A66 Portable Bluetooth Speaker User Manual](#)

TENMIYA A66

Tenmiya A66 Portable Bluetooth Speaker User Manual

Model: A66

INTRODUCTION

Thank you for choosing the Tenmiya A66 Portable Bluetooth Speaker. This manual provides detailed instructions for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and keep it for future reference.

The Tenmiya A66 is a versatile 30W portable Bluetooth speaker designed for both indoor and outdoor use. It features integrated Bluetooth 4.2 for wireless connectivity, FM radio, colorful LED lights, and multiple playback options including USB, AUX, and TF Card. Enjoy powerful stereo sound with heavy bass, perfect for parties, gatherings, or personal listening.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x A66 Bluetooth Speaker (with built-in 4000mAh rechargeable lithium battery)
- 1 x Remote Control (batteries not included)
- 1 x AUX Cable
- 1 x USB Cable
- 1 x Shoulder Strap
- 1 x User Manual

PRODUCT OVERVIEW



Figure 1: Front view of the Tenmiya A66 Portable Bluetooth Speaker, showcasing its main body, handle, control panel, and vibrant colorful LED lights on the speaker grilles.

Bluetooth 4.2 + Aux Port



Wireless + wired Can connect most of the equipment



USB



FM Radio



RECHARGEABLE



REMOTE



PC/MAC



TF CARD



MP3/4



Mobile Phone

Figure 2: Close-up of the speaker's control panel, highlighting the various buttons, knobs, and input ports including USB, AUX, TF card slot, and microphone inputs.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB cable to the speaker's DC 5V input port and the other end to a compatible USB power adapter (not included). The charging indicator light will turn off once the speaker is fully charged.

2. Remote Control Battery Installation

The remote control requires two 1.5-volt AAA batteries (not included). Open the battery compartment on the back of the remote control, insert the batteries with correct polarity, and close the compartment.

OPERATING INSTRUCTIONS

1. Power On/Off

Locate the power button on the control panel. Press and hold to turn the speaker on or off.

2. Bluetooth Connection

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, enable Bluetooth and search for available devices.
3. Select "A66" from the list of devices. Once connected, you will hear a confirmation sound.
4. The speaker supports Bluetooth 4.2 with a working distance of up to 33 feet (10 meters).



Figure 3: Illustration of the speaker's wireless Bluetooth 4.2 and wired AUX port connectivity options, compatible with various devices like smartphones, tablets, and PCs.

3. FM Radio Operation

1. Press the "Mode" button on the speaker or remote control to switch to FM radio mode.
2. To auto-scan and save available stations, press and hold the "Play/Pause" button.

3. Use the "Previous/Next" buttons to navigate through saved stations.
4. You can also manually enter a station frequency using the numeric keypad on the remote control.



Figure 4: The Tenmiya A66 speaker positioned outdoors, highlighting its portable design and FM radio functionality, allowing users to enjoy radio broadcasts on the go.

4. USB/TF Card Playback

Insert a USB flash drive or TF (Micro SD) card into the corresponding slot on the speaker. The speaker will automatically detect the storage device and begin playing MP3 music files. Use the control buttons on the speaker or remote for playback control (play, pause, skip tracks).

5. AUX Input

Connect one end of the provided 3.5mm AUX cable to the speaker's AUX input port and the other end to the audio output jack of your external device (e.g., PC, TV, MP3 player). The speaker will automatically switch to AUX mode. Control playback from your connected device.

6. Microphone Connection (Karaoke)

The speaker features microphone input ports (MC1, MC2). Connect a wired microphone (not included) to either port to use the karaoke function. Adjust microphone volume using the dedicated knob on the control panel.



Portable FM Radio

Colorful lights

Figure 5: Depiction of the speaker's karaoke capabilities and various EQ sound effects (Jazz, Rock, Classical, Pop), illustrating its versatility for different music genres and party environments.

7. Colorful Lights Control

The speaker features dynamic colorful LED lights. Use the dedicated light button on the control panel or remote to cycle through light modes or turn the lights off.



Figure 6: The Tenmiya A66 speaker illuminated with cool, vibrant lights, enhancing the atmosphere for outdoor activities like camping, shown under a colorful rainbow.

8. EQ Sound Effects

The speaker offers various EQ sound effects to enhance your listening experience, including Jazz, Rock, Classical, and Pop. Use the EQ button on the remote control to switch between these modes.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker regularly, even if not in use for extended periods. The 4000mAh battery provides approximately 10 hours of playback time on a full charge.
- **Water Resistance:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery or no charge.	Charge the speaker fully using the provided USB cable.
No sound.	Volume too low; incorrect input mode; device not connected properly.	Increase speaker and source device volume. Ensure correct mode (Bluetooth, AUX, USB, TF) is selected. Reconnect device.

Problem	Possible Cause	Solution
Bluetooth connection fails.	Speaker not in pairing mode; device too far; interference.	Ensure speaker is in Bluetooth mode and discoverable. Move device closer to speaker. Avoid obstacles. Try unpairing and re-pairing.
Poor FM radio reception.	Weak signal; antenna not extended (if applicable); environmental interference.	Relocate the speaker to an area with better signal. Perform an auto-scan again.
Remote control not working.	No batteries; incorrect battery polarity; remote out of range; IR sensor blocked.	Install two 1.5V AAA batteries with correct polarity. Ensure remote is pointed at the speaker's IR sensor. Reduce distance.

TECHNICAL SPECIFICATIONS

Feature	Specification
Product Type	RS-A66 Bluetooth Speaker
Speaker Output Power	20W + 5W x 2 (Total 30W)
Speaker Driver Size	4" + 2.5" x 2
Frequency Response	60Hz - 20kHz
Input Impedance	10 kΩ
Input Voltage	DC 5V-1A
Product Dimensions (L x W x H)	355 x 160 x 210 mm (13.98 x 6.30 x 8.27 inches)
Playback Time	Approximately 10 hours
Battery Capacity	4000 mAh
Connectivity Technology	Bluetooth 4.2
Functions	Bluetooth, MP3 Music Player, FM Radio, TF Card, AUX, USB Music Player, Remote Control, Equalizer, Karaoke, Colorful Lights
Compatibility	Computer, MP3/MP4 Players, Smartphones, iPods

WARRANTY AND SUPPORT

Warranty Information

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific warranty terms and conditions.

Customer Support

For any questions, technical assistance, or issues not covered in this manual, please contact Tenmiya customer support through their official website or the retailer from whom you purchased the product. Please have your model number (A66) and purchase details ready when contacting support.

Related Documents - A66

 <p>TENMIYA PORTABLE BOOMBOX SPEAKER USER MANUAL</p> <p>Thank you for purchasing our portable, 12.5 L portable speaker. This device can be easily connected with other audio devices for your daily needs. Before you use the product for the first time, please read the manual carefully to get the most out of it.</p> <p>CONTENTS</p> <ol style="list-style-type: none">1. The speaker2. The accessories	<p>TENMIYA A66 Portable Boombox Speaker User Manual</p> <p>User manual for the TENMIYA A66 Portable Boombox Speaker, detailing its features, specifications, operation, and troubleshooting.</p>
 <p>TENMIYA PORTABLE BOOMBOX SPEAKER USER MANUAL</p> <p>Thank you for purchasing our portable, 12.5 L portable speaker. This device can be easily connected with other audio devices for your daily needs. Before you use the product for the first time, please read the manual carefully to get the most out of it.</p> <p>CONTENTS</p> <ol style="list-style-type: none">1. The speaker2. The accessories	<p>TENMIYA A66 Portable Boombox Speaker User Manual</p> <p>User manual for the TENMIYA A66 Portable Boombox Speaker, detailing its features, specifications, functions, and troubleshooting.</p>
 <p>A66 Wireless Earbuds</p> <p>User Manual</p>	<p>A66 Wireless Earbuds User Manual</p> <p>User manual for the A66 Wireless Earbuds, covering packing list, product overview, pairing, wear instructions, power on/off, call and music controls, Siri activation, charging, specifications, safety instructions, and troubleshooting tips.</p>
 <p>A20 PORTABLE WIRELESS SPEAKER</p>	<p>A20 Portable Wireless Speaker User Manual</p> <p>User manual for the A20 Portable Wireless Speaker by TENMIYA, detailing features, specifications, operation, and troubleshooting.</p>
 <p>TENMIYA A30 USER'S MANUAL 2.2 CH PORTABLE WIRELESS SPEAKER</p> <p>Thank you for purchasing our portable 12.5 L 12.5 L portable speaker. This device can be easily connected with other audio devices for your daily needs. Before you use the product for the first time, please read the manual carefully to get the most out of it.</p>	<p>TENMIYA A30 Portable Wireless Speaker User Manual</p> <p>User manual for the TENMIYA A30 2.2 CH Portable Wireless Speaker, covering package contents, technical specifications, product features, safety information, operational specifications, remote control functions, and troubleshooting.</p>



[TENMIYA A23 Portable Wireless Speaker User Manual](#)

Comprehensive user manual for the TENMIYA A23 2.2 CH Portable Wireless Speaker, covering package contents, technical specifications, product features, safety information, operational functions, modes, charging, troubleshooting, and remote control details.

Documents - TENMIYA – A66

说明书第一页

TENMIYA
PORTABLE BOOMBOX SPEAKER
USER'S MANUAL

A66



说明书第二页

Thank you for purchasing our product A66. It's a portable audio. This device can be easily connected with audio or video devices for your daily needs. Before you use this product for the first time, please read this manual carefully to get familiar with all its functions.

Package contents

1. A66 speaker1PC
2. User manual1PC
3. 3.5mm Audio cable1PC

[TENMIYA A66 Portable Boombox Speaker User Manual](#)

User manual for the TENMIYA A66 Portable Boombox Speaker, detailing its features, specifications, operation, and troubleshooting.

lang:en score:34 filesize: 277.07 K page_count: 8 document date: 2022-04-02

说明书第一页

TENMIYA
PORTABLE BOOMBOX SPEAKER
USER'S MANUAL

A66



说明书第二页

Thank you for purchasing our product A66. It's a portable audio. This device can be easily connected with audio or video devices for your daily needs. Before you use this product for the first time, please read this manual carefully to get familiar with all its functions.

Package contents

1. A66 speaker1PC
2. User manual1PC
3. 3.5mm Audio cable1PC

[TENMIYA A66 Portable Boombox Speaker User Manual](#)

User manual for the TENMIYA A66 Portable Boombox Speaker, detailing its features, specifications, functions, and troubleshooting.

lang:en score:33 filesize: 566.09 K page_count: 8 document date: 2022-03-26



[\[pdf\]](#) User Manual Specifications

A96 A66 AS96 B96 B66 4 If your car has a manual gearbox prior to activating the function of remote or automatic engine starting be sure perform procedure preparation for program neutral 5 Never hand over security complex control key children and other persons without their preliminary study operation user ENG starline sales eu Manuals Go Now Tenmiya Manual Url |||

We would like to thank you for choosing the security telematic complex A96,**A66**, AS96, B96, B66 and wish you many pleasant and safe drives Revision 1 November 2017 StarLine A96, StarLine **A66**, StarLine AS96, StarLine B96, StarLine B66 Contents General description.....

lang:en score:27 filesize: 1.19 M page_count: 52 document date: 2018-06-15