

SEVERIN MW 7775

SEVERIN MW 7775 3-in-1 Microwave Oven Instruction Manual

Model: MW 7775

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your SEVERIN MW 7775 3-in-1 Microwave Oven. This appliance combines microwave, grill, and hot air functions, offering versatile cooking options. Please read these instructions thoroughly before first use and retain them for future reference.

2. SAFETY INSTRUCTIONS

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, personal injury, or exposure to excessive microwave energy.

- Do not attempt to operate this oven with the door open, as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door, or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Ensure adequate ventilation around the appliance. Do not block ventilation openings.
- Do not heat liquids or other foods in sealed containers, as they are liable to explode.
- Only use utensils suitable for microwave ovens. Metal containers are not suitable for microwave cooking.
- Supervise children when using the appliance.

3. PRODUCT OVERVIEW

The SEVERIN MW 7775 features a sleek design with a digital display and intuitive controls. It includes a spacious cooking chamber, a glass turntable, and a grill rack for various cooking needs.



Figure 3.1: Front view of the SEVERIN MW 7775 Microwave Oven. This image displays the appliance's exterior, including the control panel on the right, the door with a handle, and the viewing window into the cooking chamber.

Key components include:

- **Control Panel:** Digital display, function buttons, and rotary knob for settings.
- **Door:** Equipped with a safety lock mechanism.
- **Cooking Chamber:** Interior space for food preparation.
- **Glass Turntable:** Ensures even cooking by rotating food.

- **Grill Rack:** Used for grilling and hot air functions.

4. SETUP

4.1 Unpacking

Carefully remove all packaging materials from the oven and its accessories. Check for any damage during transit. Do not discard packaging until you are satisfied with the product.

4.2 Placement

Place the oven on a flat, stable, heat-resistant surface. Ensure there is sufficient space for ventilation: at least 20 cm above, 10 cm at the rear, and 5 cm on each side. Do not place the oven near heat sources or in direct sunlight.



Figure 4.1: SEVERIN MW 7775 placed on a kitchen counter. This image illustrates the microwave oven positioned on a countertop, demonstrating typical placement with surrounding kitchen elements.

4.3 Turntable Assembly

Before use, assemble the turntable components inside the cooking chamber:

1. Place the rotating ring on the bottom of the oven cavity.
2. Position the glass turntable plate securely on top of the rotating ring. Ensure it sits correctly in the center.



Figure 4.2: Interior of the microwave oven. This image shows the inside of the oven, highlighting the glass turntable and the metal grill rack positioned above it.

4.4 Power Connection

Plug the power cord into a grounded electrical outlet. The oven is now ready for initial setup and use.

5. OPERATING INSTRUCTIONS

5.1 Setting the Clock

Upon first connection, the display will show '0:00'. To set the clock:

1. Press the 'Clock' button.
2. Use the rotary knob to set the hour. Press 'Clock' again.
3. Use the rotary knob to set the minutes. Press 'Clock' again to confirm.

5.2 Microwave Function

To cook with microwave power:

1. Place food in a microwave-safe container on the glass turntable.
2. Press the 'Microwave' button repeatedly to select the desired power level (e.g., P100 for 100% power).
3. Use the rotary knob to set the cooking time.
4. Press 'Start' to begin cooking.

5.3 Grill Function

The grill function is ideal for browning and crisping food.

1. Place food on the grill rack, which should be placed on the glass turntable.
2. Press the 'Grill' button.
3. Use the rotary knob to set the grilling time.
4. Press 'Start' to begin grilling.

5.4 Hot Air Function (Convection)

The hot air function allows for baking and roasting, similar to a conventional oven.

1. Place food on the grill rack.
2. Press the 'Hot Air' button.
3. Use the rotary knob to select the desired temperature (e.g., 140°C).
4. Press 'Hot Air' again to confirm temperature.
5. Use the rotary knob to set the cooking time.
6. Press 'Start' to begin. The oven will preheat first if necessary.



Figure 5.1: Digital display showing temperature setting. This close-up image of the control panel display indicates a temperature of 140°C, relevant for the hot air function.

5.5 Combination Modes

The oven offers various combination modes (e.g., Microwave + Grill, Microwave + Hot Air, Grill + Hot Air) for optimized cooking results. Refer to the specific combination program codes in the full manual for detailed instructions.

5.6 Automatic Programs

The MW 7775 includes 10 pre-set automatic cooking programs, including a pizza function. These programs simplify cooking for common dishes.

1. Press the 'Auto Menu' button.
2. Use the rotary knob to select the desired program number (e.g., A-1 for pizza).
3. Press 'Start' to begin. The oven will automatically adjust power and time.



Figure 5.2: Digital display showing an automatic program. This close-up image of the control panel display indicates an automatic program, such as 'd-2', which corresponds to a specific pre-set cooking function.

5.7 Defrost Function

The defrost function allows thawing food by weight or time.

- **Defrost by Weight:** Press 'Defrost by Weight', use the rotary knob to enter the food weight, then press 'Start'.
- **Defrost by Time:** Press 'Defrost by Time', use the rotary knob to set the defrosting duration, then press 'Start'.

5.8 Child Lock

To activate the child lock, press and hold the 'Stop/Cancel' button for 3 seconds. The display will show a lock icon. To deactivate, repeat the process.

6. MAINTENANCE AND CLEANING

Regular cleaning helps maintain the performance and longevity of your oven.

- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners.
- **Interior:** Clean the inside of the oven with a mild detergent and a soft cloth after each use. For stubborn stains, place a bowl of water with lemon juice inside and microwave for a few minutes to loosen residue.
- **Door Seals:** Keep the door seals clean to ensure proper closure.
- **Turntable and Grill Rack:** The glass turntable and metal grill rack can be removed and washed with warm soapy water or in a dishwasher.
- Always ensure the oven is unplugged before cleaning.

7. TROUBLESHOOTING

If you encounter issues with your oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Power cord unplugged; Door not closed properly; Fuse blown.	Check power connection; Close door firmly; Check household fuse/circuit breaker.
Food not heating	Incorrect power level or time set; Utensil not microwave-safe.	Adjust settings; Use appropriate cookware.
Unusual noise during operation	Turntable not correctly positioned; Food container touching oven walls.	Re-position turntable; Ensure adequate space around food.
Display shows error code	Internal malfunction.	Unplug the oven for a few minutes, then plug back in. If the error persists, contact customer service.

If the problem persists after attempting these solutions, please contact SEVERIN customer support.

8. SPECIFICATIONS

Technical details for the SEVERIN MW 7775 3-in-1 Microwave Oven:

Feature	Detail
Model Number	MW 7775
Capacity	30 liters
Microwave Power	900 W
Grill Power	1100 W
Hot Air Power	2500 W
Product Dimensions (W x D x H)	52.6 cm x 51 cm x 33 cm
Weight	18 kg
Material	Stainless Steel
Special Features	Programmable, Timer, Turntable
Included Components	Grill Grate, Rotating Plate



Figure 8.1: Dimensions of the SEVERIN MW 7775. This image provides a visual representation of the microwave oven with its width (52.5cm), depth (51cm), and height (33cm) clearly labeled.

9. WARRANTY AND SUPPORT


For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official SEVERIN website. Keep your proof of purchase for any warranty claims.

Related Documents - MW 7775

	Severin MW 7775 / MW 7803 Microwave Oven User Manual Comprehensive user manual for the Severin MW 7775 and MW 7803 microwave ovens, covering operation, safety instructions, and features like microwave, grill, and hot air functions.
	SEVERIN Mikrowelle mit Grillfunktion - Bedienungsanleitung Umfassende Bedienungsanleitung für die SEVERIN Mikrowelle mit Grillfunktion, Modellreihen MW 7892, MW 7893, MW 7894, MW 7898. Erfahren Sie mehr über Sicherheit, Bedienung und Funktionen wie Auftauen, Erwärmen und Grillen.

 SEVERIN SEVERIN MW 7892/7893/7894/7898 Mikrowelle Bedienungsanleitung Umfassende Bedienungsanleitung für die SEVERIN Retro-Mikrowelle mit Grillfunktion, Modelle MW 7892, MW 7893, MW 7894, MW 7898. Enthält Sicherheitshinweise, Bedienung, Programme und technische Daten in mehreren Sprachen.	
 SEVERIN SEVERIN MW 7778 Mikrowelle Bedienungsanleitung Grill & Heißluft Entdecken Sie die SEVERIN MW 7778 Mikrowelle mit dieser vollständigen Bedienungsanleitung. Erfahren Sie alles über Funktionen, Sicherheit, Bedienung und Pflege für Ihr Küchengerät.	
 SEVERIN SEVERIN MW 7760 Mikrowelle mit Grill – Bedienungsanleitung Umfassende Bedienungsanleitung für die SEVERIN MW 7760 Mikrowelle mit Grill. Enthält Informationen zu Sicherheit, Bedienung, Funktionen und technischen Daten von SEVERIN.	
 SEVERIN Severin PG 8107 Barbecue Grill Parts Diagram and Overview An exploded view and parts list for the Severin PG 8107 Barbecue Grill, detailing all components for assembly and maintenance.	

Documents - SEVERIN – MW 7775



[\[pdf\]](#) User Manual

im MW7848 Fun Maker Severin MW 7775 Mikrovlnná trouba CZ dwn alza cz manual 111468 |||

Mikrovlnn trouba **MW 7775** Nvod k obsluze 1. Zavrn dvek 2. Prhledov oknko 3. Vnitn osvten 4. Ochran kryt 5. Pohonn jednotka 6. C 12. Rukoje dvek Pklady program Optovn ohev 1 jdl 1 chodu piblizn 350 g Dvakrt sti...

lang:hr **score:28** filesize: 888.29 K page_count: 8 document date: 2022-09-21



[\[pdf\]](#) Instructions

Buy Severin MW 7775 Microwave Silver black 900 W Heat convection Grill function Conrad Electronicuser safety instructions 2804005 severin mw microwave silve

Mikrowelle Silber Schwarz Heißluft Funktion Grillfunktion kaufenuser functionbedienungs und sicherheitshinweise mikrowelle silber schwarz heissluft funktion grillfu

Mikrowelle 4 GB Instructions for use Microwave oven 17 FR Mode d'emploi Four micro-ondes 29 NL Gebruiksaanwijzing Microwave oven 42 ES Instrucciones de u

ART.-NO. **MW 7775** / MW 7803 DE Gebrauchsanleitung Mikrowelle 4 GB Instructions for use Microwave oven 17 FR Mode d'emploi

de uso Horno microondas 55 IT Manuale d'uso Forno a microonde 68 DK Brugsanvisning...

lang:de **score:27** filesize: 3.17 M page_count: 160 document date: 2022-08-31



[Severin MW 7775 / MW 7803 Microwave Oven User Manual](#)

Comprehensive user manual for the Severin MW 7775 and MW 7803 microwave ovens, covering operation, safety instructions, and

lang:de score:23 filesize: 3.17 M page_count: 160 document date: 2022-08-31



[\[pdf\] Instructions](#)

NO MW 7775 May 23 2023 — GB Instructions for use FR Mode d emploi NL Gebruiksaanwijzing Mikrowelle 4 Microwave oven 17 Four à micro ondes 29 BA PRO
bWFzdGVyGluc3RydWN0aW9uc3wzMzA4OTA4IGFwcGxpY2F0aW9uL3BkZnxpbN0cnVjdGlbnMvaGM1L2gxYS85MDkxNzkxMzU1OTM0LnBkZnxkY2UxNTc1

|||
ART.-NO. **MW 7775** / MW 7803 DE Gebrauchsanleitung Mikrowelle 4 GB Instructions for use Microwave oven 17 FR Mode d emploi
de uso Horno microondas 55 IT Manuale d uso Forno a microonde 68 DK Brugsanvisning...


lang:de score:21 filesize: 3.16 M page_count: 160 document date: 2022-08-31



[\[pdf\] Declaration of Conformity Label](#)

Microsoft Word CE 7775 xxxx niederhoff Bekijk de marking Severin MW Vrijstaande Combi Magnetron met Grill en Hetelucht 30 Liter bol original media s JjMrm
EU-Konformitätserklärung EU-Declaration of Conformity Hiermit erklären wir, dass das nachfolgend bezeic ... elnummer: Article number:
7775 7803 230V; 50Hz; 2500W Einschlgige EU-Richtlinien / Governing EU-directives Niederspannung...

lang:de score:18 filesize: 112.2 K page_count: 1 document date: 2023-06-21



[\[pdf\]](#)

im MW7848 Fun Maker NÄvod Severin MW 7775 SK 953 47 kB mikroInnÄj rÄ*ra Nay sk 1881113 cdn nay images orig 3 |||
MikroInn rra **MW 7775** Nvod k obsluze 1. Zatvanie dvierok 2. Prieťahov okienko 3. Vntorn osvetlenie 4. Ochrrann kryt 5. Pohonn jec
mriezka 11. Displej 12. Rukov dvierok Prklady programov Optovn ohrev 1 jedla 1 chodu ...

lang:hr score:17 filesize: 953.47 K page_count: 8 document date: 2022-09-30



[\[pdf\]](#)

Sortiment 2024 DE more Documents SEVERIN Official de severin 08 |||
Sortiment 2024 DE Machen deinen Alltag leichter. Produkte von SEVERIN. 04 HIGHLIGHTS 06 KAFFEE ... khlpizza Leistung: Mikr
30 L *laut Herstellerangabe MW 7752 25 L *laut Herstellerangabe 3-in-1 Mikrowelle mit Grill...

lang:de score:15 filesize: 6.18 M page_count: 92 document date: 2024-04-25



[pdf]

Sortiment 2023 24 Downloads SEVERIN Official de severin 10 |||
Sortiment 2023 2024 DE Machen deinen Alltag leichter. Produkte von SEVERIN. 04 HIGHLIGHTS 08 K ... hl-Pizza Leistung: Mikrow
30 L *laut Herstellerangabe 3-in-1 Mikrowelle mit Grill- und Heiluftfunktion 1 239,00 5 v...
lang:de score:14 filesize: 8.51 M page_count: 98 document date: 2023-09-08



[pdf] Accessories

Assortment 2023 24 Downloads SEVERIN Official Sortiment gb ohne severin 10 |||
Assortment 2023 2024 GB We make home life simpler. Products from SEVERIN. 04 HIGHLIGHTS 08 COF ... Output: Microwave ap
7775 30 L 3-in-1 microwave with grill and convection 1 functions 5 different power settings, ...
lang:en score:14 filesize: 8.5 M page_count: 98 document date: 2023-09-08



[pdf] Declaration of Conformity Label

Microsoft Word CE 7775 xxxx niederhoff EU Konformitätserklärung Declaration of Conformity EMGAMW Typ Type 7803 Technische Daten Technical data 230V 5
6359emga media akeneo connector files 9 1 910045 6359 |||
EU-Konformitätserklärung EU-Declaration of Conformity Hiermit erklären wir, dass das nachfolgend bezeic ... elnummer: Article number:
7775 7803 230V; 50Hz; 2500W Einschligige EU-Richtlinien / Governing EU-directives Niederspannung...
lang:de score:14 filesize: 112.2 K page_count: 1 document date: 2023-06-21



[pdf]

UVP Preisliste 2022 23 Downloads SEVERIN Official Sortiment de severin 10 |||
Sortiment 2022 2023 Preisliste DE Machen deinen Alltag leichter. Produkte von SEVERIN. 04 INN ... hl-Pizza Leistung: Mikrowelle c
30 L *laut Herstellerangabe 3-in-1 Mikrowelle mit Grill- und Heiluftfunktion 1 239,00 ...
lang:de score:14 filesize: 11.73 M page_count: 124 document date: 2022-09-29



[pdf]

Sortiment 2023 Severin 29 janv — Tee Wasserkocher 18 19 Toaster 23 Frühstücksserie 25 Eierkocher 27 Joghurtbereiter 28 Zubehör Zitruspressen de severin 01
Sortiment 2023 DE Machen deinen Alltag leichter. Produkte von SEVERIN. 04 NEUHEITEN 07 KAFFEE E ... hl-Pizza Leistung: Mik
7775 30 L *laut Herstellerangabe 3-in-1 Mikrowelle mit Grill- und Heiluftfunktion 1 239,00 5 v...
lang:de score:14 filesize: 8.59 M page_count: 96 document date: 2023-01-18



[pdf]

Sortiment 2023 Severin 17 mars — Tee Wasserkocher 18 19 Toaster 23 Frühstücksserie 25 Eierkocher 27 Joghurtbereiter 28 Zubehör Zitruspressen 29 de severin
Sortiment 2023 DE Machen deinen Alltag leichter. Produkte von SEVERIN. 04 NEUHEITEN 07 KAFFEE E ... hl-Pizza Leistung: Mikr
7775 30 L *laut Herstellerangabe 3-in-1 Mikrowelle mit Grill- und Heilluftfunktion 1 239,00 5 v...
lang:de score:14 filesize: 8.84 M page_count: 98 document date: 2023-03-08




[pdf] Datasheet

Microsoft Word 7775 000 blome Severin MW Microwave Silver black 900 W Heat convection Grill function Conrad datasheet 2804005 severin mw microwave silver
MULTIFUNKTIONAL EINSETZBAR UND MIT 2 HEIZUNGEN FR OPTIMALE WRMEVERTEILUNG.MW 7775 Mikrowelle mit Grill- u
Auftaustufe nach Gewicht und Zeit - 10 verschiedene Automatik-Kochprogramme zur Zubereitung unterschiedlicher Le...
lang:de score:13 filesize: 465.73 K page_count: 2 document date: 2022-06-13



[pdf] Accessories

Assortment 2024 SEVERIN Hhgh quality grill surface with ceramic coating and an area of 48 x 24 cm including parking level for storing hot unused pans raclette 8
Output approx 1 300 W 79 99 € Sortiment gb severin 08 |||
Assortment 2024 GB We make home life simpler. Products from SEVERIN. 04 HIGHLIGHTS 06 COFFEE Es ... crowave approx. 90
7775 30 L 3-in-1 microwave with grill and convection functions 5 different power settings, inclu...
lang:en score:13 filesize: 6.19 M page_count: 92 document date: 2024-04-25



[pdf] Instructions

ManualMikrovågsugn 900W med varmluft 30 liter MW 7775 GEP Communication Group ABFILE 68d4124835923static unpri media 2729 FILE 68d4124835923 ||
ART.-NO. MW 7775 / MW 7803 DE Gebrauchsanweisung Mikrowelle 4 GB Instructions for use Microwave oven 17 FR Mode d empl
de uso Horno microondas 55 IT Manuale d uso Forno a microonde 68 DK Brugsanv...
lang:de score:12 filesize: 993.44 K page_count: 160 document date: 2022-10-18



[pdf]

Direttiva sulla progettazione ecocompatibile Ali di pollo croccanti e patatine fritte dalla friggitrice ad aria SEVERIN Official EcoDesign Richtlinie 05 2025 severin |||
ERP Ecodesign Requirements 2023/826 Category Haushalt / Beauty Haushalt / Beauty Haushalt / Beauty Haushalt / Beauty Hausha
Kitchen Kitchen Kitchen Kitchen Microwave Toasting oven Microwave Toasting oven Microwave ...
lang:de score:11 filesize: 162.11 K page_count: 7 document date: 2025-05-08