

[Manuals.plus](#) /

› [Perlegear](#) /

› Perlegear Floor-Standing TV Stand Instruction Manual

Perlegear PGFS03

Perlegear Floor-Standing TV Stand Instruction Manual

Model: PGFS03 | Brand: Perlegear

1. PRODUCT OVERVIEW

The Perlegear PGFS03 Floor-Standing TV Stand is designed to provide a stable and versatile mounting solution for your television. Its high-type, wall-leaning design saves space while offering adjustable height and swivel capabilities for optimal viewing from various angles. Constructed with reinforced steel and a tempered glass base, it ensures exceptional stability for large TVs.



Image: Front view of the Perlegear PGFS03 TV stand with a television mounted, showcasing its sleek design.

Key Features:

- **Wide Compatibility:** Supports 32-75 inch TVs with VESA patterns from 200x100mm to 600x400mm and a maximum weight of 40kg (88 lbs).
- **Exceptional Stability:** Features a 10mm thick tempered glass base and an 8cm diameter high-quality reinforced steel pillar for superior stability.
- **Adjustable Height:** Offers 6 levels of height adjustment in 5cm increments for customized viewing.
- **Swivel Function:** Allows for $\pm 35^\circ$ rotation, providing flexible viewing angles.
- **Space-Saving Design:** Positions the TV close to the wall (approx. 4cm distance from pillar to wall), reducing dead space.
- **Integrated Cable Management:** Cables can be neatly hidden behind the stand's pillar for a clean and organized appearance.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembly and use. Failure to do so may result in serious personal injury or property damage.

- Do not exceed the maximum load capacity of 40kg (88 lbs).
- Ensure your TV's VESA pattern is within the supported range (200x100mm to 600x400mm) and its size is between 32-75 inches.
- Always assemble the stand on a flat, stable surface.
- Do not allow children to climb on or play with the TV stand.
- Periodically check all screws and connections to ensure they remain tight and secure.
- Avoid placing the stand in areas with high humidity or direct sunlight.
- Use caution when adjusting the height or swiveling the TV to prevent pinching or accidental drops.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact Perlegear customer service.




Image: Illustration of the various screws and bolts included for TV mounting, ensuring compatibility with different TV models.

Typical Components:

- Base (Tempered Glass)
- Main Support Pillar (Reinforced Steel)
- TV Mounting Brackets
- Height Adjustment Mechanism
- Cable Management Clips/Covers
- Hardware Kit (various screws, washers, spacers for TV and stand assembly)

- Assembly Tools (e.g., Allen wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Perlegear TV stand. It is recommended to have two people for certain steps, especially when mounting the TV.

1. **Attach the Main Pillar to the Base:** Securely fasten the main support pillar to the tempered glass base using the provided bolts and tools. Ensure the pillar is firmly seated and aligned.



Image: Detail of the stand's base, highlighting the sturdy construction and anti-slip pads.

2. **Assemble the TV Mounting Brackets:** Attach the vertical TV mounting brackets to the horizontal support bar. Ensure they are spaced correctly to match your TV's VESA pattern.



Image: Detailed view of the TV mounting bracket, illustrating the secure attachment points.

3. **Attach Brackets to TV:** Carefully place your TV face down on a soft, clean surface. Attach the assembled mounting brackets to the back of your TV using the appropriate screws, washers, and spacers from the hardware kit. Do not overtighten.



Image: Visual guide for checking TV compatibility with VESA patterns, screen size, and weight limits.

4. **Mount TV onto Stand:** With assistance, carefully lift the TV and hook the mounting brackets onto the main support pillar's mounting plate. Engage the safety lock mechanism to secure the TV in place.
5. **Cable Management:** Route all necessary cables through the integrated cable management system within the main pillar to maintain a tidy appearance.



Image: Demonstration of the integrated cable management feature, allowing for a clean setup.

5. OPERATING YOUR TV STAND

Height Adjustment:

The Perlegear PGFS03 TV stand allows for easy height adjustment to achieve your preferred viewing level. To adjust the height, locate the protrusion on the main pillar. Gently pull this protrusion to disengage the locking mechanism, then slide the TV up or down to one of the 6 available height settings (5cm increments). Release the protrusion to lock the TV at the desired height. Ensure the TV is securely locked before letting go.

6段高さ調整

各間隔5cm




Image: Visual guide demonstrating the 6-level height adjustment feature of the TV stand.

Swivel Function:

This TV stand features a convenient swivel function, allowing you to rotate your television up to 35 degrees to the left or right. Gently push the sides of the TV to rotate it to your desired viewing angle. This is ideal for optimizing viewing from different seating positions in a room.

最適な視線を実現



Image: Illustration of the TV stand's $\pm 35^\circ$ swivel capability, enhancing viewing flexibility.

6. CARE AND MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the stand's surfaces. Avoid abrasive cleaners or solvents that may damage the finish or glass.
- **Dusting:** Regularly dust the stand to prevent accumulation, especially around the moving parts.
- **Inspection:** Periodically inspect all connections and fasteners to ensure they are tight. Retighten if necessary.
- **Avoid Overloading:** Never place items on the stand that exceed its stated weight capacity.
- **Environmental Conditions:** Keep the stand away from extreme temperatures, direct sunlight, and high humidity to prolong its lifespan.

7. TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
TV is not stable/wobbles	Loose connections; uneven floor; TV too heavy or large.	Ensure all screws are tightened. Move stand to a level surface. Verify TV weight and size are within limits.
Difficulty adjusting height	Locking mechanism not fully disengaged; obstruction.	Ensure the protrusion is fully pulled out. Check for any debris or obstructions in the pillar.
TV not swiveling smoothly	Friction; obstruction.	Ensure no cables are snagged. Check for any foreign objects.
Missing parts upon unboxing	Packaging error; shipping damage.	Contact Perlegear customer service immediately with your purchase details.

8. PRODUCT SPECIFICATIONS



Image: Comprehensive dimensional diagram of the TV stand, providing all key measurements.

Specification	Detail
Model Number	PGFS03
Brand	Perlegear
Compatible TV Size	32 - 75 inches
Maximum Load Capacity	40 kg (88 lbs)
VESA Compatibility	Horizontal: 200-600mm, Vertical: 100-400mm
Height Adjustment	6 levels, 5cm increments (approx. 104cm to 128cm from floor to TV center)
Swivel Angle	±35 degrees
Material	Alloy Steel, Tempered Glass
Color	Black
Base Dimensions	52cm (W) x 40cm (D) x 1cm (H)
Overall Dimensions (approx.)	77 x 41.9 x 11 cm (Package Size)
Product Weight (Package)	12.16 kg

9. WARRANTY AND SUPPORT

Warranty Information:

The Perlegear PGFS03 Floor-Standing TV Stand comes with a **3-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or exceeding the stated load capacity.

Customer Support:

Perlegear is committed to providing high-quality products and excellent customer service. If you encounter any issues, have questions about assembly, or require assistance with your product, please do not hesitate to contact our customer support team. We perform thorough checks at our manufacturing plant, warehouse, and distribution center, but in the rare event of missing parts, defects, or shipping damage, we will provide prompt assistance.

For support, please refer to the contact information provided on your purchase receipt or visit the official Perlegear website.

Thank you for choosing Perlegear.