

[Manuals.plus](#) /

› [NORTHCLAN](#) /

› NORTHCLAN Ice Maker User Manual

NORTHCLAN 1226

NORTHCLAN Ice Maker User Manual

Model: 1226

INTRODUCTION

Welcome to the NORTHCLAN Ice Maker user manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new ice maker. Please read this manual thoroughly before using the appliance.



Image: The NORTHCLAN Ice Maker in silver, shown with an ice scoop and freshly made ice cubes.

PRODUCT FEATURES

- **Rapid Ice Production:** Produces 9 bullet-shaped ice cubes in just 6-8 minutes, with a daily capacity of 12-14 kg.
- **Smart One-Touch Control:** Easy operation with an intuitive LED display indicating low water level or full ice basket.
- **Quiet Operation:** Operates at less than 40 dB, ensuring a peaceful environment.
- **Energy & Water Saving:** Features a high-quality foam layer for insulation and re-freezes melted ice, reducing waste.
- **Easy to Clean & Portable:** Durable ABS casing, food-grade interior, and a convenient drain plug for effortless cleaning. Compact size and lightweight for easy transport.
- **Versatile Use:** Ideal for home, office, BBQs, outdoor parties, and various beverages.

A lot of ice

NORTHCLAN

Ready In 5 Mere Mins

III

14kg daily production is your
life-saver when you got a crowd to entertain



Image: The ice maker shown with a large quantity of ice, highlighting its rapid production capability.

Quiet

NORTHCLAN

Be Your Silent Pal

|||

Bulky and noisy is not "NORTHCLAN"y



Image: The ice maker operating quietly, demonstrating its low noise level, with a child sleeping peacefully nearby.

NORTHCLAN

Safe & Durable

III

Inner layer: Food-Grade ABS Materials

Middle Layer: High-density Polyurethane Foam

Outer Layer: Premium ABS Materials



Polyurethane Foam Insulation

Block external heat and make ice cubes last longer



Bargain Foam Insulation

Ice cubes melt fast

Image: A cutaway diagram illustrating the durable construction of the ice maker, including its food-grade inner layer, high-density polyurethane foam middle layer, and premium ABS outer layer.

SETUP

1. **Unpack:** Carefully remove the ice maker from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
3. **Clean Before First Use:** Before first use, clean the interior of the ice maker as described in the "Maintenance and Cleaning" section.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet (220 Volts).

Correct Fit

compact outside, but spacious inside



Image: The ice maker positioned on a countertop next to a coffee maker, illustrating its compact size and how it fits in a typical kitchen space.

OPERATING INSTRUCTIONS

1. **Add Water:** Open the lid and fill the water reservoir with clean, potable water up to the MAX fill line. Do not overfill.
2. **Start Production:** Close the lid and press the "ON/OFF" button on the control panel. The "ICE MAKING" indicator light will illuminate.
3. **Monitor Progress:** The ice maker will begin producing ice cubes. You can observe the process through the transparent lid. The first batch of ice may take slightly longer and the cubes might be smaller or irregular. This is normal.
4. **Ice Full Indicator:** When the ice basket is full, the "ICE FULL" indicator light will turn on, and the machine will automatically stop ice production. Remove ice from the basket to resume production.
5. **Add Water Indicator:** If the water level is too low, the "ADD WATER" indicator light will turn on, and the machine will stop. Add more water to the reservoir to continue.
6. **Stop Production:** To stop the ice maker at any time, press the "ON/OFF" button again.

Note: The ice maker is not a freezer. Ice cubes will gradually melt if left in the basket for extended periods. Transfer ice to a freezer for long-term storage.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your ice maker.

Daily Cleaning:

- After each use, unplug the unit.
- Remove the ice basket.
- Drain any remaining water from the reservoir using the drain plug at the bottom of the unit.
- Wipe the interior with a soft cloth and mild detergent. Rinse thoroughly with clean water.
- Dry all surfaces before closing the lid.

Monthly Cleaning (or as needed):

- Prepare a solution of water and white vinegar (10:1 ratio) or a dedicated ice maker cleaning solution.
- Pour the solution into the water reservoir.
- Run the ice maker for a few cycles (without consuming the ice).
- Drain the solution completely.
- Rinse the reservoir and interior thoroughly with clean water multiple times to remove any residue or odor.
- Wipe down the exterior with a damp cloth.

Important: Always unplug the ice maker before cleaning. Do not immerse the unit in water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Ice production is slow or ice cubes are small.	First few cycles after setup. Ambient temperature is too high. Poor ventilation.	Allow the machine to run for several hours until the refrigeration system stabilizes. Ensure ambient temperature is below 90°F/32°C. Ensure adequate space around the unit for air circulation.
"ADD WATER" indicator is on.	Water reservoir is empty or water level is too low.	Add clean, potable water to the reservoir up to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket. The machine will resume production automatically.
Ice cubes melt quickly in the basket.	The ice maker is not a freezer.	Transfer ice to a separate freezer for long-term storage.
Unusual noise during operation.	Unit not level or internal components settling.	Ensure the unit is on a flat, stable surface. If noise persists, contact customer support.

♥♥ Les 5 premiers tours peuvent prendre plus de temps et les glaçons peuvent être imparfaits. Laissez simplement la machine à glaçons fonctionner pendant plusieurs heures jusqu'à ce que le système de réfrigération fonctionne de manière stable.

♥♥ La machine à glaçons n'est par définition pas un réfrigérateur. Les glaçons ne restent pas congelés dans la machine à glaçons. Utilisez un congélateur séparé à cet effet.

♥♥ Lorsque l'indicateur "ICE FULL" s'allume, veuillez retirer les glaçons du panier à glaçons et les utiliser ou les mettre au réfrigérateur pour éviter qu'ils ne fondent.

♥♥ Condition idéale pour la fabrication de glaçons: température ambiante inférieure à 90°F/32°C, sans lumière directe du soleil.

☎☎ Notre équipe professionnelle est toujours prête à l'action. N'hésitez pas à nous contacter si vous rencontrez des problèmes avec ce produit. Nous offrons les meilleures solutions pour gagner du temps, de l'argent et de l'énergie.

Image: A visual representation of common troubleshooting tips, including advice on initial ice production, the ice maker not being a freezer, and indicator lights.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	NORTHCLAN
Model Number	1226
Dimensions (L x W x H)	28.9P x 21.8I x 30.2H centimeters (approx. 11.38 x 8.58 x 11.89 inches)
Weight	6.6 kilograms (approx. 14.55 lbs)
Daily Ice Production	Up to 12-14 kg (26.5-30.8 lbs) per 24 hours
Ice Production Cycle	9 ice cubes in 6-8 minutes
Water Reservoir Capacity	2 Liters
Power	120 Watts
Voltage	220 Volts
Refrigerant	R600a (21g)
Noise Level	Less than 40 dB
Material	ABS Plastic
UPC	735940861625

WARRANTY AND SUPPORT

NORTHCLAN offers a 2-year worry-free online support and replacement service. If you have any questions or encounter issues with your product, please do not hesitate to contact our customer support team. We are committed to providing the best solutions to save you time, money, and energy.

For assistance, please refer to the contact information provided with your purchase or visit the official NORTHCLAN website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question