

## Aureday XX-FR640PBK

# Aureday 64-inch Extendable Phone & Camera Tripod Stand (Model: XX-FR640PBK) Instruction Manual

## 1. PRODUCT OVERVIEW

The Aureday 64-inch Extendable Phone & Camera Tripod Stand is a versatile accessory designed for stable support of smartphones, tablets, and small cameras. Constructed from high-quality aluminum alloy, it offers adjustable height, a flexible 3-way pan head, and a universal 2-in-1 holder for various devices. It also includes a wireless remote shutter for convenient operation.

- **Multi-functional Tripod Kit:** Supports smartphones, point-and-shoot cameras, and other small cameras. Includes a sturdy tablet holder. Ideal for photography, vlogging, YouTube, family gatherings, and live streaming.
- **Lightweight & Durable:** Made of high-quality aluminum alloy, weighing only 540 g (1.2 lbs). Easy to transport with the included water-resistant carrying bag, suitable for outdoor activities.
- **Extendable Height & 3-way Pan Head:** Height adjustable from 17 inches to 64 inches with quick flip locks. The 3-way pan head and dual built-in bubble levels allow for precise framing and 360-degree swivel for panoramic shots or switching between portrait and landscape modes.
- **2-in-1 Universal Phone and Tablet Holder:** Adaptable clip extends from 2.5 inches to 8.7 inches wide, compatible with various iPad models, Samsung Galaxy Tabs, Kindle devices, Pixel phones, iPhones (6 to 14 series), and other smartphones (≥4.7 inches).
- **Wireless Remote Shutter:** Compatible with iOS (higher than 6.0) and Android (4.2.2 and above) devices within a 10 m (33 ft) range for easy photo and video capture.

## 2. WHAT'S IN THE BOX

- Aureday 64-inch Extendable Phone & Camera Tripod Stand
- 2-in-1 Universal Phone and Tablet Holder
- Wireless Remote Shutter (1 Lithium Metal battery included)
- Water-resistant Carrying Bag

## 3. SETUP INSTRUCTIONS

### 3.1 Unfolding the Tripod

Carefully remove the tripod from its carrying bag. Gently spread the tripod legs until they are fully extended and stable on a flat surface.



Figure 1: The Aureday tripod demonstrating its adjustable height from a compact 17 inches to a maximum of 64 inches, with intermediate heights shown.

### 3.2 Adjusting Tripod Height

1. Locate the quick flip locks on each leg section.
2. Flip open the locks to release the leg sections.
3. Extend each leg section to your desired height. The tripod can extend from 17 inches to 64 inches.
4. Close the flip locks securely to fix the legs in place. Ensure all locks are tightened for stability.
5. For additional height, rotate the center column locking knob counter-clockwise, pull up the center column, and then rotate the knob clockwise to secure it.



Figure 2: Detailed diagram illustrating the various components of the Aureday tripod, including adjustment knobs and leg locks.

### 3.3 Attaching the Device Holder

The 2-in-1 universal holder can be attached to the tripod head. It features a 1/4 standard screw interface. Securely screw the holder onto the tripod head.

# Universal Mount

## 2-in-1 tablet and smartphone holder



Figure 3: The universal 2-in-1 holder for tablets and smartphones, demonstrating its adjustable width and compatibility with a range of devices.

### 3.4 Mounting Your Device

Gently pull apart the spring-loaded clamps of the 2-in-1 holder and insert your smartphone or tablet. Ensure the device is centered and held firmly by the clamps. The holder is compatible with devices between 4.7-11 inches and weighing less than 1.5 lb. For heavy tablets or tablets with a case, add some weight to the tripod base for enhanced stability.

### 3.5 Pairing the Wireless Remote Shutter

1. Turn on the remote shutter by sliding the power switch. A blue indicator light will flash, indicating it's in pairing mode.
2. On your smartphone, go to Bluetooth settings and search for available devices.
3. Select the remote shutter (usually named 'AB Shutter3' or similar) to pair. The blue light will stop flashing once paired.
4. Open your phone's camera app. Press the appropriate button on the remote (iOS or Android) to take photos or start/stop video recording.

Video 1: Demonstrates the unboxing, setup, and remote control functionality of the Aureday tripod, highlighting its ease of use for both iPhone and Android devices.

Video 2: Showcases the various features of the Aureday tripod, including its remote control, emphasizing its versatility for different content creation needs.

## 4. OPERATING INSTRUCTIONS

### 4.1 Using the 3-Way Pan Head

The tripod features a 3-way pan head for flexible positioning:

- **Vertical Tilt:** Use the vertical tilt locking knob to adjust the device's vertical angle.
- **Horizontal Pan:** Use the pan locking knob to rotate the device 360 degrees horizontally for panoramic shots.
- **Portrait/Landscape Mode:** The device holder can be rotated 90 degrees to switch between portrait and landscape orientations.

Utilize the dual built-in bubble view levels on the tripod head and base to ensure your device is perfectly level for professional-looking shots.



Figure 4: Illustrates the flexibility of the 3-way pan head, allowing for vertical and horizontal adjustments, as well as easy switching between portrait and landscape modes.

Video 3: A brief demonstration of the tripod's features and ease of use, highlighting its practical application.



## 4.2 General Usage Tips

- Always ensure the tripod legs are fully extended and locked for maximum stability.
- When using heavy devices, consider adding weight to the base of the tripod for extra stability.
- The tripod is suitable for various scenarios including video recording, selfies, live streaming, and vlogging.



Figure 5: Showcases the wide compatibility of the tripod with various devices and illustrates diverse usage scenarios for content creation.

Video 4: Provides an overview of the tripod's features, emphasizing its affordability and suitability for various needs.

## 5. MAINTENANCE

To ensure the longevity and optimal performance of your Aureday tripod, follow these maintenance guidelines:

- **Cleaning:** Wipe down the tripod with a soft, dry cloth after each use to remove dust and dirt. For stubborn grime, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Storage:** Store the tripod in its water-resistant carrying bag in a cool, dry place when not in use. Avoid exposing it to extreme temperatures or humidity.
- **Inspection:** Periodically check all screws, locks, and joints to ensure they are tight and functioning correctly. Tighten any loose parts as needed.

- **Avoid Overloading:** Do not exceed the recommended weight limit of 1.05 pounds (544.31 grams) for your devices to prevent damage to the tripod.

## 6. TROUBLESHOOTING

---

- **Remote Shutter Not Pairing:** Ensure the remote is turned on and fully charged. Check your phone's Bluetooth settings to confirm it's discoverable and try re-pairing.
- **Tripod Instability:** Make sure all leg flip locks are securely closed and the center column locking knob is tightened. For heavy tablets or devices, add extra weight to the tripod base for improved stability.
- **Device Not Fitting in Holder:** The 2-in-1 holder extends from 2.5 inches to 8.7 inches. Ensure your device falls within this range.

## 7. SPECIFICATIONS

---

Feature	Detail
Product Dimensions	3.86 x 3.82 x 17.24 inches (folded)
Item Weight	1.2 pounds (544.31 Grams)
Material	Aluminum
Color	Black
Maximum Height	64 Inches
Minimum Height	17 Inches
Weight Limit	1.05 Pounds
Tripod Head Type	Pan Heads
Batteries	1 Lithium Metal battery required (included for remote)
Item Model Number	XX-FR640PBK
Date First Available	July 21, 2022

## 8. WARRANTY & SUPPORT

---

For any product inquiries, technical support, or warranty information, please contact Aureday customer service. Refer to the product packaging or the official Aureday website for the most current contact details.