

[Manuals.plus](#) /

> [VINATO](#) /

> VINATO Electric Body Hair Trimmer User Manual

VINATO B0B76QLNXK

VINATO Electric Body Hair Trimmer User Manual

Model: B0B76QLNXK

Brand: VINATO



INTRODUCTION

The VINATO Electric Body Hair Trimmer is designed for efficient and comfortable body hair grooming. Featuring a ceramic blade, a powerful 7000 RPM motor, and a waterproof design, it offers a versatile solution for various body areas. This manual provides essential information for safe and effective use, setup, operation, and maintenance of your trimmer.





Image: The VINATO Electric Body Hair Trimmer in its charging dock, showcasing its sleek black design and digital display.

Video: An overview of the VINATO body hair trimmer, highlighting its design and various color options.

WHAT'S INCLUDED

Your VINATO Electric Body Hair Trimmer package includes the following components:

- VINATO Electric Body Hair Trimmer
- USB Recharge Dock
- USB Charging Cable
- 4 Length Guide Combs (1.5mm, 2.5mm, 3.5mm, 4.5mm)
- Cleaning Brush

- Lubricating Oil Bottle



Image: Close-up of the USB recharge dock for the trimmer.



Image: The four included guide combs for adjusting trimming length.



Image: The cleaning brush and lubricating oil bottle included with the trimmer.

SPECIFICATIONS

Feature	Detail
Product Dimensions	2.32 x 3.27 x 8.03 inches
Item Weight	11.29 ounces (0.32 Kilograms)
Battery	1 Lithium Polymer battery required
Battery Life	Up to 90 minutes of wireless use
Motor Speed	7000 RPM
Blade Type	Ceramic Blade
Waterproof Rating	Fully Waterproof (Shower-friendly)
Charging Method	USB Recharge Dock

Recommended Uses	Armpit, Back Hair, Beard, Chest, Genital, Leg, Pubic, Body
Country of Origin	China

SAFETY INFORMATION

Please read and understand all safety instructions before using the VINATO Electric Body Hair Trimmer:

- Unplug the device before cleaning.
- Do not use while charging.
- Keep away from water except when using in the shower.
- Do not use on broken or irritated skin.
- Consult a healthcare professional if irritation occurs.

SETUP

Charging the Trimmer

Before first use, fully charge the trimmer. Place the trimmer into the USB recharge dock. Connect the USB charging cable to the dock and a compatible power source. The digital display on the trimmer will indicate the battery charge level.

RECHARGEABLE 90 MINS USAGE TIME



Cordless Charging Base



USB Charging



Image: The trimmer being charged via its USB recharge dock, showing the digital power display.

Attaching Guide Combs

To achieve your desired hair length, select one of the four provided guide combs (1.5mm, 2.5mm, 3.5mm, 4.5mm). Align the comb with the trimmer head and gently push until it clicks into place. Ensure the comb is securely attached before use.

STYLE ALL AREAS OF YOUR BODY



Image: The trimmer shown with its various guide combs, indicating different trimming lengths.

OPERATING INSTRUCTIONS

General Trimming

Press the power button to turn on the trimmer. The 7000 RPM motor provides efficient cutting for various hair types. For optimal results, hold the trimmer firmly and move it against the direction of hair growth. The ceramic blade is designed for skin-friendly trimming, minimizing nicks and cuts.

PRO DESIGNED OF BELOW THE-WAIST TRIMMING



Image: Illustration highlighting the powerful 7000 RPM motor of the trimmer.

SOFT CERAMIC BLADE, NO NICKS, NO CUTS



Security



Led Light



Low Noise



Image: Close-up of the soft ceramic blade, designed to prevent nicks and cuts.

Wet and Dry Use

The VINATO trimmer is fully waterproof, allowing for convenient use in both dry and wet conditions, including in the shower. This feature also simplifies the cleaning process.

FULLY WATERPROOF WORK WITH DRY AND WET



Image: The trimmer submerged in water, demonstrating its fully waterproof capability for wet and dry use.

Built-in LED Spotlight

The trimmer features a built-in LED spotlight to illuminate the trimming area, ensuring visibility in low-light conditions and helping to prevent missed spots.

Video: Demonstrates the trimmer's use on various body parts, including the groin, pubic area, chest, and legs, highlighting its versatility.

MAINTENANCE

Cleaning the Trimmer

For hygienic and optimal performance, clean the trimmer before and after each use. The detachable blade can be easily removed for thorough cleaning. Rinse the blade under running water to remove hair clippings. Allow the blade to air dry completely before reattaching it to the trimmer. Do not use a towel or rag to dry the blades, as this may leave particles stuck in the teeth.

Regularly apply a small amount of lubricating oil to the blades to maintain their sharpness and ensure smooth

operation.

TROUBLESHOOTING

If you encounter any issues with your VINATO Electric Body Hair Trimmer, consider the following common solutions:

- **Trimmer not turning on:** Ensure the trimmer is fully charged. Connect it to the charging dock and allow sufficient time for charging.
- **Reduced cutting performance:** Clean the blades thoroughly to remove any accumulated hair or debris. Apply lubricating oil to the blades. If the issue persists, the ceramic blade may need replacement.
- **Irritation after trimming:** Ensure you are using the correct guide comb for sensitive areas. Always trim on clean skin. If irritation continues, discontinue use and consult a healthcare professional.

For further assistance, please refer to the warranty and support section.

WARRANTY AND SUPPORT

VINATO is committed to your satisfaction. Your Electric Body Hair Trimmer comes with a one-year free replacement service. If you have any questions, require troubleshooting assistance, or need to utilize the replacement service, please contact our dedicated support team. Our goal is to ensure every customer is satisfied with our products and services.

