iHome iBT800

iHome PlayGlow Mini Portable Speaker

Instruction Manual

Introduction

Thank you for purchasing the iHome PlayGlow Mini Portable Speaker. This manual provides important information regarding the setup, operation, maintenance, and troubleshooting of your new device. Please read it thoroughly to ensure optimal performance and longevity of your speaker.



Image: The iHome PlayGlow Mini Portable Speaker showcasing its vibrant color-changing light.

Package Contents

- iHome PlayGlow Mini Portable Speaker
- USB Charging Cable



Image: The iHome PlayGlow Mini speaker shown in its retail packaging, highlighting key features.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the speaker's charging port and to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status. A full charge provides up to 15 hours of audio playback.

2. Powering On/Off

Press and hold the Power button located on the speaker to turn it on or off. A sound prompt will indicate the power status.

3. Bluetooth Pairing

Once powered on, the speaker will automatically enter Bluetooth pairing mode, indicated by a flashing light. On your device (smartphone, tablet, laptop), enable Bluetooth and search for 'iHome PlayGlow Mini'. Select it from the list of available devices to pair. A confirmation sound will indicate successful pairing. The speaker can stream audio wirelessly from up to 100 feet.



Image: A hand holding the iHome PlayGlow Mini speaker, illustrating its portability and highlighting Bluetooth connectivity and rechargeable battery life.

Operating Instructions

1. Audio Playback

After successful Bluetooth pairing, you can play audio from your connected device. Use your device's controls to manage playback (play, pause, skip tracks, volume).

2. Color Changing Lights

The speaker features 360-degree color-changing lights with 5 distinct modes:

- **Slow Fade:** Colors transition smoothly.
- **Fast Change:** Colors change rapidly.
- **Favorite Color:** Locks onto a single color.
- **Pulse-to-Music:** Lights react to the beat of the music.
- **Preset Pulsing:** Pre-programmed light patterns.

Refer to the speaker's control buttons for cycling through these light modes.



Image: A display of multiple iHome PlayGlow Mini speakers, each showcasing a different 360-degree LED color mode.

3. Waterproof and Floatable Features

The iHome PlayGlow Mini is iP67 certified, meaning it is waterproof and sandproof. It can be fully immersed in water up to 1 meter (3.3 feet) for up to 30 minutes. Ensure the charging port cover is securely closed before exposing the speaker to water. The speaker is also designed to float, making it suitable for use in pools or baths.



Image: The iHome PlayGlow Mini speaker in a wet environment, illustrating its IP67 certified waterproof and sandproof capabilities, as well as its floatable design.

Maintenance

To ensure the longevity of your speaker, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Drying:** After exposure to water, ensure the speaker is completely dry before charging.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on	Low battery; Power button not held long enough	Charge the speaker; Press and hold the Power button for 3-5 seconds
Cannot pair via Bluetooth	Speaker not in pairing mode; Device Bluetooth off; Speaker already paired to another device	Ensure speaker is on and flashing; Turn on Bluetooth on your device; Disconnect from other devices and try again
No sound during playback	Volume too low; Device not connected; Audio source issue	Increase volume on speaker and device; Re-pair the device; Check audio source on your device
Lights not working	Light mode off; Malfunction	Cycle through light modes; Contact support if issue persists

Specifications

Model Name	iBT800
Material	Plastic
Speaker Type	Portable Bluetooth Speaker, Outdoor
Special Feature	LED Light, Portable, Waterproof
Product Dimensions	2.88"D x 2.88"W x 3.7"H
Item Weight	0.34 Kilograms (12 ounces)
Water Resistance Level	Waterproof (iP67 Certified)
Wireless Communication Technology	Bluetooth
Bluetooth Range	100 Feet
Power Source	Battery Powered (1 Lithium Ion battery included)
Speaker Maximum Output Power	10 Watts
UPC	047532920185

Warranty and Support

This iHome PlayGlow Mini Portable Speaker comes with a Limited Warranty. For detailed warranty information, product support, or to explore other iHome products, please visit the official iHome brand store or contact their customer service.

Visit the iHome Store on Amazon

© 2023 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question