SIKAI CASE 6 Key Macro Mechanical Gaming Macro Keypad

SIKAI CASE Programmable Macro Keyboard User Manual

Model: 6 Key Macro Mechanical Gaming Macro Keypad

Brand: SIKAI CASE

Introduction

The SIKAI CASE Programmable Macro Keyboard is a versatile 6-key mechanical gaming macro keypad designed for enhanced productivity and gaming performance. Featuring a custom knob and hot-swappable switches, this wired keypad allows for extensive customization of key functions and shortcuts. It is compatible with Windows, VISTA, Linux, and Mac operating systems, though initial programming requires a Windows computer. Its compact design makes it an ideal addition to any workspace without occupying excessive desk space.

What's in the Box

- SIKAI CASE Programmable Macro Keyboard
- USB Cable




Image: The SIKAI CASE Programmable Macro Keyboard shown with its included USB-C cable.

Setup

1. Software Download and Installation

To program your SIKAI CASE Macro Keyboard, you must first download and install the dedicated software on a Windows computer. Once programmed, the macros will function on other operating systems like Mac, VISTA, or Linux without needing the software to run in the background.

1. Visit the official SIKAI CASE website for software download:https://sikaicase.com/blogs/news/before-software-setting.
2. Locate and download the "Download the Software" file.
3. Follow the on-screen instructions to install the software.



Image: Screenshot illustrating the software download instructions from the SIKAI CASE website.

2. Connecting the Keypad

Connect the macro keyboard to your computer using the provided USB-C cable. The keypad is plug-and-play for basic functionality, but programming requires the software.




Image: Diagram illustrating the Type-C USB connection for the macro keyboard to a computer.

Operating Instructions

1. Programming Keys and Macros

The SIKAI CASE Macro Keyboard allows for extensive customization. Each macro can include up to 5 characters (letters, numbers, or symbols). The keypad stores these custom shortcuts in its onboard memory, eliminating the need for reprogramming on different computers.

- Open the installed programming software.
- Select the desired key (e.g., KEY1, KEY2) or knob function (e.g., K1 Left, K1 Right, K1 Centre) you wish to program.
- Choose the function type (Key, Ctrl Shift Alt, Multimedia, LED, Mouse) from the left panel.
- Input the desired key combination or function.
- Click "Download" to save the programming to the keypad.



Image: The multi-mode mechanical keypad demonstrating various programmable functions such as setting shortcut keys, custom multimedia control, one-click game actions, and copy/paste.

2. Multimedia Controls and Shortcuts

Program buttons for a variety of tasks including multimedia controls (play, pause, volume), shortcut keys (copy, paste, undo), text snippets, and app launches. This streamlines office work, design projects, and gaming.

3. LED Lighting Modes

The keypad features customizable LED lighting. Use the software to select different LED modes to suit your preference.

- In the software, navigate to the "LED" section.
- Select from available LED modes (e.g., LED Mode1, LED Mode2).
- Click "Download" to apply the selected LED mode to the keypad.

Demonstration Video

Your browser does not support the video tag.

Video: An official demonstration of the SIKAI CASE Programmable Macro Keyboard, showcasing its hot-swappable switches, key programming, multimedia control functions, and LED lighting customization.

Maintenance

To ensure the longevity and optimal performance of your SIKAI CASE Programmable Macro Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keypad. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.
- **Keycap and Switch Care:** The keypad features hot-swappable switches. When removing or installing switches or keycaps, do so gently to avoid damaging the components.
- **Storage:** Store the keypad in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the keypad to liquids, as this can cause internal damage.



Image: A detailed view of the mechanical key switches and keycaps, highlighting the hot-swappable design for easy maintenance and customization.

Troubleshooting

Problem	Possible Cause	Solution
Keypad not recognized by computer.	Loose USB connection, driver issue, or incorrect port.	Ensure the USB-C cable is securely connected to both the keypad and the computer. Try a different USB port on your computer. Restart your computer. Verify that the necessary software/drivers are installed (refer to Setup section).
Programmed macros not working.	Macro not saved correctly, software issue, or conflict with other applications.	Ensure you clicked "Download" in the software after programming each key. Close and reopen the programming software. Ensure no other software is interfering with key inputs. Remember that macro configuration requires Windows, but saved macros can be used on other operating systems.
LED lights not functioning or displaying incorrectly.	Incorrect LED mode selected or software glitch.	In the software, re-select your desired LED mode and click "Download". Ensure the keypad is receiving sufficient power.

Specifications

Feature	Detail
Brand	SIKAI CASE
Number of Keys	6
Connectivity Technology	USB-C
Special Feature	Backlit
Keyboard Description	Gaming
Compatible Devices	Gaming Console (and PC/Mac/Linux via software)
Material	Acrylonitrile Butadiene Styrene
Item Weight	5.6 ounces
Package Dimensions	4.84 x 3.43 x 1.77 inches

Warranty and Support

For warranty information and technical support, please refer to the official SIKAI CASE website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Official SIKAI CASE Store: https://www.amazon.com/stores/SIKAICASE/page/81BB2B56-2435-40E6-8CA0-00081A9BC9B1

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why are my SIKAI CASE SK-06 Macro Keypad settings not being saved to the device memory after clicking Download?

It appears your SIKAI CASE Macro Keypad is failing to commit new settings to its onboard memory. While the manual confirms that clicking "Download" should save settings permanently to the device, here are several...

Read full answer