

Iceman RJ56-D-2

Iceman Countertop Nugget Ice Maker

INSTRUCTION MANUAL

Model: RJ56-D-2

Introduction

The Iceman Countertop Nugget Ice Maker provides restaurant-style nugget ice for your home or office. This machine is designed for convenience, offering quick ice production and easy maintenance. Key features include a 3 lb. ice basket capacity, 26 lbs/24H ice production, waterline compatibility, and a self-cleaning function. Enjoy soft, chewable ice perfect for beverages, entertaining, or simply as a cool snack.

Safety Information

Please read all instructions carefully before operating the appliance. Keep this manual for future reference.

- Ensure the ice maker is placed on a stable, level surface with adequate ventilation (recommended 6 inches clearance on all sides).
- Do not immerse the appliance, cord, or plug in water or other liquids.
- This appliance is UL approved with advanced safety technology. Use only with a 120V/1.7AMPS power supply.
- Keep out of reach of children.
- Unplug the appliance before cleaning or when not in use for extended periods.

Product Overview & Components

The Iceman Countertop Nugget Ice Maker comes with the following components:

- Ice Maker Unit
- Removable Ice Basket
- Ice Scoop
- Waterline Connection Kit (for optional professional installation)



Figure 1: Iceman Countertop Nugget Ice Maker

Makes Ice in Minutes

Make a full batch in 20 minutes



Figure 2: Key Features and Components

Setup

1. **Unboxing:** Carefully remove the ice maker and all accessories from the packaging.
2. **Placement:** Place the unit on a flat, stable countertop away from direct sunlight or heat sources. Ensure proper ventilation around the unit.
3. **Water Source Options:**
 - **Manual Fill:** Open the top lid and pour clean, potable water directly into the water reservoir until it reaches the MAX fill line. The reservoir holds 2.7 liters of water.
 - **Waterline Connection:** For continuous ice-making, the unit can be connected to a main water line. Professional installation is recommended for this option. Refer to the dedicated waterline installation guide for

detailed instructions.

4. **Initial Cleaning:** Before first use, it is recommended to run a cleaning cycle. Refer to the 'Maintenance' section for instructions.

Water Sources

Fill by hand or connect to your home's main water line for perpetual use



*Professional installation recommended.

Figure 3: Water Source Options

Operation

1. **Power On:** Plug the ice maker into a grounded electrical outlet. The unit will enter standby mode.
2. **Start Ice Production:** Press the 'START/STOP' button to begin ice production. The 'ICE' indicator light will illuminate.
3. **Ice Production Cycle:** The machine will begin producing nugget ice. A batch of ice can be made in as little as 20 minutes.

4. **Monitoring Ice Levels:** The top viewing window allows you to monitor the ice level. The 'FULL' indicator light will illuminate when the ice basket is full, and the machine will pause production.
5. **Refill Water:** If the water reservoir is low, the 'REFILL' indicator light will illuminate. Add more water to the reservoir to resume ice production. The machine will automatically reuse melted ice water.
6. **Stopping Production:** Press the 'START/STOP' button again to pause or stop ice production.

It's *THAT* Ice

Impress your guests with
restaurant-quality nugget ice at home



Figure 4: Control Panel and Quick Ice Production

Countertop Nugget Ice Machine



Figure 5: Ice Basket Capacity

Maintenance

Regular cleaning ensures optimal performance and longevity of your ice maker.

1. **Self-Cleaning Function:** The unit features a built-in self-clean function. To activate, ensure the water reservoir is filled, then press and hold the 'HOLD TO CLEAN' button for 3 seconds. The machine will run a cleaning cycle.
2. **Manual Cleaning:**
 - Unplug the ice maker.
 - Remove the ice basket.
 - Locate the drain plug at the bottom of the unit (usually on the side or back). Place a container under the plug and remove it to drain all water from the reservoir.
 - Clean the interior of the water reservoir and ice basket with a soft cloth and mild detergent. Rinse thoroughly.
 - For descaling, a solution of water and vinegar can be used. Run a self-cleaning cycle with this solution, then

drain and rinse thoroughly with clean water.

- Ensure all components are dry before reassembling and operating.



Figure 6: Self-Cleaning Feature

Troubleshooting

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; unit not powered on; ice basket full.	Check 'REFILL' light and add water; ensure unit is plugged in and 'ICE' light is on; empty ice basket if 'FULL' light is on.

Problem	Possible Cause	Solution
'REFILL' light is on, but reservoir has water.	Water sensor may be obstructed or dirty.	Perform a cleaning cycle to clear any mineral buildup on the sensor.
Ice melts quickly in the basket.	Ice maker is not a freezer; ambient temperature is too high.	Transfer ice to a freezer for long-term storage. Ensure adequate ventilation around the unit.
Unusual noises during operation.	Normal operational sounds; internal component issue.	Some operational noises are normal. If noise is excessive or unusual, refer to warranty information or contact customer support.

Specifications

Brand: Iceman

Model Name: Countertop Nugget Ice Maker

Model Number: RJ56-D-2

Product Dimensions: 17.32"D x 9.84"W x 19.29"H

Capacity: 3 Pounds (ice basket) / 2.7 Liters (water reservoir)

Ice Production: Up to 26 lbs per 24 hours

Wattage: 105 watts

Voltage: 120 Volts

Material: Stainless Steel

Refrigerant: R600a

Manufacturer: Chefman

UPC: 810087842802

Warranty and Support

The Iceman Countertop Nugget Ice Maker comes with a **1-year assurance provided by Chefman**.

For detailed warranty information, product support, or to download the full User Guide in PDF format, please visit the official Chefman website or refer to the included documentation.

You can also access the User Guide (PDF) [here](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question