

NPO US-NX10

USAMS NX10 True Wireless Earbuds

User Manual

1. INTRODUCTION

Thank you for choosing the USAMS NX10 True Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.2 connectivity, noise cancellation, and sensitive touch controls. Please read this manual carefully before using the product to ensure proper operation and maintenance.



Image: The USAMS NX10 True Wireless Earbuds in their pink charging case, with the earbuds partially visible inside.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- USAMS NX10 True Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual



USAMS-NX10

Dual-mic ENC TWS Earbuds - NX Series

Image: Display of the USAMS NX10 product packaging, showing available colors: pink, white, and black.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the USB charging cable to the charging port on the case and a power source. The indicator light on the case will show charging status.

- A full charge for the case and earbuds typically takes about 1 hour.
- A quick 10-minute charge can provide approximately 2 hours of listening time.
- The charging case provides additional battery life, extending total listening time up to 28 hours.




Image: Visual representation of charging times and listening durations for the earbuds.



Image: Illustration highlighting the total 28 hours of battery life when using the charging case.

3.2 Pairing with a Device

1. Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "USAMS NX10" in the list of available Bluetooth devices.
4. Select "USAMS NX10" to connect. Once connected, a voice prompt will confirm successful pairing.

The earbuds will automatically reconnect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.




Image: Diagram showing that opening the case lid powers on the earbuds for pairing/reconnection, and closing the lid powers them off.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The USAMS NX10 earbuds feature sensitive touch controls for easy management of music and calls:

- **Play/Pause:** Tap once on either earbud.
- **Hang up call:** Double tap on either earbud.
- **Previous/Next Song:** Double tap on either earbud (specific earbud for prev/next might vary, refer to image).
- **Wake up Siri/Voice Assistant:** Long press the Left earbud for 2 seconds.
- **Low-latency Game Mode On/Off:** Long press the Right earbud for 2 seconds.
- **Reject Call:** Long press either L or R earbud for 1 second.



Image: Visual guide to the touch control functions on the USAMS NX10 earbuds.

4.2 Noise Cancellation (ENC)

The USAMS NX10 features Environmental Noise Cancellation (ENC) for clear phone calls, reducing up to 90% of ambient noise with a noise reduction depth of 30dB.




Image: Diagram illustrating the 90% noise suppression and 30dB noise reduction depth provided by the ENC feature.

4.3 Low-Latency Gaming Mode

Activate the low-latency gaming mode for an optimized audio experience during gaming, reducing audio delay to 60ms. This mode is ideal for competitive gaming where audio synchronization is crucial.



Image: The USAMS NX10 earbuds alongside a smartphone displaying a gaming scene, illustrating the gaming mode

5. MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.

6. TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing	<p>Ensure earbuds are charged.</p> <p>Make sure Bluetooth is enabled on your device.</p> <p>Place earbuds back in the case, close the lid, then open again to re-enter pairing mode.</p> <p>Forget "USAMS NX10" from your device's Bluetooth list and try pairing again.</p>
No sound from one earbud	<p>Ensure both earbuds are charged.</p> <p>Place both earbuds back in the case, close the lid, then open again.</p> <p>Try resetting the earbuds (refer to manufacturer's website if specific reset steps are not in manual).</p>
Earbuds not charging	<p>Check the charging cable and power adapter.</p> <p>Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.</p>
Touch controls not responding	<p>Ensure earbuds are properly seated in your ears.</p> <p>Clean the touch sensitive area on the earbuds.</p> <p>Restart the earbuds by placing them in the case and taking them out again.</p>

7. SPECIFICATIONS

Feature	Detail
Model Number	US-NX10
Wireless Communication Technology	Bluetooth 5.2
Control Type	Touch Control
Special Feature	Noise Cancellation (ENC)

Feature	Detail
Ear Placement	In Ear
Listening Time (Earbuds)	Up to 5 hours (2 hours with 10 min quick charge)
Total Listening Time (with Case)	Up to 28 hours
Low-Latency Gaming Mode	60ms
Item Weight	4.6 ounces
Package Dimensions	6.65 x 3.66 x 1.46 inches

The image displays six key features arranged in a 2x3 grid, each represented by a blue circular icon with a white symbol inside. The features are:

- ENC Function**: Clear Phone Calls
- 2hrs of Listening Time**: 10mins Quick Charging
- BT5.2**: Advanced Chip
- 60ms**: Low-latency Gaming Mode
- 28hrs of Battery Life**: Using with Charging Case
- Sensitive Touch Control**: Multifunctional

Image: Icons representing key features: ENC function, 2 hours listening time with 10 mins quick charging, BT5.2 advanced chip, 60ms low-latency gaming mode, 28 hours of battery life with charging case, and sensitive multifunctional touch control.



Image: An exploded view illustrating the internal components and layered structure of an earbud speaker, highlighting its acoustic design.

8. SAFETY INFORMATION

- Do not disassemble, repair, or modify the product.
- Keep away from water, fire, and high voltage equipment.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Dispose of the product responsibly according to local regulations.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or the official NPO/USAMS website. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: USAMS

Brand: NPO