

- Manuals.plus /
- › [PXBNIUYA](#) /
- › PXBNIUYA 600 LED Plug-in Starburst Lights Instruction Manual (Model YHD-001)

PXBNIUYA YHD-001

PXBNIUYA 600 LED Plug-in Starburst Lights Instruction Manual

Model: YHD-001

1. INTRODUCTION

Thank you for choosing the PXBNIUYA 600 LED Plug-in Starburst Lights. This manual provides essential information for the safe and efficient use of your new lighting product. Please read these instructions carefully before installation and operation, and retain them for future reference.



Image 1.1: PXBNIUYA 600 LED Plug-in Starburst Lights in an outdoor setting.

2. SAFETY INFORMATION

- Ensure the power adapter is suitable for your local voltage and current requirements.
- Do not expose the plug-in adapter to water or extreme weather conditions unless specifically rated for outdoor use. The lights themselves are waterproof.
- Avoid bending the copper wires excessively or repeatedly at the same point to prevent damage.
- Keep out of reach of children and pets.
- Disconnect power before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon unpacking:

- 3 x 600 LED Starburst Light Units (each with 40 copper wires, 5 LEDs per wire)

- 1 x Plug-in Power Adapter
- 1 x Remote Control
- Hanging Hooks (pre-attached or included)



Image 3.1: Contents of the PXBNIUYA 600 LED Starburst Lights package.

4. PRODUCT FEATURES

- **600 LED Bulbs:** Each pack includes three starburst units, totaling 600 bright LED bulbs for enhanced illumination.
- **Flexible Copper Wire:** Each starburst unit features 40 high-quality flexible copper wires, allowing for custom shaping into various designs like bouquets or fireworks.
- **8 Lighting Modes:** Choose from 8 distinct flashing modes, including a steady-on option, to suit different

occasions.

- **Dimmable Function:** Adjust the brightness with 4 adjustable levels to create the desired ambiance.
- **Remote Control:** Conveniently operate the lights, change modes, and set the timer from a distance of up to 10 meters.
- **Timer Function:** Set the lights to automatically turn on for 6 hours and off for 18 hours.
- **Waterproof Design:** The LED bulbs and copper wires are waterproof, making them suitable for both indoor and outdoor use.
- **Plug-in Power:** Reliable AC/DC power source for consistent performance.




Image 4.1: Key features of the starburst lights.

5. SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Connect Starburst Units:** The three starburst light units are designed to connect to a single power adapter. Ensure the spiral ports are securely fastened. One end of the connection adapter can be removed if needed

for specific setups.

3. **Shape the Lights:** Gently bend the copper wires of each starburst unit into your desired shape. The wires are flexible, allowing for creative arrangements.
4. **Positioning:** Use the integrated hooks to hang the lights in your chosen location. Ensure the power adapter is placed in a dry area or is protected from direct water exposure if used outdoors. The lead wire is designed to be long enough for flexible placement.
5. **Connect Power:** Plug the power adapter into a suitable electrical outlet.



Image 5.1: Connection diagram for the starburst lights.

6. OPERATING INSTRUCTIONS

The starburst lights are operated using the included remote control.

Remote Control Functions:



Image 6.1: Remote control for the starburst lights.

- **ON/OFF:** Press the 'ON' button to turn the lights on, and 'OFF' to turn them off.
- **TIMER:** Press the 'TIMER' button to activate the 6-hour on, 18-hour off cycle. The lights will automatically turn on for 6 hours and then turn off for 18 hours, repeating daily.
- **Mode Selection (1-8):** Use buttons '1' through '8' to select different lighting modes. These include various flashing patterns and a steady-on option.
- **DIM+/DIM-:** Use the 'DIM+' and 'DIM-' buttons to adjust the brightness level of the lights. There are 4 adjustable brightness settings.

7. MAINTENANCE

- **Cleaning:** Disconnect the power adapter before cleaning. Use a soft, dry cloth to gently wipe the lights and wires. Do not use abrasive cleaners or immerse the power adapter in water.
- **Storage:** When not in use for extended periods, store the lights in a cool, dry place, away from direct sunlight and moisture. Carefully coil the wires to prevent tangling or damage.
- **Inspection:** Periodically inspect the wires and connections for any signs of wear or damage. If any damage is found, discontinue use and replace the affected components if possible, or the entire unit.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, remote control battery dead.	Check if the power adapter is securely plugged in. Ensure all light unit connections are tight. Replace the remote control battery (CR2032).
Remote control not working.	Remote battery dead, remote out of range, obstruction.	Replace the remote control battery (CR2032). Ensure you are within 10 meters of the lights and there are no major obstructions.
Lights flicker or dim unexpectedly.	Unstable power supply, loose connection, damaged wire.	Ensure the power outlet is stable. Check all connections for tightness. Inspect copper wires for damage.
Timer function not activating.	Timer not set correctly.	Press the 'TIMER' button on the remote control to activate the 6-hour on/18-hour off cycle.

9. SPECIFICATIONS

- **Model Number:** YHD-001

- **Light Source Type:** LED
- **Number of Light Sources:** 600 (3 units, 200 LEDs each)
- **Material:** Copper (wires), Plastic (adapter)
- **Power Source:** AC/DC Plug-in
- **Bulb Features:** Dimmable
- **Mounting Type:** Hanging
- **Remote Control Battery:** 1 x CR2032 (not included)
- **Item Weight:** Approximately 8 ounces (0.5 pounds)
- **Package Dimensions:** 11.34 x 2.99 x 2.48 inches

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact PXBNIUYA customer service through the retailer where the product was purchased. Please have your model number (YHD-001) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B7D96635>

More documents and user manuals: <https://manuals.plus/>