

Jovow 6602

Jovow Baby Gym with Kick and Play Piano Instruction Manual

Model: 6602

Brand: Jovow

1. INTRODUCTION

Thank you for choosing the Jovow Baby Gym with Kick and Play Piano. This activity mat is designed to provide a stimulating and engaging environment for your baby's early development. Featuring multiple play modes, sensory toys, musical piano keys, and soft lights, it supports various stages of infant growth from lying to sitting and tummy time.

ENJOY FUNNY TUMMY TIME



Image: The Jovow Baby Gym with Kick and Play Piano in green, fully assembled with hanging toys and the piano at the foot.

2. SAFETY INFORMATION

- Always supervise your baby during play.
- Ensure all components are securely assembled before placing your baby on the mat.
- Regularly inspect the product for any signs of damage or wear. Discontinue use if any parts are broken or missing.
- Keep small parts out of reach of infants to prevent choking hazards.
- Do not use near open flames or heat sources.

3. PACKAGE CONTENTS

Verify that all the following components are included in your package:

- Soft Activity Mat
- Arch Bridge (2 pieces)
- Piano Unit with 4 illuminated musical keys

- Side Support Legs (2 pieces)
- Connecting Rods for side supports (2 pieces)
- Plastic Screws for assembly
- Detachable Hanging Toys (5 pieces: horse rattle, elephant rattle, rabbit rattle with chew, bee rattle with chew, flower mirror)

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Jovow Baby Gym:

1. Lay the soft activity mat flat on a clean, safe surface.
2. Attach the two side support legs to the base of the activity mat. Ensure they click securely into place.
3. Insert the connecting rods into the designated slots on the side support legs.
4. Connect the two pieces of the arch bridge to form a complete arch.
5. Attach the arch bridge to the top of the connecting rods.
6. Secure the piano unit to the front of the activity mat, ensuring it is firmly attached to the side supports. The piano can be adjusted to different angles.
7. Hang the five detachable toys from the rings on the arch bridge.
8. Insert the plastic screws into the designated holes on the side supports to further secure the structure.

Your browser does not support the video tag.

Video: Official assembly and feature overview of the Jovow Baby Gym with Kick and Play Piano.

Guardrails on both sides

Double-sided pendant to increase the interest of the fitness rack



Image: Close-up view of the guardrails on both sides of the baby gym, providing a secure play area.

Early Music Education Help Brain Development



Image: The piano unit of the baby gym, highlighting the colorful lights, knob control, projection feature, and detachable design.

5. OPERATING INSTRUCTIONS

5.1 Play Modes

The Jovow Baby Gym offers six versatile play modes to adapt to your baby's developmental stages:

- **Lying Play:** Baby lies on their back, kicking the piano keys and reaching for hanging toys.
- **Tummy Time:** The arch can be adjusted or removed to facilitate tummy time, encouraging head and neck development.
- **Sitting Play:** As your baby grows, they can sit and play with the piano and toys.
- **Kick and Play Piano:** The piano keys are designed for babies to kick, producing musical sounds and activating lights.
- **Take-Along Toys:** Detachable toys can be removed for play on the go.
- **Take-Along Piano:** The piano unit can be detached and used independently.

Detachable And Funny Pendant Rattles




Image: Illustration showing four different ways to play with the baby gym: Lay & play, Tummy time, Sit & play, and Take along.

5.2 Piano Functions

- The piano features 4 illuminated musical keys that respond to touch.
- Built-in LED soft lights protect baby's eyesight and promote visual discrimination.
- Multiple modes of music are available, including melodies, animal sounds, and individual notes. Use the mode switch on the piano unit to cycle through these options.
- The piano also includes a light projection function to engage your baby visually.

5.3 Detachable Toys

The five detachable toys are designed for sensory exploration:

- Horse and elephant rattles provide auditory stimulation.
- Rabbit and bee rattles include chewable parts for teething babies.
- A mirror toy encourages self-discovery and visual engagement.



Image: A close-up view of the five detachable hanging toys, including a unicorn rattle, rabbit rattle, honey rattle, elephant rattle, and a baby flower mirror.

6. MAINTENANCE

- The baby play mat is machine washable. Remove all plastic components and toys before washing. Use a gentle cycle with cold water and mild detergent. Air dry or tumble dry on low heat.
- Wipe plastic components and toys with a damp cloth and mild soap. Rinse thoroughly and air dry.
- Do not immerse the piano unit in water. Clean with a dry or slightly damp cloth.

Soft Thick & Machine-Washable Mat for Baby Skin

Strong & Soft Arch for Safe Performance




Image: The soft, thick, and machine-washable mat of the baby gym, emphasizing its comfort and ease of cleaning.

7. TROUBLESHOOTING

- **No Sound/Lights from Piano:** Check if batteries are correctly installed and not depleted. Replace with new disposable batteries if necessary. Ensure the power switch is in the 'On' position.
- **Loose Components:** Re-check all connection points and plastic screws to ensure they are securely fastened.
- **Toys Not Hanging Properly:** Ensure the rings are fully closed and the toys are correctly attached to the arch bridge.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	17.7 x 12 x 4.33 inches
Item Model Number	6602

Target Gender	Unisex
Material Type	Fabric
Power Source	Battery
Batteries Required	No (Batteries for piano not included)
Item Weight	2.59 pounds

9. WARRANTY AND SUPPORT

Jovow products are manufactured with quality and safety in mind. For any questions, concerns, or support needs regarding your Baby Gym, please refer to the retailer's return policy or contact Jovow customer service through their official channels.

Visit the official Jovow Store for more products and support:[Jovow Store](#)