

seenda JP300

seenda Wired Backlit Keyboard for Mac OS

Model: JP300

1. INTRODUCTION

This manual provides instructions for the seenda Wired Backlit Keyboard, Model JP300. This full-size keyboard is specifically designed for Mac OS systems, offering a stable wired connection and adjustable backlighting for enhanced usability.

Key features include a 2-in-1 USB-A and Type-C connector for broad compatibility, dedicated Mac multimedia and shortcut keys, and quiet scissor-switch keys for a comfortable typing experience.

2. SETUP AND CONNECTION

The seenda JP300 keyboard connects directly to your Mac device via a wired connection, ensuring stability and eliminating the need for batteries. It features a versatile 2-in-1 connector.

2.1 Connecting the Keyboard

- 1. Identify the correct connector:** The keyboard cable has a 2-in-1 connector that supports both USB-A and USB-C ports.
 - For devices with a standard USB-A port, use the larger USB-A end of the connector.
 - For devices with a USB-C port, the USB-A end can be detached to reveal a USB-C connector.
- 2. Plug into your Mac:** Insert the appropriate connector into an available USB-A or USB-C port on your iMac, MacBook Pro/Air, Mac Pro, or Mac Mini.
- 3. System Recognition:** Your Mac OS system should automatically detect and configure the keyboard. No additional drivers are typically required.



Image: The keyboard's 2-in-1 connector, showing both USB-A and USB-C options for versatile connectivity.

Note: If connecting to an iPad or iPhone, an additional adapter to a Lightning port may be required (not included).

3. OPERATING INSTRUCTIONS

3.1 Backlight Control

The keyboard features an adjustable white LED backlight. You can control the brightness using the dedicated backlight keys.

- **Adjust Brightness:** Press the **Light Button** (often labeled with a sun icon) to cycle through backlight brightness levels: Off, Low, Medium, High.

BACKLIGHT WIRED KEYBOARD

Strong and beautiful light, 3 levels adjustable - Low/Mid/High



Image: Illustration of the keyboard's adjustable white LED backlight with three brightness levels.

3.2 Multimedia and Shortcut Keys

The keyboard includes a full set of Mac-specific multimedia and shortcut keys for convenient control of your system.

MULTI-MEDIA FUNCTION KEYS FOR MAC

	Decrease Brightness		Volume Down
	Increase Brightness		Volume Up
	Mission Control		Power On / Off (Long Press)
	Search		Select All
	Previous Track		Copy
	Pause / Play		Paste
	Next Track		Cut
	Mute		




Image: Diagram highlighting the multimedia function keys and their corresponding actions on the seenda keyboard.

Common functions include:

- **Brightness Control:** F1 (Decrease Brightness), F2 (Increase Brightness)
- **Mission Control:** F3
- **Search:** F4
- **Media Control:** F7 (Previous Track), F8 (Play/Pause), F9 (Next Track)
- **Volume Control:** F10 (Mute), F11 (Volume Down), F12 (Volume Up)
- **Power On/Off:** Dedicated key (long press for power options)
- **Text Editing:** Select All, Copy, Paste, Cut keys

3.3 Typing Experience

The keyboard utilizes stable scissor-switch keys, providing a low-profile design for quiet and responsive typing. The full-size QWERTY layout includes a numeric keypad for efficient data entry.



Silent Clicking



Scissor Switches



SWIFT RESPONSE & SMOOTH TYPING

Providing supreme comfort and high efficiency

Image: A close-up view illustrating the scissor-switch mechanism beneath a keycap, highlighting silent clicking and smooth typing.

4. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your seenda keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the keycaps and surface. Avoid excessive moisture.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Avoid Spills:** Keep liquids away from the keyboard to prevent damage to internal components.
- **Storage:** When not in use, store the keyboard in a clean, dry environment.

5. TROUBLESHOOTING

If you encounter issues with your seenda keyboard, refer to the following common solutions:

Problem	Solution
---------	----------

Problem	Solution
Keyboard is not responding.	<ul style="list-style-type: none"> • Ensure the USB connector is securely plugged into your Mac's port. • Try plugging the keyboard into a different USB port. • Restart your Mac. • If using a USB-C adapter, ensure the adapter is functioning correctly.
Backlight is not working or is dim.	<ul style="list-style-type: none"> • Press the dedicated Light Button repeatedly to cycle through brightness levels (Off, Low, Medium, High). • Ensure the keyboard is properly connected and receiving power.
Certain keys are not functioning.	<ul style="list-style-type: none"> • Check for any physical obstructions or debris under the keycap. • Try cleaning the keyboard as described in the Maintenance section. • Test the keyboard on another Mac device to determine if the issue is with the keyboard or the computer.

6. SPECIFICATIONS

Below are the technical specifications for the seenda Wired Backlit Keyboard (Model JP300):

- **Model Number:** JP300 (KB049)
- **Connectivity:** Wired (USB-A / Type-C 2-in-1 Connector)
- **Compatibility:** Mac OS (iMac, MacBook Pro/Air, Mac Pro, Mac Mini)
- **Keyboard Layout:** Full-size QWERTY with Numeric Keypad
- **Key Type:** Scissor-switch
- **Backlight:** White LED, 3 adjustable levels (Low, Medium, High) + Off
- **Dimensions (L x W x H):** 17" x 4.8" x 0.3" (thinnest part)
- **Item Weight:** 1.32 pounds
- **Color:** Black and Gray
- **Special Features:** Backlit, Concave Keycaps, Slim Design




Image: Diagram showing the physical dimensions of the seenda keyboard: 17 inches length, 4.8 inches width, and 0.3 to 0.8 inches height.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official seenda website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Manufacturer: seenda