

[Manuals.plus](#) /

› [ASHATA](#) /

› ASHATA Mini 1080P HD WiFi Security Camera User Manual

ASHATA B0B7JCYSDS

ASHATA Mini 1080P HD WiFi Security Camera User Manual

Model: B0B7JCYSDS

1. INTRODUCTION

Thank you for choosing the ASHATA Mini 1080P HD WiFi Security Camera. This compact and versatile camera is designed for real-time surveillance, offering high-definition video, night vision, and motion detection capabilities. It supports mobile application interconnection for remote monitoring and is powered by a built-in rechargeable battery, making it suitable for various indoor and outdoor applications.

The camera features a 110-degree wide-angle lens to cover more areas and reduce blind spots, complemented by a 360-degree rotating magnetic base for flexible placement and adjustment.



Image 1.1: The ASHATA Mini Security Camera is suitable for monitoring various locations such as homes, supermarkets, schools, and factories.

2. PRODUCT COMPONENTS

The ASHATA Mini 1080P HD WiFi Security Camera package typically includes:

- ASHATA Mini Security Camera
- USB Charging Cable
- Magnetic Rotating Base
- User Manual



Image 2.1: Close-up of the camera lens, showing the compact design.



Image 2.2: The magnetic rotating base allows for flexible positioning of the camera.

3. SETUP INSTRUCTIONS

3.1 Initial Charging

Before first use, fully charge the camera for approximately 2 hours using the provided USB charging cable. Connect the cable to the camera's charging port and a standard USB power adapter (not included).

3.2 App Installation

Download the dedicated mobile application from your device's app store (compatible with Android and iOS systems). Search for the app name specified in the included user manual or on the product packaging.

3.3 Camera Connection

1. Power on the camera.

2. Open the installed mobile application.
3. Follow the in-app instructions to add a new device. This typically involves scanning a QR code on the camera or connecting to the camera's temporary Wi-Fi hotspot.
4. Connect the camera to your home or office Wi-Fi network (2.4GHz only).

3.4 Placement

Utilize the 360-degree rotating magnetic base to position the camera. It can be adsorbed onto metallic surfaces or mounted using appropriate hardware (not included). Ensure the camera has a clear line of sight to the area you wish to monitor.



Image 3.1: The camera with its magnetic base, demonstrating flexible placement and remote viewing via smartphone.

4. OPERATING INSTRUCTIONS

4.1 Real-Time Monitoring

Once connected, open the mobile application to view live 1080P HD video from your camera. You can monitor in real-time from any location with an internet connection.




Image 4.1: The mobile app interface showing a clear 1080P HD video feed from the camera.

4.2 Motion Detection

The camera features motion detection. When motion is detected, the camera can send alerts to your mobile device and begin recording. Adjust sensitivity settings within the app.



Motion detection, WiFi connection

Mobile APP interconnection,
wireless remote monitoring

Image 4.2: The camera's motion detection feature triggers alerts and recording, visible on the mobile app.

4.3 Night Vision

The camera is equipped with night vision functionality, allowing for clear monitoring in low-light or dark conditions.



Image 4.3: The camera's night vision capability provides visibility in dark environments.

4.4 Storage

The camera supports a maximum of 128GB small memory card (not included) for local video storage. Recordings can be accessed and managed through the mobile application.

5. MAINTENANCE

5.1 Cleaning

Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the device.

5.2 Battery Care

To prolong battery life, avoid exposing the camera to extreme temperatures. Recharge the battery regularly, even if the camera is not in constant use.

5.3 Software Updates

Periodically check the mobile application for available firmware updates for your camera. Keeping the software

updated ensures optimal performance and security.

6. TROUBLESHOOTING

- **Camera not powering on:** Ensure the camera is fully charged. Connect it to a power source and check for charging indicators.
- **Cannot connect to Wi-Fi:** Verify that your Wi-Fi network is 2.4GHz. Ensure the camera is within range of your router. Restart both the camera and your router. Re-attempt the connection process through the app.
- **Poor video quality:** Check your internet connection speed. Ensure the camera lens is clean and free from obstructions. Adjust camera placement for better lighting.
- **Motion detection not working:** Verify that motion detection is enabled in the app settings. Adjust sensitivity levels as needed. Ensure the camera's view is not obstructed.
- **Short battery life:** Battery life can vary based on usage, Wi-Fi signal strength, and motion detection frequency. Ensure the camera is fully charged. Reduce recording duration or frequency if possible.

7. SPECIFICATIONS

Feature	Specification
Video Capture Resolution	1080p
Connectivity Protocol	Wi-Fi
Power Source	Battery Powered (Built-in 300mAh polymer lithium battery 502030)
Compatible Devices	Smartphone (Android, iOS)
Mounting Type	Wall Mount (with magnetic base)
Special Features	Night Vision, Motion Detection, Wide Angle (110 degrees)
Material	Acrylonitrile Butadiene Styrene (ABS)
Frame Rate	25 fps
Storage Support	Max 128GB small memory card (not included)
International Protection Rating	IP65
Item Weight	2.82 ounces
Dimensions	Approximately 3cm x 3cm x 2.3cm (1.2in x 1.2in x 0.9in)




Image 7.1: Approximate dimensions of the ASHATA Mini Security Camera.

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided on the product packaging or the official ASHATA website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B7JCYSDS>

More documents and user manuals: <https://manuals.plus/>