Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo ET2107

ChooChoo End Side Table Instruction Manual

Model: ET2107 | Brand: ChooChoo

Product Overview

The ChooChoo End Side Table (Model ET2107) is a modern and stylish furniture piece designed to complement various living spaces. Featuring a unique X-design and a convenient storage shelf, this black end table offers both aesthetic appeal and practical functionality. It is constructed from durable engineered wood, ensuring stability and longevity.



Figure 1: ChooChoo End Side Table (Model ET2107)

Safety Information

WARNING: This product has a weight of 23 pounds. Adult assembly is required. Ensure stability to prevent tipping. Always place the table on a flat, stable surface. Do not overload the table or shelves.

Package Contents

Before beginning assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer service.

- 1 x End Table (disassembled components)
- 1 x Instruction Manual
- 8 x Hole Stickers (for covering screw holes)
- Assembly Tools (as specified in instructions, typically a screwdriver)

Assembly Instructions

Assembly of the ChooChoo End Side Table is designed to be straightforward. Please follow these steps carefully. It is recommended to assemble the table on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and identify each part by referring to the numbered illustrations in the included instruction booklet.
2. **Attach Base Components:** Begin by attaching the X-design support pieces to the bottom base panel using the provided screws. Ensure the pieces are oriented correctly as shown in the diagrams.
3. **Secure Top Panel:** Once the base structure is stable, align the top panel with the upper connection points of the X-design supports. Secure it firmly with the remaining screws.
4. **Apply Hole Stickers:** After all screws are tightened, use the provided hole stickers to cover the visible screw holes for a clean, finished appearance.
5. **Attach Felt Pads:** For floor protection, attach the self-adhesive felt pads to the bottom corners of the table's base.




Figure 2: Table Dimensions for Assembly Reference




Figure 3: Key Features and Components

Usage

The ChooChoo End Side Table is designed for versatile use in various settings:

- **Living Room:** Ideal as an end table next to a sofa or armchair, providing a surface for lamps, drinks, or decorative items.
- **Bedroom:** Can serve as a bedside table for books, a lamp, or personal belongings.
- **Office:** Suitable as a small side table for holding beverages, snacks, or documents.
- **Storage:** The open lower shelf provides convenient storage for magazines, books, or small decorative plants.

Maintenance

To ensure the longevity and appearance of your ChooChoo End Side Table, follow these maintenance guidelines:

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.

- **Spills:** Promptly wipe up any spills to prevent staining, especially on the engineered wood surface.
- **Heat and Moisture:** Use coasters under hot or wet items to protect the tabletop.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.

Troubleshooting

If you encounter any issues with your ChooChoo End Side Table, please refer to the following common solutions:

- **Table Wobbles:**
  - Ensure the table is placed on a level surface.
  - Check that all screws are securely tightened.
  - Verify that all components are correctly assembled according to the instructions.
- **Missing or Damaged Parts:**
  - Carefully re-check the packaging to ensure no small parts were overlooked.
  - Contact ChooChoo customer service with your product model and a description of the missing/damaged part for assistance.
- **Assembly Difficulties:**
  - Review the instruction manual step-by-step, paying close attention to illustrations and part numbers.
  - Ensure parts are not installed backward or upside down.
  - If issues persist, contact customer service for guidance.

Specifications

Attribute	Detail
Brand	ChooChoo
Model Name	ET2107
Product Dimensions	16"D x 22"W x 20"H (40.6cm D x 55.9cm W x 50.8cm H)
Color	Black
Material Type	Engineered Wood
Item Weight	23 Pounds (10.4 kg)
Table Design	End Table
Style	Modern
Number of Shelves	1
Recommended Number of People for Assembly	1
Tools Recommended For Assembly	Screw Driver (not included)

Warranty & Support

ChooChoo provides customer services before and after your purchase. For any questions or concerns regarding your ChooChoo End Side Table, please contact our customer support team. We aim to respond within 24 hours.
Please retain your proof of purchase for any warranty claims. Specific warranty details may be provided with your product packaging or can be obtained by contacting customer service.
For further assistance, visit the official ChooChoo Store: ChooChoo Store on Amazon

© 2024 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B7KZDCP1

More documents and user manuals: **https://manuals.plus/**