

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### PowerA XBGP0025-01

# PowerA Nano Enhanced Wired Controller for Xbox Series X|S - Lilac User Manual

Official User Manual for Model XBGP0025-01

## PRODUCT OVERVIEW

The PowerA Nano Enhanced Wired Controller is designed for compact portability and enhanced gaming performance across Xbox Series X|S, Xbox One, and Windows 10/11. This controller features a smaller, lightweight design, making it ideal for players who prefer a more compact gamepad without sacrificing functionality.



Figure 1: Front view of the PowerA Nano Enhanced Wired Controller in Lilac. This compact controller features a D-pad, two analog sticks, ABXY buttons, and central navigation buttons, all in a vibrant lilac color.

Key features include two mappable Advanced Gaming Buttons, dual rumble motors for immersive feedback, a 3.5mm stereo headphone jack for in-game audio, and a dedicated Share button for capturing and sharing gameplay moments. The controller connects via a detachable 10ft (3m) USB-C cable, ensuring a reliable and lag-free gaming experience without the need for batteries.

## SETUP GUIDE

Follow these steps to set up your PowerA Nano Enhanced Wired Controller:

- 1. Unpack the Controller:** Carefully remove the controller and its detachable USB-C cable from the packaging.
- 2. Connect the Cable:** Insert the USB-C end of the cable into the port on the top of the controller.
- 3. Connect to Console/PC:**
  - For Xbox Series X|S or Xbox One:** Plug the USB-A end of the cable into an available USB port on your Xbox console. The controller will automatically connect and be ready for use.
  - For Windows 10/11 PC:** Plug the USB-A end of the cable into an available USB port on your PC. Windows will automatically detect and install the necessary drivers. If prompted, allow the installation.
- 4. Verify Connection:** The controller's Xbox button will illuminate once successfully connected. You can now begin

gaming.



Figure 2: The detachable USB-C cable being connected to the top port of the PowerA Nano Controller. Ensure the cable is fully inserted for a secure connection.

## OPERATING INSTRUCTIONS

---

### Basic Controls

The PowerA Nano Enhanced Wired Controller features standard Xbox button layouts for intuitive gameplay:

- **Left/Right Analog Sticks:** For movement and camera control.
- **D-Pad:** For directional input, menu navigation.
- **A, B, X, Y Buttons:** Action buttons, typically color-coded.
- **Left/Right Bumpers (LB, RB):** Shoulder buttons.
- **Left/Right Triggers (LT, RT):** Analog triggers for precise input.
- **View Button (█):** Access in-game maps, menus, or other functions.
- **Menu Button (█):** Access game menus or system options.
- **Share Button (█):** Quickly capture screenshots or record game clips.
- **Xbox Button (█):** Power on/off console, access Xbox Guide.

### Advanced Gaming Buttons

The controller features two mappable Advanced Gaming Buttons (AGB) on the back, allowing you to assign any standard button function for quick access during gameplay.



## MAPPABLE ADVANCED GAMING BUTTONS

Figure 3: Close-up view of the mappable Advanced Gaming Buttons located on the underside of the controller, labeled AGL and AGR. These buttons can be programmed for custom functions.

### To Program Advanced Gaming Buttons:

1. Press the **Program Button** (located on the back of the controller, near the center) until the LED indicator on the front of the controller begins to flash slowly.
2. Press the standard button you wish to map (e.g., A, B, X, Y, LB, RB, LT, RT, D-pad directions, or analog stick clicks). The LED will flash more quickly.
3. Press the Advanced Gaming Button (AGR or AGL) you wish to assign the function to. The LED will stop flashing, indicating successful programming.
4. Repeat the process for the other Advanced Gaming Button if desired.

*Note: Mapped functions remain active even after disconnecting the controller. To clear mappings, hold the Program Button for 5 seconds until the LED flashes rapidly, then release.*

### Dual Rumble Motors

The controller is equipped with dual rumble motors that provide immersive haptic feedback, enhancing your gaming experience with vibrations that correspond to in-game actions like explosions, impacts, and more.



**DUAL RUMBLE MOTORS**

Figure 4: An internal view diagram of the controller highlighting the placement of the dual rumble motors within the grips, responsible for haptic feedback.

### **3.5mm Stereo Headphone Jack**

Connect your favorite wired gaming headset to the 3.5mm stereo headphone jack located on the bottom of the controller for in-game audio and chat functionality.



## 3.5mm STEREO HEADPHONE JACK

Figure 5: Close-up view of the 3.5mm stereo headphone jack located on the bottom edge of the controller, allowing for audio output and microphone input.

### Compact Portable Size

The Nano controller is designed to be smaller and lighter than standard controllers, making it highly portable and comfortable for various hand sizes. Its dimensions are approximately 9.19 cm (3.62 inches) in height and 13.59 cm (5.35 inches) in width.



## COMPACT PORTABLE SIZE

Figure 6: An image illustrating the compact size of the PowerA Nano Controller, showing its approximate height of 3.62 inches. While the image indicates a width of 4.14 inches, the product specifications state a total width of approximately 5.35 inches (13.59 cm), suggesting the image measurement might refer to a specific part of the controller.

### Additional Features

- **Anti-Friction Rings:** Smooth movement around the analog sticks for enhanced control.
- **Diamond Textured Grip:** Provides a comfortable and secure hold during extended gaming sessions.



Figure 7: A detailed diagram highlighting various features of the PowerA Nano Enhanced Wired Controller, including the Share Button, Anti-Friction Rings, 3.5mm Stereo Headset Jack, Dual Rumble Motors, Program Button, Two Advanced Gaming Buttons, Detachable USB-C Cable, and Diamond Textured Grip.

## MAINTENANCE

Proper care and maintenance will extend the life of your controller:

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. Disconnect the USB-C cable when not in use.
- **Cable Care:** Avoid sharp bends or kinks in the USB-C cable. Do not pull the cable to disconnect it; always grasp the connector.
- **Avoid Drops:** Protect the controller from drops or impacts, which can damage internal components.

## TROUBLESHOOTING

If you encounter issues with your PowerA Nano Enhanced Wired Controller, refer to the following common solutions:

Problem	Possible Solution
Controller not recognized by Xbox/PC.	<ul style="list-style-type: none"><li>Ensure the USB-C cable is securely connected to both the controller and the console/PC.</li><li>Try a different USB port on your console/PC.</li><li>Restart your console or PC.</li><li>Ensure your console/PC operating system is up to date.</li></ul>
Buttons or analog sticks are unresponsive.	<ul style="list-style-type: none"><li>Disconnect and reconnect the controller.</li><li>Test the controller in a different game or application to rule out software issues.</li><li>Check for any physical obstructions or debris around the buttons/sticks.</li></ul>
Vibration feedback is not working.	<ul style="list-style-type: none"><li>Ensure the game you are playing supports rumble feedback.</li><li>Check in-game settings to ensure vibration is enabled.</li><li>Verify that the controller is properly connected.</li></ul>
Headset audio or microphone not working.	<ul style="list-style-type: none"><li>Ensure your headset is fully plugged into the 3.5mm jack.</li><li>Check your console/PC audio settings to ensure the controller's audio output is selected.</li><li>Test the headset with another device to confirm it is functioning correctly.</li></ul>

If these solutions do not resolve your issue, please visit the PowerA support website for further assistance.

## SPECIFICATIONS

- Model Number:** XBGP0025-01
- Compatibility:** Xbox Series X|S, Xbox One, Windows 10/11
- Connectivity:** Wired USB-C (detachable 10ft/3m cable included)
- Dimensions (L x W x H):** Approximately 13.59 cm x 9.19 cm x 5 cm (5.35 in x 3.62 in x 1.97 in)
- Weight:** Approximately 229.97 g (0.51 lbs)
- Features:** Two mappable Advanced Gaming Buttons, Dual Rumble Motors, 3.5mm Stereo Headphone Jack, Share Button, Anti-Friction Rings, Diamond Textured Grip.
- Color:** Lilac

## WARRANTY AND SUPPORT

For warranty information, product registration, and technical support, please visit the official PowerA website. You can find detailed FAQs, troubleshooting guides, and contact information for customer service there.

**Online Support:** [www.powera.com/support](http://www.powera.com/support)

*Please retain your proof of purchase for warranty claims.*



[\[pdf\] Catalog](#)

Catálogos Riverint CATALOGO POWER A tienda riverint Catalogo |||

ndice XBOX ..... arras:

0617885045257 Dun14: 10617885045254 Unidades de embalaje: 4 Cdigo River:  
70083XX241 POWER A **XBGP0025-01** NANO ENHANCED MANDO CON CABLE  
XBOX SERIES X/S LILA Ms pequeno, ligero y fcil de usar, el ...  
lang:i-klingon **score:13** filesize: 1.82 M page\_count: 59 document date: 2024-08-02



[\[pdf\] Catalog](#)

CATALOGO POWER A riverint Catalogo |||

ndice XBOX ..... arras:

0617885045257 Dun14: 10617885045254 Unidades de embalaje: 4 Cdigo River:  
70083XX241 POWER A **XBGP0025-01** NANO ENHANCED MANDO CON CABLE  
XBOX SERIES X/S LILA Ms pequeno, ligero y fcil de usar, el ...  
lang:i-klingon **score:13** filesize: 1.83 M page\_count: 59 document date: 2023-10-09