

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [COACH](#) /

› COACH Signature Strawberry Leather Long Zip Around Clutch Wallet - Model CB593 User Manual

## COACH CB593

# COACH Signature Strawberry Leather Long Zip Around Clutch Wallet - Model CB593 User Manual

Model: CB593

## INTRODUCTION

This manual provides instructions for the proper use and care of your COACH Signature Strawberry Leather Long Zip Around Clutch Wallet, model CB593. Designed for functionality and style, this wallet offers organized storage for your essentials.

## PRODUCT FEATURES

- Twelve credit card slots for organized storage.
- Full-length bill compartments to keep currency flat.
- Inside zip coin pocket for secure coin storage.
- Detachable wrist strap for versatile carrying options.
- Dimensions: 7 1/2" (L) x 4" (H) x 1" (W).

## SETUP AND FIRST USE

Upon receiving your new COACH wallet, carefully unwrap it from its packaging. Inspect the wallet for any visible damage. The wallet is ready for immediate use.

1. **Unzipping:** Locate the main zipper pull and gently open the wallet completely.
2. **Initial Inspection:** Familiarize yourself with the internal layout, including card slots, bill compartments, and the coin pocket.
3. **Attaching Wrist Strap:** If desired, attach the detachable wrist strap to the designated loop on the wallet. Ensure it is securely fastened.



Image: The COACH Signature Strawberry Leather Long Zip Around Clutch Wallet fully unzipped, revealing its organized interior with multiple card slots, bill compartments, and a central zippered coin pocket. The gold-tone hardware is visible.

## OPERATING AND USAGE

---

This wallet is designed for efficient organization of your daily essentials.

- **Credit Card Slots:** Insert credit cards, identification cards, or business cards into the twelve dedicated slots.
- **Bill Compartments:** Place unfolded banknotes into the full-length compartments on either side of the central coin pocket.
- **Coin Pocket:** Use the interior zippered pocket for secure storage of coins or small items. Ensure the zipper is fully closed to prevent items from falling out.
- **Detachable Wrist Strap:** Utilize the wrist strap for convenient carrying, allowing the wallet to be held securely on your wrist.

## MAINTENANCE AND CARE

---

To maintain the quality and longevity of your leather wallet, follow these care guidelines:

- **Cleaning:** Wipe the leather surface with a soft, dry cloth. For minor stains, use a damp cloth with a mild leather cleaner specifically designed for genuine leather. Test any cleaner on an inconspicuous area first.
- **Avoid Moisture:** Protect the wallet from excessive moisture, rain, and direct sunlight. If it gets wet, blot gently with a clean, dry cloth and allow it to air dry naturally, away from direct heat.
- **Storage:** When not in use, store the wallet in a cool, dry place, preferably in a dust bag to protect it from dust and scratches. Avoid storing in plastic bags, which can trap moisture.

- **Avoid Harsh Chemicals:** Do not use harsh chemicals, abrasive cleaners, or alcohol-based products, as these can damage the leather finish.
- **Zipper Care:** Keep the zipper clean and free of debris. If the zipper becomes stiff, a small amount of zipper lubricant or wax can be applied carefully.

## TROUBLESHOOTING

---

Refer to the following for common issues:

- **Stiff Zipper:** If the zipper feels stiff, ensure no fabric or debris is caught. Apply a small amount of zipper lubricant or a graphite pencil lead along the teeth to improve smoothness.
- **Leather Discoloration:** Leather can naturally change color over time with exposure to light and oils from hands. This is a characteristic of genuine leather. Avoid prolonged direct sunlight exposure.
- **Strap Detachment:** Ensure the wrist strap's clasp is fully closed and securely attached to the wallet's loop. Periodically check the clasp for wear.

## SPECIFICATIONS

---

<b>Model Number</b>	CB593
<b>Dimensions (L x H x W)</b>	7 1/2" x 4" x 1" (approximately 19.05 cm x 10.16 cm x 2.54 cm)
<b>Material</b>	Leather
<b>Weight</b>	Approximately 236 g (0.52 lbs)
<b>Card Slots</b>	Twelve
<b>Compartments</b>	Full-length bill compartments, interior zip coin pocket

## WARRANTY AND SUPPORT

---

For information regarding warranty coverage, product support, or service inquiries, please refer to the official COACH website or contact their customer service department. Keep your purchase receipt as proof of purchase.

*Note: This manual provides general guidance. Specific warranty terms may vary by region and retailer.*

