

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SPLITSKY](#) /

› [SPLITSKY Aromatherapy Essential Oil Home Diffuser with Remote Control, 300ML User Manual](#)

SPLITSKY dgxd300mlQ

SPLITSKY Aromatherapy Essential Oil Home Diffuser

Model: dgxd300mlQ

INTRODUCTION

Thank you for choosing the SPLITSKY Aromatherapy Essential Oil Home Diffuser. This device is designed to enhance your environment with soothing aromas and gentle humidification. Featuring a 300ml water tank, two atomization modes (intermittent and continuous), four timer settings, and seven LED ambient light colors, it offers a customizable experience. Its quiet operation and automatic shut-off feature ensure safe and convenient use in various settings, including homes, offices, and yoga spaces.

SAFETY PRECAUTIONS

- Always place the diffuser on a stable, flat surface.
- Do not exceed the maximum water level indicated inside the tank.
- Use only pure essential oils. Avoid corrosive or synthetic oils that may damage the unit.
- The diffuser features an automatic shut-off function when the water level is low, preventing dry burning.
- Keep out of reach of children and pets.
- Unplug the device before cleaning or refilling.
- This product is made from BPA-free materials, ensuring safe use.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x SPLITSKY Aromatherapy Essential Oil Diffuser (Model: dgxd300mlQ)
- 1 x Remote Control
- 1 x Power Adapter
- 1 x User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your SPLITSKY diffuser:



Image: Front view of the SPLITSKY Aromatherapy Diffuser, showing the main unit with its wood grain base and white top, featuring the 'MIST/TIMER' and 'LIGHT' buttons on the front.

- **Mist Outlet:** Located at the top, where the cool mist is released.
- **Lid:** Removable cover for accessing the water tank.
- **Water Tank:** 300ml capacity for water and essential oils.
- **MIST/TIMER Button:** Controls mist output and timer settings.
- **LIGHT Button:** Controls the LED ambient lighting.
- **Power Inlet:** Located at the base for connecting the power adapter.
- **Remote Control:** Allows for convenient adjustment of mist, timer, and light settings from a distance.

Easy to Use Two Buttons Low Noise Operation



MIST/TIMER Button



Light Button



Image: A close-up view of the diffuser's front panel, highlighting the 'MIST/TIMER' and 'LIGHT' buttons, along with indicator lights for different timer settings (10s intermittent, 2H, 4H).

SETUP INSTRUCTIONS

- Place the Diffuser:** Position the diffuser on a flat, stable surface away from direct sunlight or heat sources.
- Remove the Lid:** Gently lift the top cover of the diffuser.
- Add Water:** Fill the water tank with clean tap water up to the maximum water level line (300ml). Do not overfill.
- Add Essential Oil:** Add 3-5 drops of your preferred essential oil directly into the water tank. Adjust the amount based on personal preference and room size.
- Replace the Lid:** Securely place the lid back onto the diffuser.
- Connect Power:** Plug the power adapter into the power inlet at the base of the diffuser, then plug the adapter into a standard electrical outlet.

OPERATING INSTRUCTIONS

Mist Control

Independent Operation



◀ Mist Only ▶

Short press the MIST button



Light Only



Work as nightlight



Image: Two panels illustrating independent operation. The top panel shows the diffuser emitting mist, labeled 'Mist Only'. The bottom panel shows the diffuser glowing blue, labeled 'Light Only', functioning as a nightlight.

- **To Turn On Mist:** Press the 'MIST/TIMER' button once. The diffuser will start in continuous mist mode.
- **To Set Timer:** Press the 'MIST/TIMER' button repeatedly to cycle through timer settings: 10-second intermittent mist, 2 hours, 4 hours, and continuous mist. The corresponding indicator light will illuminate.
- **To Turn Off Mist:** Continue pressing the 'MIST/TIMER' button until all mist indicator lights are off, or use the remote control.

LED Light Control

7 LED Color Lights



Adjustable Brightness
(bright and dim)



Fixed color



Rotating Color



LED & Mist Mode
Works Separately



Image: The diffuser glowing with various LED colors, showcasing the 7 available light options. Icons above indicate adjustable brightness, fixed color, rotating color, and separate mist/light operation.

- **To Turn On Light:** Press the 'LIGHT' button once. The light will cycle through 7 colors automatically.
- **To Set Fixed Color:** Press the 'LIGHT' button repeatedly to select your desired color.
- **To Adjust Brightness:** For some colors, a second press on the 'LIGHT' button while on that color may adjust its brightness (bright/dim).
- **To Turn Off Light:** Continue pressing the 'LIGHT' button until the light turns off, or use the remote control.

Remote Control Operation



The product is plugged in to work, press the light button will display 7 LED light colors

Image: A SPLITSKY diffuser glowing green, with its remote control placed next to it. The remote allows for convenient adjustment of settings.

The included remote control allows you to operate the diffuser from a distance. Functions typically include:

- **Mist On/Off:** Activates or deactivates mist.
- **Timer Settings:** Selects 10s intermittent, 2H, 4H, or continuous mist.
- **Light On/Off:** Turns the LED light on or off.
- **Color Selection:** Cycles through or sets a specific LED color.

MAINTENANCE

Regular cleaning helps maintain the diffuser's performance and extends its lifespan.

Daily Maintenance

- Empty any remaining water from the tank.
- Wipe the inside of the water tank with a clean, soft cloth.

Weekly Cleaning

- Unplug the diffuser from the power outlet.
- Remove the lid and empty the water tank.
- Add a small amount of warm water (do not use hot water) and 1-2 drops of white vinegar to the water tank.
- Let it soak for 5-10 minutes.
- Gently wipe the inside of the tank and the ultrasonic disc with a soft brush or cotton swab. Avoid scrubbing forcefully.
- Rinse the tank thoroughly with clean water, ensuring no vinegar residue remains.
- Wipe the exterior of the diffuser with a soft, dry cloth.
- Ensure all parts are completely dry before reassembling and storing or reusing.

Do not immerse the diffuser base in water. Do not use harsh detergents or abrasive cleaners.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or weak mist	Insufficient water; water level too high; ultrasonic disc dirty; lid not properly placed.	Add water to the appropriate level; clean the ultrasonic disc; ensure the lid is securely closed.
Diffuser does not turn on	No power connection; power adapter faulty.	Check if the power adapter is securely plugged into both the diffuser and the outlet; try a different outlet.
Water leaking from the unit	Overfilled water tank; diffuser placed on an uneven surface; lid not sealed correctly.	Ensure water is below the MAX line; place on a flat, stable surface; re-seat the lid properly.
Remote control not working	Battery depleted; obstruction between remote and diffuser; remote not pointed correctly.	Replace the remote control battery; ensure a clear line of sight to the diffuser's sensor.
Unusual noise	Low water level; diffuser not on a flat surface.	Add water; ensure the diffuser is on a stable, flat surface.

SPECIFICATIONS

Small and Compact 300ML Diffuser



Image: A visual comparison showing the dimensions of the SPLITSKY 300ML diffuser (5.11" L x 5.11" W x 4.01" H) next to a smartphone for scale.

- **Brand:** SPLITSKY
- **Model Name:** dgxd300mlQ
- **Capacity:** 300 Milliliters
- **Product Dimensions:** 5.11" L x 5.11" W x 4.01" H
- **Item Weight:** 0.36 Kilograms (12.7 ounces)
- **Material:** Plastic
- **Power Source:** Corded Electric
- **Wattage:** 10 Watt-hours
- **Special Feature:** 7 LED Night Light, Auto Shutoff, Remote Control
- **Recommended Uses:** Home, Office, Yoga, SPA
- **Color:** Yellow Wood Grain (variant shown)


WARRANTY AND SUPPORT

The SPLITSKY Aromatherapy Essential Oil Home Diffuser is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or contact SPLITSKY customer support.

If you encounter any issues or have questions regarding your product, please contact SPLITSKY customer service through the retailer's platform or the official SPLITSKY website. Please have your model number (dgxd300mIQ) and purchase date available when contacting support.

© 2025 SPLITSKY. All rights reserved.

Related Documents - dgxd300mIQ

	<p>SPLITSKY 400ML Aroma Diffuser User Manual Operation, Maintenance & Troubleshooting Guide</p> <p>Comprehensive user manual for the SPLITSKY 400ML Aroma Diffuser. Learn how to operate, maintain, and troubleshoot your essential oil diffuser for optimal performance.</p>
 <p>User Manual Colorful Light Alarm Clock</p> <p>Read and follow all instructions in this user manual before use. Note: The CR2032 batteries only save the time of day and the programmed wake time. All functions are only possible with main power operation.</p>	<p>Colorful Light Alarm Clock User Manual</p> <p>User manual for the Colorful Light Alarm Clock, detailing its features, settings, and maintenance. Includes instructions for time setting, alarm configuration, snooze function, relaxing bedtime sounds, colorful light modes, and battery replacement.</p>
 <p>RGB Color Changing Clock</p> <p>Model CH-07</p> <p>User's Manual</p> <p>Please read the operation manual carefully and save it for reference when needed.</p>	<p>SPLITSKY CH-07 RGB Color Changing Clock User Manual</p> <p>Comprehensive user manual for the SPLITSKY CH-07 RGB Color Changing Clock. Learn how to set up, configure alarms, adjust display colors and brightness, use FM radio, and utilize the sleep countdown timer.</p>