

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AGPTEK](#) /

› [AGPTEK 32GB MP3 Player with Clip User Manual](#)

## AGPTEK 32GB MP3 Player

# AGPTEK 32GB MP3 Player with Clip

User Manual

## 1. INTRODUCTION

---

Thank you for choosing the AGPTEK 32GB MP3 Player with Clip. This device is designed to provide a portable and versatile audio experience, featuring Bluetooth 5.3, FM radio, and a voice recorder. Its compact design and integrated clip make it ideal for sports and on-the-go use. This manual will guide you through the setup, operation, and maintenance of your new MP3 player.



Image: Front view of the AGPTEK 32GB MP3 Player, showcasing its compact design and screen.

## 2. PRODUCT OVERVIEW

---

### Key Features:

- **32GB Internal Storage:** Ample space for your music library.
- **Expandable Memory:** Supports up to 128GB TF (Micro SD) card for additional storage.
- **Bluetooth 5.3:** For stable and efficient wireless audio streaming.
- **Lossless Sound:** High-fidelity audio playback.
- **FM Radio:** Tune into your favorite radio stations.
- **Voice Recorder:** Capture audio notes and lectures.
- **Integrated Clip:** Securely attach the player to clothing for hands-free use during activities.
- **Pedometer Function:** Track your steps during workouts.

- **E-Book Reader:** Read text files on the go.

## Components:

The AGPTEK MP3 player includes the main unit, a USB charging/data cable, and a user manual. Please ensure all components are present upon unboxing.



Image: Side view of the AGPTEK MP3 player, highlighting its compact size and integrated clip.

## 3. SETUP

### 3.1 Charging the Device

Before first use, fully charge your MP3 player. Use the included USB cable to connect the player to a computer's USB port or a compatible USB wall adapter (not included). The battery indicator on the screen will show charging status. A full charge typically takes approximately 1.5 hours.

### 3.2 Transferring Music Files

To transfer music from your computer to the MP3 player:

1. Connect the MP3 player to your computer using the provided USB cable.
2. On the MP3 player screen, select "Charge & Transfer" when prompted.
3. Your computer will recognize the MP3 player as a removable disk. Open the device folder.
4. Manually create a new folder (e.g., named "Music") within the player's storage.
5. Copy your desired music files from your computer and paste them into the newly created "Music" folder on the MP3 player. It is recommended to rename song files with a numerical or alphabetical prefix (e.g., "001-SongTitle.mp3") for proper sorting.
6. Once the transfer is complete, safely eject the MP3 player from your computer before disconnecting the USB cable.
7. On the MP3 player, navigate to the "Music" menu and select "Update Playlist" to refresh your music library.

## SCHRITZÄHLER FUNKTION

Schritte Entfernung Kalorien  
Geschwindigkeit





Image: The AGPTEK MP3 player connected to a laptop, illustrating the file transfer process.

Your browser does not support the video tag.

Video: A step-by-step guide on how to transfer music files from a PC to the AGPTEK MP3 Player.

## 4. OPERATING INSTRUCTIONS

## 4.1 Basic Music Playback

Navigate to the "Music" icon on the main menu. Select "All songs," "Artists," "Albums," or "Genres" to browse your music. Use the navigation buttons to select a track and press the play button to start playback. Use the volume buttons on the side to adjust the sound level. The player supports various audio formats for lossless sound quality.



Image: The MP3 player screen showing music playback with Bluetooth 5.0 connectivity indicated.

## 4.2 Bluetooth Connectivity

To connect your MP3 player to Bluetooth headphones or speakers:

1. Turn on your Bluetooth headphones/speaker and set them to pairing mode.
2. On the MP3 player, go to the main menu and select the "Bluetooth" icon.
3. The player will scan for available Bluetooth devices. Select your device from the list to pair.
4. Once paired, audio will be routed through your Bluetooth device.

# BLUETOOTH 5.0

Kabellose Verbindung



Image: The MP3 player screen displaying Bluetooth 5.0 connection status and a graphic equalizer during music playback.

## 4.3 FM Radio

Plug in wired headphones (they act as the antenna). From the main menu, select "FM Radio." You can perform an auto-scan to find and save available stations or manually tune to a specific frequency.

## 4.4 Voice Recorder

Select the "Recorder" icon from the main menu. Choose "Start Voice Recording" to begin. Press the appropriate button to stop and save the recording. Recordings can be played back from the "Recordings Library." The device also supports LINE-IN recording, allowing you to record audio directly from another device using a LINE-IN cable (not included).

# LINE-IN-Aufnahme

**Aufnahmefunktion:** Sie können Audio von einem MP3-Player direkt über das LINE-IN-Kabel (Audiokabel) auf den anderen MP3-Player oder auf andere Geräte aufnehmen.

**HINWEIS:** Muss eine Ausgabefunktion haben.

**Abspielfunktion:** Stecken das LINE-IN-Kabel (Audiokabel) beim Abspielen ein, die Musik im Gerät wird abgespielt.



Image: Diagram illustrating the LINE-IN recording function of the AGPTEK MP3 player, showing connection to various audio sources.

## 4.5 Pedometer Function

For tracking steps during exercise, select the "Pedometer" icon. Activate the function to monitor steps, distance, calories burned, and speed. This feature is useful for fitness enthusiasts.



Image: The MP3 player screen showing the pedometer function with a running shoe icon and text indicating its purpose.

#### 4.6 E-Book Reader

Access the "e-Books" icon to read text files. The player supports basic text file formats, allowing you to carry your reading material with your music.



Image: A woman exercising, demonstrating the MP3 player's clip feature for hands-free use.



Image: A man running with the AGPTEK MP3 player secured to an armband, emphasizing its suitability for active lifestyles and high-fidelity sound.

## 5. MAINTENANCE

---

- Keep the device dry. Moisture can damage internal circuits.
- Avoid extreme temperatures. High temperatures can shorten the life of electronic devices and deform plastic parts.
- Do not drop or strike the device. Rough handling can break internal circuit boards.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or detergents.
- Charge the battery regularly, even if not in use, to maintain battery health.

## 6. TROUBLESHOOTING

---

### Device not turning on:

- Ensure the battery is charged. Connect to a power source and allow it to charge for at least 10 minutes before attempting to power on.

- Check the power switch.

### Music files not appearing after transfer:

- Ensure you have updated the playlist on the device (Menu > Music > Update Playlist).
- Verify that the music files are in a supported format (e.g., MP3).
- Check if the files were successfully copied to the correct folder on the player.

### Bluetooth connection issues:

- Ensure your Bluetooth headphones/speaker are in pairing mode and within range.
- Try unpairing and re-pairing the device.
- Restart both the MP3 player and the Bluetooth audio device.

## 7. SPECIFICATIONS

Feature	Detail
Brand	AGPTEK
Model Number	32GB MP3 Player
Memory Storage Capacity	32 GB (expandable up to 128GB via TF card)
Connectivity Technology	Bluetooth 5.3
Special Features	Bluetooth, E-Book, FM Radio, Voice Recorder, Pedometer
Screen Size	1.5 Inches
Compatible Devices	Headphones, Personal Computer
Media Type	Micro SD
Supported Standards	MP3 and other common audio formats
Batteries	Lithium Polymer batteries (included)
Item Weight	5.3 ounces
Package Dimensions	7.52 x 5.12 x 0.87 inches

## 8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official AGPTEK website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

