

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Norwii](#) /
- › [Norwii S358 Bluetooth Voice Amplifier Instruction Manual](#)

Norwii S358

Norwii S358 Bluetooth Voice Amplifier Instruction Manual

Model: S358

Brand: Norwii

PRODUCT OVERVIEW

The Norwii S358 Bluetooth Voice Amplifier is a portable and versatile audio amplification device designed to make your voice louder and clearer in various settings. It is ideal for teachers, fitness instructors, tour guides, and anyone needing to project their voice effectively without strain. This device features a 10-watt output, a 3-inch boosted speaker for crystal clear sound, and advanced frequency shifting technology to minimize feedback.

It comes with a wired headset microphone and offers flexible wearing options. The long-lasting rechargeable battery ensures extended use, making it suitable for full-day events.



Image: Norwii S358 Voice Amplifier with its wired headset and various accessories.

WHAT'S IN THE BOX

- Wired Microphone Headset (1)
- Adjustable Waistband (1)
- 3.5 mm Audio Cable (1)
- USB-C Cable (1)
- User Manual (1)

PRODUCT COMPONENTS

Familiarize yourself with the main components of your Norwii S358 Voice Amplifier:

- **MIC-IN Port:** For connecting the wired headset microphone.
- **AUX-IN Port:** For connecting external audio sources like mobile phones, tablets, or MP3 players.
- **Dial Switch/Volume Control:** To turn the device ON/OFF and adjust the volume.
- **Indicator Light:** Shows power status and charging needs.
- **USB-C Charging Port:** For recharging the device.
- **Back Clip:** For attaching the amplifier to a belt or pocket.
- **Strap Buckles:** For attaching the adjustable waistband.



Image: Detailed view of the Norwii S358 amplifier's control panel, highlighting the MIC-IN, AUX-IN, and volume dial.

Your browser does not support the video tag.

Video: This video provides a detailed introduction to the functions and components of the Norwii S358 Voice Amplifier.

SETUP

1. Connecting the Microphone

1. Plug the wired headset microphone into the **MIC-IN** port of the voice amplifier.
2. Ensure the microphone plug is fully inserted.

2. Wearing the Microphone and Amplifier

- The headset microphone can be worn on your head or hung around your neck.
- Adjust the microphone pickup hole to face your mouth, keeping it 0.5-1 cm away for optimal sound capture.
- The amplifier can be worn on the shoulder using the adjustable waistband, hung on the waist, or clipped onto a pocket or belt using the back clip.

Teach Without Ear-Piercing Feedback with Norwii Smart Anti-Squeal Tech



Image: A person demonstrating how to wear the Norwii S358 Voice Amplifier on their waist with the headset microphone positioned correctly.

Your browser does not support the video tag.

Video: This video demonstrates the proper way to set up and wear the Norwii S358 Voice Amplifier and its wired headset microphone.

OPERATING INSTRUCTIONS

1. Power On/Off and Volume Adjustment

1. Rotate the dial switch/volume control to the 'ON' position. You will hear a 'click' sound, and the indicator light will turn on.

2. Continue rotating the dial to adjust the volume to your desired level.
3. To power off, rotate the dial switch to the 'OFF' position until you hear a 'click'.

2. External Audio Playback (AUX)

Connect the voice amplifier to computers, mobile phones, tablets, or MP3 players using the provided 3.5 mm AUX audio cable. The amplifier will function as an external speaker for your device.

3. Bluetooth Speaker Function

The Norwii S358 can also function as an external Bluetooth speaker. Pair it with your Bluetooth-enabled device to play music or other audio wirelessly.



Image: A person connecting the Norwii S358 Voice Amplifier to a laptop using the AUX cable for external audio playback.

CHARGING

The Norwii S358 Voice Amplifier is equipped with a USB-C charging port and comes with a USB-C cable. It is available in two battery capacities: 2000mAh and 4000mAh.

- **2000mAh Battery:** Provides 12-15 hours of continuous use on a full charge. Charging time is

approximately 2-3 hours.

- **4000mAh Battery:** Provides 25-30 hours of continuous use on a full charge. Charging time is approximately 4-6 hours.

Charging Process:

1. Connect the provided USB-C cable to the charging port on the amplifier.
2. Connect the other end of the USB-C cable to a standard 5V charger or a computer USB port.
3. The indicator light will flash (red quickly or orange/green slowly) when charging is needed. It will show a steady light when fully charged.

Important: Do not use quick charge adapters or chargers with voltages higher than 5V to avoid damaging the device.



Image: The Norwii S358 Voice Amplifier being charged via its USB-C port connected to a laptop.

MAINTENANCE

- **Microphone Care:** Do not remove the sponge cover from the microphone, as it helps reduce noise and ensures clear sound.

- **Feedback Prevention:** To effectively avoid howling, maintain a distance of at least 50 cm (20 inches) between the microphone and the amplifier. Also, keep the front of the amplifier at a distance of 50 cm or more from any walls or reflective surfaces.
- **Battery Lifespan:** To ensure the battery's longevity, fully charge the amplifier when it is not in use for a long period.
- **Interference:** Keep the amplifier away from charging devices or other electronic devices to avoid potential interference.



Image: A diagram illustrating the recommended distance of greater than 20cm/8 inches between the microphone and the amplifier to prevent feedback.

TROUBLESHOOTING

- **No Sound:** Ensure the amplifier is turned ON and the volume is adjusted. Check if the microphone is securely plugged into the MIC-IN port.
- **Howling/Feedback:** Increase the distance between the microphone and the amplifier (at least 50 cm). Ensure the microphone's sponge cover is in place. Keep the amplifier away from walls or reflective surfaces.
- **Distorted Sound:** Adjust the volume to a lower level. Ensure the microphone is positioned correctly (0.5-1 cm from mouth) and not too close to the amplifier.
- **Device Not Charging:** Verify that the USB-C cable is properly connected to both the amplifier and a standard 5V power source. Check the indicator light for charging status. Avoid using quick chargers.
- **Short Battery Life:** Ensure the device is fully charged before use. For prolonged storage, fully charge the battery to maintain its lifespan.

SPECIFICATIONS

Feature	Detail
---------	--------

Model Number	S358
Output Power	10 Watts
Speaker Size	3-inch
Battery Capacity	2000mAh or 4000mAh
Continuous Use (2000mAh)	12-15 hours
Continuous Use (4000mAh)	25-30 hours
Charging Time (2000mAh)	2-3 hours
Charging Time (4000mAh)	4-6 hours
Charging Port	USB-C (5V input)
Audio Input	AUX, MIC, Bluetooth
Mounting Type	Portable (with back clip and waistband)
Material	Acrylonitrile Butadiene Styrene (ABS), PC
Dimensions	4 x 3.59 x 1.49 inches
Item Weight	10.6 ounces (0.3 Kilograms)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Norwii website. Keep your purchase receipt as proof of purchase for any warranty claims.