

[Manuals.plus](#) /

› [Vasco Electronics](#) /

› Vasco V4 Language Translator Device User Manual

Vasco Electronics Vasco Translator V4

Vasco V4 Language Translator Device User Manual

Model: Vasco Translator V4

Brand: Vasco Electronics

1. INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your Vasco V4 Language Translator Device. Designed for seamless communication across language barriers, the Vasco V4 offers instant voice and photo translation in 112 languages with free lifetime internet connectivity.



Image: Front and back views of the Vasco V4 Language Translator Device in Ruby Red. The front features a large display, while the back shows the camera and Vasco logo.

2. SETUP

2.1 Unboxing and Initial Inspection

Upon receiving your Vasco V4, carefully unbox all components and inspect for any damage. The package should contain the Vasco V4 device, a clear protective case, a lanyard, a USB-C charging cable, and a wall adapter.



Image: The Vasco V4 Language Translator Device displayed alongside its retail packaging and included accessories: a clear protective case, a black lanyard, a white USB-C charging cable, and a white wall power adapter.

2.2 Charging the Device

Before first use, fully charge your Vasco V4. Connect the provided USB-C cable to the device's USB-C port and the other end to the wall adapter. Plug the adapter into a power outlet. The device's screen will indicate charging status.

2.3 Powering On/Off

To power on the device, press and hold the power button located on the side until the screen illuminates. To power off, press and hold the power button, then select 'Power Off' from the on-screen options.

2.4 Initial Setup and Connectivity

The Vasco V4 is designed for immediate use without complex setup or app downloads. Simply turn it on, and it will automatically connect to the internet via its built-in SIM card, providing free lifetime connectivity for translations in almost 200 countries. No Wi-Fi is required for basic translation functions.



Image: A person is shown easily sliding a blue Vasco V4 translator device into a pants pocket, highlighting its compact size and portability for travel.

3. OPERATING THE DEVICE

3.1 Voice Translation

The primary function of the Vasco V4 is instant voice translation. It supports 112 languages for voice input and output.

1. **Select Languages:** On the main screen, tap the language icons to select your source and target languages.
2. **Speak:** Press and hold the microphone button corresponding to your language. Speak clearly into the device.
3. **Listen:** Release the button. The device will process your speech and play the translation aloud in the target language. The translated text will also appear on the screen.



Image: A close-up of hands holding the Vasco V4 device, displaying its voice translation interface with prominent microphone buttons for selecting and speaking in different languages.

3.2 Photo Translation

The Vasco V4 features a high-quality Sony camera for translating text from images, such as signs, menus, or documents.

1. **Access Photo Translator:** From the main menu, select the 'Photo Translator' option.

2. **Capture Image:** Point the device's camera at the text you wish to translate. Ensure good lighting and focus. Tap the capture button.
3. **View Translation:** The device will process the image and display the translated text on the screen.



■ Coverage map for free, lifetime connectivity with the Vasco Translator V4.

Image: A user holds the Vasco V4 device horizontally, utilizing its camera to capture and translate text from a printed document, demonstrating the photo translation feature.

3.3 Text Translation

For direct text input, the device also supports manual text translation. This is useful for translating short phrases or words by typing them directly into the device.

3.4 Conversation Mode

The Vasco V4 includes a conversation mode designed for natural, back-and-forth dialogue. This mode streamlines the translation process for interactive communication.

3.5 Supported Languages and Coverage

The device supports 112 languages for translation. Its free lifetime internet connectivity ensures global coverage in nearly 200 countries, allowing you to translate without relying on Wi-Fi or a smartphone connection.



Coverage map for free, lifetime connectivity with the Vasco Translator V4.

Image: A world map illustrating the extensive global coverage for free lifetime internet connectivity provided with the Vasco V4 translator, showing most countries highlighted.



Image: A detailed list of numerous languages, with indicators for whether each language supports voice input, voice output, and photo translation on the Vasco V4 device.

4. MAINTENANCE

4.1 Cleaning the Device

To clean your Vasco V4, use a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or aerosol sprays directly on the device. For stubborn smudges, slightly dampen the cloth with water.

4.2 Battery Care

The Vasco V4 is equipped with a 2400 mAh Lithium Ion battery. For optimal battery life:

- Avoid extreme temperatures.
- Charge the device regularly, but avoid leaving it fully discharged for extended periods.
- The device can last up to 5 days with regular use and up to 180 hours in standby mode.

4.3 Durability Features

The Vasco V4 is designed to be dust-proof, water-resistant, and shock-proof, making it suitable for various environments. While durable, avoid intentional exposure to harsh conditions or submersion in water.



Image: An infographic detailing the robust features of the Vasco V4, including its dust-proof, water-resistant, and shock-proof design, high-quality Sony camera, built-in SIM for lifetime connectivity, ergonomic 5-inch screen, loud speakers, and powerful battery.

5. TROUBLESHOOTING


If you encounter issues with your Vasco V4, try the following steps:

- **Device Not Responding:** Press and hold the power button for 10-15 seconds to force a restart.
- **Translation Inaccuracy:** Ensure you are speaking clearly and directly into the microphone. Verify that the correct source and target languages are selected.
- **Connectivity Issues:** Although the device has free lifetime internet, ensure you are in an area with cellular network coverage. If issues persist, try restarting the device.
- **Battery Draining Quickly:** Reduce screen brightness or close unused applications if available. Ensure the device is not left in extreme temperatures.

For persistent problems, refer to the support section for contact information.

6. SPECIFICATIONS

Detailed technical specifications for the Vasco V4 Language Translator Device:



DISPLAY	5" 576x1440
PROCESSOR	Quad-core Mediatek Helio A22 (MT6761) 64 bit
RAM	2 GB
ROM	32 GB
MODEM	4G
WIFI	2.4 GHz
BATTERY	B2400 mAh
SIZE	149 x 55 x 10 mm
WEIGHT	0,3 lb (134 g)
EARPHONE INPUT	USB Type-C
USB INPUT	Type-C
USER MANUAL	Download the manual from the "Product Guides and Documents" section

Image: A technical diagram illustrating the physical dimensions (149mm height, 55mm width, 10mm thickness) and a list of specifications for the Vasco V4 device.

Feature	Specification
Display	5" 576x1440
Processor	Quad-core Mediatek Helio A22 (MT6761) 64 bit
RAM	2 GB
ROM	32 GB

Modem	4G
WiFi	2.4 GHz
Battery	2400 mAh Lithium Ion (included)
Size	149 x 55 x 10 mm (5.87 x 2.17 x 0.39 inches)
Weight	0.3 lb (134 g / 4.7 ounces)
Earphone Input	USB Type-C
USB Input	USB Type-C

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The Vasco V4 Language Translator Device comes with a 24-month protection period from the date of purchase. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For further assistance, technical support, or warranty inquiries, please contact Vasco Electronics customer service. Refer to the official Vasco Electronics website for the most up-to-date contact information.

© 2025 Vasco Electronics. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question