ZdalaMit AH81-13358A

ZdalaMit AH81-13358A Replacement Remote Control User Manual

For Samsung Soundbar Models

Introduction

This manual provides essential instructions for the ZdalaMit AH81-13358A replacement remote control. This remote is designed to operate various Samsung Soundbar models without requiring any programming. Simply install batteries, and it is ready for use.

Package Contents

- 1x ZdalaMit AH81-13358A Replacement Remote Control

Note: Batteries and additional manuals are not included.

Compatible Samsung Soundbar Models

This remote control is compatible with the following Samsung Soundbar models:

- HW-N450, HW-N450/ZA
- HW-N550, HW-N550/ZA
- HW-N650, HW-N650/ZA
- HW-A430, HW-A470
- HW-N430/ZA, HW-N470/ZA
- HW-T420, HW-T450, HW-T450/ZA
- HW-Q900T, HW-Q900T/ZA
- HW-Q950T
- HW-R50C, HW-R550, HW-R550/ZA

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.

3. Insert two (2) 1.5V AA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

The remote control does not require any programming and is ready for use immediately after battery installation.





Image: Back view of the ZdalaMit AH81-13358A remote control, highlighting the battery compartment. This is where two AA batteries are inserted.

Operating Instructions

The ZdalaMit AH81-13358A remote control features standard buttons for controlling your Samsung Soundbar. Below is a general overview of common button functions.






Image: Front view of the ZdalaMit AH81-13358A remote control, displaying all buttons including Power, Play/Pause, Volume, Sound Mode, and Woofer controls.

- **Power Button ( )**: Turns the soundbar on or off.
- **Play/Pause Button ( )**: Controls media playback (play, pause).
- **Volume Up/Down (VOL)**: Adjusts the main volume level of the soundbar.
- **Mute Button ( )**: Mutes or unmutes the sound.
- **Sound Mode**: Cycles through available sound modes (e.g., Standard, Surround, Game).
- **Woofer Up/Down (WOOFER)**: Adjusts the bass level of the connected subwoofer.
- **Settings Button (⚙)**: Accesses soundbar settings or menu options.
- **Source/Input Button (⏏)**: Changes the input source (e.g., HDMI, Optical, Bluetooth).
- **Pair Button (PAIR)**: Initiates Bluetooth pairing mode for compatible soundbars.

For detailed functionality of specific buttons, refer to your Samsung Soundbar's original user manual.

Maintenance

- **Cleaning**: Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Avoid Exposure**: Keep the remote control away from direct sunlight, heat sources, moisture, and extreme temperatures.

Troubleshooting

Remote is not responding:

- Ensure batteries are inserted correctly with the correct polarity.
- Replace old batteries with new 1.5V AA alkaline batteries.
- Check for any obstructions between the remote control and the soundbar's infrared receiver.
- Ensure you are within the effective operating range (up to 33 feet) and pointing the remote directly at the soundbar.

Specific buttons are not working:

- Verify that your soundbar model is listed in the compatible models section.
- Some advanced functions may require specific soundbar firmware or settings. Refer to your soundbar's original manual.

Specifications

Brand	ZdalaMit
Model Name	AH81-13358A
Connectivity Technology	Infrared (IR)
Power Supply	2 x 1.5V AA Alkaline Batteries
Maximum Range	33 Feet (approx. 10 meters)
Special Feature	Pre-programmed, no setup required
Color	Black
Item Weight	40 Grams
Dimensions (L x W x H)	6.55" x 1.39" x 0.55"

Warranty and Support

Warranty Information

This product comes with a **1-year warranty** from the manufacturer, ZdalaMit factory. Please retain your proof of purchase for warranty claims.

Customer Support

If you have any questions, concerns, or require assistance with your ZdalaMit AH81-13358A remote control, please contact the seller or manufacturer's customer support. Contact information is typically available on the product packaging or the point of purchase.

© 2026 ZdalaMit. All rights reserved. Samsung is a registered trademark.