

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Ajazz](#) /

› [Ajazz AK40 Wired Mechanical Keyboard User Manual](#)

Ajazz AK40

Ajazz AK40 Wired Mechanical Keyboard User Manual

Model: AK40

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Ajazz AK40 Wired Mechanical Keyboard. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

PACKAGE CONTENTS

- 1 x Ajazz AK40 Mechanical Keyboard
- 1 x USB Cable (1.6m)
- 1 x Keycap Puller

SETUP

Follow these steps to set up your Ajazz AK40 Mechanical Keyboard:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all listed package contents are present.
2. **Connecting the Keyboard:**
Locate the USB cable provided. Connect one end of the USB cable to the keyboard's USB port and the other end to an available USB 1.1, 2.0, or 3.0 port on your computer. The keyboard is designed for plug-and-play operation.



Image: The Ajazz AK40 Mechanical Keyboard, showcasing its compact design and the USB cable connection point.

3. System Compatibility:

The keyboard is compatible with Windows 98SE/ME/2000/XP/Vista/Win7/Win8/Win10 and MAC OS. No additional drivers are typically required for basic functionality. Note that specific software or advanced programming features may not be available for Mac OS.

OPERATING INSTRUCTIONS

The Ajazz AK40 keyboard features an 87-key layout with full N-key rollover for precise input during gaming and typing.

Key Features:

- **Mechanical Switches:** Equipped with mechanical switches (e.g., Black Switch: 60g actuation force, 2mm actuation distance) for responsive and tactile feedback.
- **Anti-Ghosting:** Ensures all key presses are registered accurately, even during rapid, simultaneous inputs.
- **Durable Construction:** Made from top-grade ABS and aluminum panels, providing a durable, dustproof, and water-resistant design.

Backlight Control:

The keyboard features a full-key backlight with 9 different modes. To cycle through or adjust backlight modes, use the following key combination:

- **FN + F8:** Cycles through the 9 available backlight modes.
- **FN + Down Arrow:** Decreases backlight brightness or turns off the backlight.
- **FN + Up Arrow:** Increases backlight brightness.



Image: The Ajazz AK40 Mechanical Keyboard displaying its vibrant RGB backlighting, enhancing visibility and aesthetics.

Media Keys and Function Shortcuts:

Access various functions quickly using the FN key in combination with the F1-F12 keys:

Key Combination	Function
FN + F1	Media Player
FN + F2	Volume Down
FN + F3	Volume Up
FN + F4	Mute
FN + F5	Stop
FN + F6	Previous Track
FN + F7	Play/Pause
FN + F8	Next Track / Backlight Mode Cycle

Key Combination	Function
FN + F9	Email
FN + F10	Web Browser
FN + F11	My Computer
FN + F12	Calculator

MAINTENANCE

Proper maintenance will extend the lifespan of your keyboard:

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For deeper cleaning, you can use the included keycap puller to remove keycaps and clean underneath. Keycaps are designed to be easily cleaned and replaced.
- **Spills:** While the keyboard is designed to be water-resistant, avoid direct exposure to liquids. In case of a spill, immediately disconnect the keyboard from your computer and allow it to dry completely before reconnecting.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.



Image: The Ajazz AK40 Mechanical Keyboard positioned on a desk, illustrating its compact and ergonomic design suitable for daily use.

TROUBLESHOOTING

If you encounter issues with your Ajazz AK40 keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely connected to both the keyboard and the computer.
 - Try connecting the keyboard to a different USB port on your computer.
 - Restart your computer.
 - If using a USB hub, try connecting directly to the computer.
- **Backlight Not Working or Dim:**
 - Press **FN + Up Arrow** to increase brightness.
 - Press **FN + F8** to cycle through backlight modes.
 - Ensure the keyboard is properly powered via the USB connection.
- **Keys Not Registering or Ghosting:**
 - The keyboard features anti-ghosting. If issues persist, ensure no debris is lodged under the

keycaps. Use the keycap puller to inspect and clean.

- Ensure only one keyboard is connected if experiencing random disconnections (as per user review).

- **Software/Driver Issues (Windows):**

- While the keyboard is plug-and-play, if you are attempting to use specific software from Ajazz and it's not detecting the keyboard, verify the software version and compatibility with your operating system.

SPECIFICATIONS

Feature	Detail
Keyboard Type	87-key Mechanical Keyboard
Switch Type	Black Switch (60g actuation force, 2mm actuation distance)
Keystroke Life	50 million times
Connectivity	Wired USB (USB 1.1/2.0/3.0)
Cable Length	1.6 meters
Material	ABS, Metal
Dimensions (L x W x H)	356 mm x 130 mm x 35 mm (approx. 14.02" x 5.12" x 1.38")
Weight	870g (approx. 2.2 pounds)
System Requirements	Windows 98SE/ME/2000/XP/Vista/Win7/Win8/Win10, MAC OS
Color	Blue & White

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not provided in the available product data. Please refer to the product packaging or the official Ajazz website for the most current warranty terms and support contact details.

For general inquiries or further assistance, you may visit the [Ajazz Store on Amazon](#).