Tribesigns Desk0133

Tribesigns 70.8" Executive Desk User Manual

Model: Desk0133 | Brand: Tribesigns

Introduction Safety Information Parts List Assembly Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Tribesigns 70.8" Executive Desk. Designed for home office and business environments, this large computer desk offers a spacious work surface and a modern aesthetic. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1.1: The Tribesigns 70.8" Executive Desk, showcasing its spacious white desktop and sturdy frame, suitable for various office setups.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten fasteners.
- Do not overload the desk. Refer to the specifications section for weight limits.
- Keep small parts and packaging materials away from children and pets.
- Use only the provided hardware or specified replacements.
- Assembly requires two people for optimal safety and ease.
- The desktop is composed of multiple spliced boards. Handle with care to avoid damage during assembly.

3. Parts List

Before assembly, verify that all components and hardware listed below are present. If any parts are missing or damaged, please contact customer support.

3.1 Components

1: Left Leg Frame (x1)

2: Right Leg Frame (x1)

3: Crossbar (x1)

4: Desktop Panel (Left) (x1)

5: Desktop Panel (Center) (x2)

6: Desktop Panel (Right) (x1)

7: Desktop Support Bar (x2)

8: Desktop Connector Plate (x1)

9: Leg Base (x4)

3.2 Hardware

A: 8x70mm Screws (x4)

B: 8x40mm Screws (x12)

C: 8x20mm Screws (x28)

D: 6x35mm Screws (x6)

E: 6x60mm Screws (x8)

F: Washers (x20)

G: Allen Wrench (x1)




Figure 3.1: All components and hardware included in the package. Please verify all parts are present before starting assembly.

4. Assembly Instructions (Setup)

Follow these steps carefully to assemble your Tribesigns Executive Desk. It is recommended to have two people for assembly.

4.1 Assembly Video Guide

[redacted]

Video 4.1: Official Tribesigns Computer Desk Assembly Guide. This video provides a visual walkthrough of the entire assembly process.

4.2 Step-by-Step Assembly

1. **Unbox and Organize Components:**
   Carefully unpack all components and hardware. Lay them out on a clean, soft surface, such as a carpet or blanket, to prevent scratches. Identify each part using the provided parts list.
2. **Attach Desktop Support:**
   Connect the desktop support bars (Part 7 and 8) using the desktop connector plate (Part 11) and 8x20mm screws (Part C) with washers (Part F). Ensure a secure fit but do not fully tighten screws until instructed.



Figure 4.1: Detail of the sturdy frame construction and adjustable leg pads, ensuring stability on uneven floors.

3. **Assemble the Legs:**
   Attach the leg frames (Part 1 and 2) to the main frame using 8x40mm screws (Part B) and 8x20mm screws (Part C). Insert the leg bases (Part 9) into the bottom of each leg. Ensure all connections are aligned before tightening.
4. **Connect Additional Support:**
   Secure the crossbar (Part 3) to the assembled leg structure using 8x70mm screws (Part A) and 8x40mm screws (Part B). This provides additional stability to the desk frame.
5. **Assemble the Desktop:**
   Carefully place the desktop panels (Parts 4, 5, 6) onto the assembled frame. Ensure the orientation of the boards is correct, with the larger spacing facing outward for proper alignment. Secure the desktop panels to the frame using 6x35mm screws (Part D) and 6x60mm screws (Part E). **Note:** The desktop is composed of 4 spliced boards. Ensure they are properly aligned and flush. Once all parts are in place, fully tighten all screws.



Figure 4.2: The desktop is constructed from multiple panels, designed for a large, continuous work surface.

5. Operating Instructions

Your Tribesigns 70.8" Executive Desk is designed for versatile use in various settings.

5.1 Intended Use

- **Workstation:** Provides ample space for laptops, multiple monitors, keyboards, and office supplies, making it ideal for productive work.
- **Gaming Desk:** The large surface accommodates gaming setups, including large monitors and accessories, offering a comfortable gaming experience.
- **Conference Table:** Its generous dimensions allow it to function as a small conference table for meetings or collaborative work.
- **Study Table:** Suitable for studying, writing, and other academic activities.



Figure 5.1: The desk configured as a home office workstation, demonstrating its spaciousness for a laptop, books, and other essentials.

6. Maintenance

Proper care will extend the life and maintain the appearance of your Tribesigns Executive Desk.

- **Cleaning:** Wipe the desk surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the laminated finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage to the engineered wood.
- **Stability Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as necessary to maintain desk stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration of the desktop finish.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat damage to the surface.

7. Troubleshooting

This section addresses common issues you might encounter with your desk.

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Screws are not fully tightened; uneven floor; incorrect assembly.	Ensure all screws are fully tightened. Adjust the adjustable leg pads to level the desk on uneven surfaces. Review assembly steps to confirm correct installation.
Desktop panels do not align flush.	Panels are incorrectly oriented; screws tightened prematurely.	Ensure the desktop panels are oriented correctly (larger spacing facing outward). Loosen screws, adjust alignment, then re-tighten all screws evenly.
Difficulty inserting screws.	Misaligned holes; incorrect screw size.	Verify that the parts are correctly aligned. Do not force screws. Ensure you are using the correct screw size for each step as indicated in the parts list.

8. Specifications

Feature	Detail
Brand	Tribesigns
Model Number	Desk0133
Product Dimensions	31.5"D x 70.8"W x 29.5"H
Item Weight	25 Kilograms
Color	White
Style	Modern
Top Material Type	Engineered Wood (E1 particleboard)
Base Material	Metal
Finish Type	Laminated
Room Type	Office, Study Room
Recommended Uses	Gaming, Working, Writing
Product Care Instructions	Wipe with Damp Cloth
Required Assembly	Yes
Recommended People for Assembly	2




Figure 8.1: Detailed dimensions of the Tribesigns Executive Desk.

9. Warranty and Support

9.1 Warranty Information

This Tribesigns product comes with a limited warranty. For specific details regarding the warranty period and coverage, please refer to the warranty card included in your product packaging or contact Tribesigns customer service directly.

9.2 Customer Support

For any questions, missing parts, or assistance with assembly or product use, please contact Tribesigns customer support. You can typically find contact information on the product packaging or on the official Tribesigns website.
Return Policy: This product is eligible for 30-day easy returns. Please refer to your purchase platform's return policy for detailed instructions.
Seller: Tribesigns-Way to Origin
For additional support and product information, visit the official Tribesigns Store:Tribesigns Store on Amazon

© 2024 Tribesigns. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question