

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Insta360](#) /

› [Insta360 Mini 2-in-1 Tripod Instruction Manual \(Model CINSAAVB\)](#)

Insta360 CINSAAVB

Insta360 Mini 2-in-1 Tripod Instruction Manual

Model: CINSAAVB | Brand: Insta360

INTRODUCTION

The Insta360 Mini 2-in-1 Tripod is a versatile accessory designed for Insta360 cameras and webcams. This lightweight and compact device functions as both a selfie stick and a stable tripod, offering flexibility for various shooting scenarios. Its sturdy construction ensures reliability for on-the-go content creation and stationary use.

WHAT'S IN THE BOX

Upon unboxing your Insta360 Mini 2-in-1 Tripod, you should find the following items:

- 1x Mini 2-in-1 Tripod
- 2x Locking Lever
- 1x 1/4" Mount Adapter
- 1x Manual

In the Box

1x Mini 2-in-1 Tripod

1x 1/4" Mount Adapter

2x Locking Lever

1x 1/4" Mount Adapter

Specs

Materials

Polycarbonate (PC), Acrylonitrile butadiene styrene (ABS), Thermoplastic polyurethane (TPU), Aluminum

Weight

110g (3.88oz)

Dimensions

162x29x29mm
(6.38x1.14x1.14in)

Image: The contents of the Insta360 Mini 2-in-1 Tripod packaging, including the tripod, locking levers, 1/4" mount adapter, and manual.

PRODUCT OVERVIEW

The Insta360 Mini 2-in-1 Tripod is designed for portability and ease of use. It features a compact form factor that easily transforms to meet your needs.



Image: The Insta360 Mini 2-in-1 Tripod in its compact, folded state, ready for portability.

Insta360

Mini 2-in-1 Tripod

Small tripod, big potential.



Image: The Insta360 Mini 2-in-1 Tripod showcasing its versatility with two different Insta360 cameras mounted in tripod mode.

SETUP

Setting up your Insta360 Mini 2-in-1 Tripod is straightforward, allowing for quick transitions between modes.

Attaching Your Camera

The tripod features a standard 1/4" thread, ensuring universal compatibility with various cameras and webcams. Use the provided 1/4" mount adapter and locking levers to securely attach your device.

Cross-compatible.

Universal interface and a 1/4" mount for all your action cameras and webcams.



Image: A diagram illustrating the cross-compatible 1/4" mount and locking lever for attaching cameras or webcams.

Converting to Tripod Mode

1. Locate the base of the handle.
2. Gently pull the three rubber pads outwards to release the legs.
3. Spread the legs evenly to form a stable tripod base.



Image: The Insta360 Mini 2-in-1 Tripod deployed as a stable tripod with an Insta360 GO 3 camera mounted.

Converting to Selfie Stick Mode

1. Ensure the tripod legs are folded back into the handle.
2. Extend the telescopic pole upwards to your desired length.





Image: The Insta360 Mini 2-in-1 Tripod extended as a selfie stick with an Insta360 GO 3 camera mounted.

OPERATING INSTRUCTIONS

The Insta360 Mini 2-in-1 Tripod offers versatile usage for various content creation needs.

Using as a Selfie Stick

Extend the pole to capture wider angles or include more of your surroundings in your shots. The compact design makes it easy to hold and maneuver.

From tripod to selfie stick.

Shoot with more variety without any hassle.



Image: A user holding the Insta360 Mini 2-in-1 Tripod extended as a selfie stick, capturing a wide shot.

Using as a Tripod

Deploy the legs for stable, hands-free recording. This is ideal for time-lapses, group photos, or when using your camera as a webcam.





Image: The Insta360 Mini 2-in-1 Tripod fully extended in tripod mode, providing a stable base for recording.

Desk Mount Capability

The tripod can act as a stable desk mount, perfect for webcam setups and stationary camera use during video calls or streaming.

Your browser does not support the video tag.

Video: A short demonstration by the seller showing the Insta360 Mini 2-in-1 Tripod being used as a desk mount for an Insta360 GO3 camera, highlighting its stability and utility for webcam setups.

Your browser does not support the video tag.

Video: A brief overview by the seller of the Insta360 2-in-1 Mini Tripod, demonstrating its compact size and quick

deployment as a tripod.

MAINTENANCE

To ensure the longevity and optimal performance of your Insta360 Mini 2-in-1 Tripod, follow these maintenance guidelines:

- **Cleaning:** Wipe the tripod with a soft, dry cloth after each use to remove dust, dirt, or moisture. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully collapsed and clean before storage.
- **Inspection:** Periodically check all moving parts, screws, and joints for any signs of wear or damage. Tighten any loose screws if necessary.

TROUBLESHOOTING

If you encounter any issues with your Insta360 Mini 2-in-1 Tripod, consider the following:

- **Unstable Tripod:** Ensure the legs are fully extended and spread evenly on a flat, stable surface. Avoid using on uneven ground.
- **Camera Wobbling:** Verify that your camera is securely attached to the 1/4" mount using the locking levers. Ensure the camera's weight does not exceed the maximum recommended load.
- **Difficulty Extending/Retracting Pole:** Check for any debris or obstructions in the telescopic sections. Clean the pole if necessary.

SPECIFICATIONS

Feature	Detail
Product Dimensions	8.75 x 2.5 x 2.25 inches
Item Weight	5.6 ounces (0.16 Kilograms)
Folded Size	15.7 inches (162x29x29mm / 6.38x1.14x1.14in)
Materials	Polycarbonate (PC), Acrylonitrile butadiene styrene (ABS), Thermoplastic polyurethane (TPU), Aluminum
Compatibility	Insta360 Ace, Ace Pro, Ace Pro 2, GO 2, GO 3, GO 3S, GO Ultra, Link, Link 2, Link 2C, ONE R, ONE RS (Twin/4K), ONE RS 1-Inch 360 Edition, ONE X, ONE X2, X3, X4, X5 Series cameras and Insta360 Link Series webcams.
Mounting Thread	Standard 1/4" thread

IMPORTANT NOTES

- Make sure the tripod is securely placed; do not use it on potholes or uneven ground. When using the tripod outdoors, please do not extend it too high to avoid the tripod falling. During windy weather (especially wind strength 4 and above), please use it carefully.

- If the camera is too heavy, the tripod may tip over and damage the camera. The maximum weight of the camera should not exceed 250g.
- If you need to move the mounted tripod, please remove the camera from the tripod first. Do not move the tripod while the camera is attached. Vigorous shaking (especially when extended to its maximum length) may break the adapter screw and damage the camera.

WARRANTY & SUPPORT

Insta360 products are designed for durability and performance. For any warranty claims or technical support, please refer to the official Insta360 website or contact their customer service directly. Keep your purchase receipt as proof of purchase.