

[Manuals.plus](#) /

› [Moose](#) /

› Moose Magic Mixies Potion Game Instruction Manual

Moose 91037

Moose Magic Mixies Potion Game Instruction Manual

Model: 91037

INTRODUCTION

Welcome to the magical world of the Moose Magic Mixies Potion Game. This exciting game challenges players to collect magical ingredients and create a potion that reveals a Magic Mixie. Designed for 2-4 players aged 4 and up, it offers an engaging experience of anticipation and fun.

Please read this manual carefully to ensure proper setup and enjoyment of your game.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

WHAT'S INCLUDED

The Magic Mixies Potion Game includes the following components:

- 1 Magic Mixie
- 1 Mixies Cauldron
- 1 Game Mat
- 1 Spinner Board
- 1 Mixling Movers (player tokens)
- Ingredient Pieces (various shapes and colors)
- 1 Instruction Sheet (this manual)



Image: All game components including the cauldron, game mat, spinner, Mixie, and ingredient pieces.

SETUP

1. **Prepare the Cauldron:** Ensure the Magic Mixie is securely placed inside the cauldron and the top is closed. The Mixie should be hidden from view.
2. **Place the Game Mat:** Unfold the game mat and place it on a flat playing surface.
3. **Position the Cauldron:** Place the Mixies Cauldron in the center of the game mat.
4. **Arrange Ingredient Pieces:** Distribute the Ingredient Pieces around the game mat, near the corresponding spaces.
5. **Set up the Spinner:** Place the Spinner Board within easy reach of all players.
6. **Choose Mixling Movers:** Each player selects a Mixling Mover (player token) and places it on the "Start" space of the game mat.



Image: The game fully set up on a table, showing the cauldron, game board, spinner, and various ingredient pieces.

OPERATING INSTRUCTIONS

Objective

The goal of the Magic Mixies Potion Game is to be the player who successfully places the correct ingredient piece into the cauldron, causing the Magic Mixie to magically pop up.

Gameplay

1. **Player Turn:** On your turn, spin the spinner.
2. **Move Your Mixling:** Move your Mixling Mover clockwise around the game mat the number of spaces indicated on the spinner.
3. **Collect Ingredients:**
 - If you land on a space with an ingredient icon, collect one matching ingredient piece.
 - If you land on a space with a "plus" symbol, you may add any ingredient piece you possess to the cauldron.

- If you land on a space with a "minus" symbol, you must remove one ingredient piece from the cauldron (if any).
4. **Add to Cauldron:** Once you have collected a set of three matching ingredient pieces (e.g., three stars, three feathers), you may choose to place one of these pieces into one of the holes on the cauldron.
 5. **The Magic Moment:** Carefully insert the ingredient piece into a hole in the cauldron. If it's the correct hole, the Magic Mixie will pop up, and you win the game! If not, the Mixie remains hidden, and play continues to the next player.



Image: A child carefully inserting a star-shaped ingredient piece into the cauldron.



Image: Two children showing excitement and surprise as the Magic Mixie appears from the cauldron.

Resetting the Cauldron

After a Magic Mixie pops up, gently push it back down into the cauldron until it locks into place. The winning ingredient piece can be removed, and the game can be reset for another round.

Your browser does not support the video tag.

Video: Official demonstration of the Magic Mixies Potion Game gameplay, showing ingredient collection and the Mixie reveal.

MAINTENANCE

To ensure the longevity of your Magic Mixies Potion Game, follow these simple maintenance tips:

- **Cleaning:** Wipe all game components with a soft, dry cloth after each use. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store all game pieces and the cauldron in their original box or a designated storage container to prevent loss or damage. Keep away from direct sunlight and extreme temperatures.

- **Handling:** Handle the Magic Mixie and cauldron mechanism gently to avoid damage.

TROUBLESHOOTING

Problem	Solution
Magic Mixie does not pop up.	Ensure the Mixie is fully pushed down and locked into place before starting the game. Verify that the ingredient piece is inserted correctly into one of the holes. The mechanism is designed to be random, so it may take several attempts to find the correct hole.
Spinner does not move freely.	Check for any obstructions under the spinner. Ensure the spinner is placed on a flat surface.
Missing game pieces.	Carefully check the game box and surrounding play area. Contact Moose Toys customer support for replacement parts if necessary.

SPECIFICATIONS

- **Model Number:** 91037
- **Product Dimensions:** 5.25 x 7.75 x 10.5 inches
- **Item Weight:** 6.7 ounces
- **Manufacturer Recommended Age:** 4 - 15 years
- **Number of Players:** 2-4
- **Manufacturer:** MOOSE TOYS LLC

WARRANTY AND SUPPORT

For warranty information, replacement parts, or any other support inquiries, please visit the official Moose Toys website or contact their customer service department. Keep your proof of purchase for warranty claims.

Official Moose Toys Website: www.moosetoys.com

© 2023 Moose Toys LLC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question