ChooChoo ET2110

ChooChoo Farmhouse End Tables (Set of 2), Model ET2110 - Instruction Manual

Brand: ChooChoo

1. Assembly Instructions

1.1 Before You Begin

Please read all instructions carefully before beginning assembly. Ensure all parts are present and undamaged. Assembly is designed to be straightforward with numbered parts and clear instructions.

Safety Information:

- Always follow the assembly instructions carefully.
- Use the provided assembly tool and ensure all parts are securely fastened.
- This table is designed for small spaces, so ensure it is properly anchored to prevent tipping, especially in homes with pets or children.

Tools Required:

- Screw Driver (recommended)
- Included Assembly Tool

Parts List:

Refer to the included assembly guide for a detailed list of all numbered parts and hardware. Each piece is clearly labeled for easy identification.

1.2 Step-by-Step Assembly

Follow the step-by-step instructions provided in your package. Assembly typically takes less than 20 minutes per table.



Figure 1.1: Assembled ChooChoo Farmhouse End Table (White)



Figure 1.2: Product Dimensions for Assembly Reference

2. Operating Instructions

2.1 Placement and Versatility

These end tables are designed for versatile use in various indoor settings. They are ideal for:

- **Living Room:** As a side table next to a sofa or armchair.
- **Bedroom:** Functioning as a nightstand.
- **Home Office:** Providing a convenient surface for small items.

- **Small Spaces:** Their compact design makes them suitable for areas with limited room.



Figure 2.1: End Tables used as Nightstands

2.2 Storage Shelf Functionality

Each end table features a decorative slatted bottom shelf. This shelf provides additional storage space, helping to keep your belongings organized and within reach. It is suitable for books, magazines, small baskets, or decorative items.



Figure 2.2: Detail of the Slatted Storage Shelf

2.3 Design Elements

The tables feature a two-tone design with a soft brown top and crisp white frame, contributing to a farmhouse aesthetic. The classic A-frame structure ensures stability and durability.



Figure 2.3: Two-Tone Top Surface



Figure 2.4: Classic A-Frame Structure

3. Care and Maintenance

To ensure the longevity and appearance of your ChooChoo Farmhouse End Tables, follow these care instructions:

- **Cleaning:** Clean with a dry cloth or a cloth dampened with mild detergent. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Wipe up spills immediately to prevent staining or damage to the finish.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters under beverages to protect against moisture rings.
- **Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration.
- **Weight Capacity:** Do not exceed the maximum weight recommendation of 15 pounds for the tabletop.

4. Troubleshooting

If you encounter any issues during assembly or use, please refer to the following common solutions:

- **Wobbly Table:** Ensure all screws and fasteners are tightened securely. Uneven flooring can also cause wobbling; try adjusting the table's position or using furniture pads.
- **Missing Parts:** Double-check the packaging and compare with the parts list in the assembly guide. If parts are genuinely missing, contact customer support.
- **Difficulty Assembling:** Re-read the step-by-step instructions carefully. Ensure you are using the correct hardware for each step. Do not force parts together.
- **Surface Damage:** For minor scratches, furniture repair kits or markers can be used. For significant damage, contact customer support for advice.

5. Product Specifications

Feature	Specification
Brand	ChooChoo
Model Name	End Table
Model Number	ET2110
Product Dimensions (D x W x H)	15.7"D x 11.8"W x 23.6"H (Note: JSON has conflicting width values, using 11.8" from 'Item Width')
Item Weight	14.3 pounds
Maximum Weight Recommendation	15 pounds
Frame Material	Wood
Top Material Type	Engineered Wood
Color	White (with brown top)
Shape	Rectangular
Style Name	Vintage
Number of Shelves	1
Indoor Outdoor Usage	Indoor
Recommended Number of People for Assembly	1
Number of Items	2
UPC	759382137612

6. Warranty and Support

6.1 Warranty Information

Specific warranty details are not provided in the product information. Please retain your proof of purchase for any potential

warranty claims. For information regarding product defects or issues, refer to the support section below.

6.2 Customer Support

If you encounter any issues with your ChooChoo Farmhouse End Tables, require replacement parts, or have questions not covered in this manual, please contact ChooChoo customer support. We are committed to assisting you promptly.

Contact Information: Please refer to the contact details provided with your purchase or visit the official ChooChoo brand store on Amazon for support options.

Online Support: Visit the ChooChoo Store on Amazon

© 2026 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question