ChooChoo TS20001

ChooChoo Floating Wall Mount TV Stand

Model: TS20001

1. Introduction

This manual provides comprehensive instructions for the assembly, installation, operation, and maintenance of your ChooChoo Floating Wall Mount TV Stand, Model TS20001. Please read this guide thoroughly before beginning assembly to ensure safe and correct usage of the product.

2. Safety Information

WARNING: Follow assembly and installation instructions carefully to ensure structural integrity and safety. Improper assembly or installation may result in property damage or personal injury. This unit is designed for wall mounting only. Do not place excessive weight on the unit. The maximum weight limit is 23 pounds.

- Always ensure the mounting surface is suitable and strong enough to support the weight of the TV stand and any items placed on it.
- Use appropriate wall anchors for your specific wall type (e.g., wood studs, concrete, drywall). Consult a professional if unsure.
- Do not allow children to climb on or play with the unit.
- Distribute weight evenly across the shelves.
- Keep small parts away from children during assembly.

3. Package Contents

Before beginning assembly, verify that all parts and hardware are present. Refer to the included assembly instruction sheet for a detailed list of numbered components.

- Main Shelf Panels (Numbered)
- Connecting Brackets
- Wall Mounting Hardware (Screws, Anchors)
- Cable Management Grommets

- Assembly Instruction Manual




Figure 1: Product Dimensions (11.7"D x 60"W x 8.3"H)

4. Assembly Instructions

Assembly of the ChooChoo Floating TV Stand is designed to be straightforward. All parts are numbered for easy identification. Follow the step-by-step instructions provided in the separate assembly guide included in your package.

1. **Identify Components:** Lay out all numbered panels and hardware. Match them with the component list in your assembly guide.
2. **Connect Shelf Sections:** Assemble the main shelf sections using the provided connecting brackets and screws. Ensure all connections are tight and secure.
3. **Install Cable Management:** Insert the cable management grommets into the designated holes on the top and bottom panels.
4. **Final Assembly Check:** Before mounting, ensure the unit is fully assembled and all screws are tightened.



Figure 2: Assembled TV Stand (example setup)

5. Wall Installation

Proper wall installation is crucial for the stability and safety of your floating TV stand. This unit is designed for wall mounting. It is recommended to mount the unit to wall studs for maximum security. If mounting to drywall without studs, use heavy-duty drywall anchors (not always included, and may need to be purchased separately based on wall type and weight requirements).

1. **Choose Location:** Select a suitable wall location, considering TV placement, power outlets, and stud locations.
2. **Mark Mounting Points:** Use a level and pencil to mark the precise drilling points on the wall according to the assembly guide's template.
3. **Drill Pilot Holes:** Drill pilot holes at the marked points. Ensure the drill bit size matches the recommended size for your chosen anchors.
4. **Insert Anchors:** Insert the appropriate wall anchors into the pilot holes.
5. **Mount the Stand:** Carefully align the TV stand with the installed anchors and secure it to the wall using the provided screws. Ensure the stand is level and firmly attached.
6. **Verify Stability:** Gently test the stability of the mounted stand before placing any items on it.



Figure 3: Key Features including Cable Management and Mounting Bracket

6. Operating and Usage

The ChooChoo Floating TV Stand is designed to organize your media devices and enhance your living space. Its unique asymmetrical design offers both aesthetic appeal and practical storage.

- **Media Device Placement:** Use the central compartment and side shelves to store electronic devices such as routers, set-top boxes, DVD players, gaming consoles, or soundbars.
- **Cable Management:** Utilize the integrated wire holes to route and conceal cables, maintaining a neat and organized appearance.
- **Decorative Items:** The flat surfaces can also be used to display decorative items, plants, or books.
- **Weight Distribution:** Always ensure that items are placed evenly and do not exceed the maximum weight capacity of 23 pounds.

7. Maintenance

To maintain the appearance and longevity of your ChooChoo Floating TV Stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Inspection:** Periodically check all screws and mounting hardware to ensure they remain tight and secure. Retighten if necessary.
- **Avoid Moisture:** Protect the unit from excessive moisture and direct sunlight to prevent warping or fading.

8. Troubleshooting

Problem	Possible Cause	Solution
Stand feels unstable or loose on the wall.	Improper wall anchors or insufficient support.	Ensure the stand is mounted to wall studs. If not possible, use heavy-duty drywall anchors appropriate for the weight. Verify all mounting screws are securely tightened.

Problem	Possible Cause	Solution
Cables are visible and untidy.	Cables not routed through management holes.	Utilize the integrated cable management holes to route and conceal all wires.
Difficulty during assembly.	Incorrect part identification or steps missed.	Refer to the numbered parts list and step-by-step instructions in the assembly guide. Ensure all parts are correctly oriented.

9. Specifications

Attribute	Detail
Brand:	ChooChoo
Model Number:	TS20001
Product Dimensions:	11.7"D x 60"W x 8.3"H
Material:	Engineered Wood
Color:	Black
Mounting Type:	Wall Mount
Number of Shelves:	1 (multi-level design)
Weight Limit:	23 Pounds
Item Weight:	22.3 Pounds
Assembly Required:	Yes
Recommended Uses:	Bedroom, Living Room, Office

10. Customer Support

If you have any questions, require assistance with assembly or installation, or encounter any issues with your ChooChoo Floating TV Stand, please do not hesitate to contact our customer service team. We are committed to providing timely support and resolving any after-sales problems.
Contact information (e.g., email, phone number, website) would typically be provided here by the manufacturer.

© 2026 ChooChoo. All rights reserved.