Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Soomill Santa Claus 7026A

Soomill Santa Claus Building Blocks 7026A Instruction Manual

Model: Santa Claus 7026A

Introduction

This manual provides detailed instructions for assembling the Soomill Santa Claus Building Blocks set, model 7026A. This micro brick set contains approximately 2500 pieces and is designed for individuals aged 9 years and older. Please read all instructions carefully before beginning assembly to ensure a smooth and enjoyable building experience.

Safety Information

- **Small Parts Warning:** This product contains small parts and is not suitable for children under 3 years of age due to choking hazards.
- **Adult Supervision:** Adult supervision is recommended during assembly, especially for younger users, to assist with complex steps and ensure proper handling of small pieces.
- **Material Safety:** The building blocks are made from high-quality ABS material. Avoid placing pieces in the mouth.
- **Storage:** Keep all unbuilt pieces and the completed model away from pets and very young children to prevent accidental ingestion.

Package Contents

Before starting assembly, verify that all components are present. The package should contain:

- Approximately 2500 Micro Building Blocks (various colors and shapes)
- 1 x Instruction Booklet
- 1 x Soomill Santa Claus Building Blocks Box



Image: The package contents laid out, showing the instruction manual, bags of micro bricks, and the product box.

Assembly Instructions

Follow the step-by-step instructions provided in the included color instruction booklet. The assembly process involves connecting micro bricks to form the Santa Claus model.

1. **Preparation:** Clear a well-lit, flat surface for assembly. Organize the micro bricks by color or shape if desired, though the instruction booklet typically guides piece selection per step.
2. **Step-by-Step Building:** Refer to the instruction booklet for detailed diagrams and sequences. Each step illustrates which pieces to use and where to place them.
3. **Precision:** Micro bricks require careful placement. Ensure each brick is firmly connected to the previous one to maintain structural integrity.
4. **Troubleshooting during Assembly:** If a piece does not fit, double-check the instruction diagram for the correct orientation and piece type. Do not force pieces together.



Image: A user's hands are shown assembling micro bricks while referring to the detailed instruction booklet.



Image: The instruction manual is open on a wooden surface, surrounded by various red micro bricks, illustrating the assembly process.

Usage and Display

Once assembled, the Soomill Santa Claus model serves as a decorative item. Its dimensions are approximately 7.5 inches (height) x 7 inches (width) x 3.9 inches (depth).

- **Display:** Place the completed model on a stable, flat surface.
- **Interaction:** While durable, the model is primarily for display. Avoid rough handling or dropping to prevent pieces from detaching.



Image: The assembled Santa Claus model is shown with its approximate dimensions: 7.5 inches tall, 7 inches wide, and 3.9 inches deep.




Image: The completed Santa Claus micro brick model is displayed on a nightstand next to a bed, serving as a decorative item.

Maintenance

To keep your Soomill Santa Claus model in good condition:

- **Cleaning:** Dust the model gently with a soft, dry cloth or a soft brush. Avoid using harsh chemicals or abrasive materials.
- **Storage:** If disassembling for storage, keep all pieces in a sealed container to prevent loss. Store in a cool, dry place away from direct sunlight to prevent material degradation or color fading.

Troubleshooting

Issue	Possible Cause	Solution
Missing pieces	Packaging error or pieces misplaced during unboxing/assembly.	Carefully check all packaging materials and the assembly area. If pieces are genuinely missing, contact Soomill customer support.
Pieces do not fit together	Incorrect piece selection or incorrect orientation.	Refer to the instruction booklet to verify the correct piece and its orientation for the current step. Do not force pieces.
Model is unstable or falls apart	Pieces not fully pressed together or an assembly error in a previous step.	Ensure all bricks are firmly connected. Review previous steps in the instruction booklet to identify any misassembled sections.

Specifications

Brand: Soomill

Model Name: Santa Claus

Model Number: 7026A

Material: Acrylonitrile Butadiene Styrene (ABS)

Number of Pieces: Approximately 2500

Assembled Dimensions (L x W x H): 7 x 7.5 x 3.9 inches (approximate)

Item Weight: 1.08 pounds

Recommended Age: 9+ years

UPC: 603922380900



Image: Details highlighting the product's quality: Certified ABS Material, Smooth Edges, Each One Fits Perfectly, and Compatibility with Major Brands.

Warranty and Support

Soomill is committed to customer satisfaction. If you encounter any issues with missing pieces or product defects, please contact our customer support team for assistance. We aim to provide a happy and easy shopping experience.
For support, please refer to the contact information provided on the product packaging or the retailer's website where the product was purchased.

© 2024 Soomill. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B88KPK1D

More documents and user manuals: **https://manuals.plus/**