

[Manuals.plus](#) /

› [PTHTECHUS](#) /

› PTHTECHUS Kids Phone Toy P1 User Manual

PTHTECHUS P1

PTHTECHUS Kids Phone Toy P1 User Manual

Model: P1 | Brand: PTHTECHUS

1. INTRODUCTION

The PTHTECHUS Kids Phone Toy P1 is an innovative and engaging device designed for children aged 4-14. This toy phone combines educational features with entertainment, offering a safe and fun experience without the need for SIM cards or app downloads. It features a 3.8-inch touch screen, dual HD cameras, 16 built-in educational games, an MP3 music player, audio recorder, pedometer, flashlight, alarm clock, and more. It is an ideal tool to help children develop reflexes, logical thinking, and hand-eye coordination while providing a rich multimedia experience.



Image: The PTHTECHUS Kids Phone Toy P1, showcasing its sleek black design, touch screen display, and accompanying accessories including a lanyard, USB-C charging cable, and wired headphones.

2. WHAT'S IN THE BOX

Please check the contents of your package to ensure all items are present:

- 1 x PTHTECHUS Kids Smartphone
- 1 x USB Type-C Charging Cable
- 1 x Type-C Headset (Wired Headphones)
- 1 x Lanyard

- 1 x User Manual



Image: A visual representation of the items included in the PTHTECHUS Kids Phone Toy P1 package, confirming the presence of the smartphone, charging cable, headset, lanyard, and user manual.

3. SETUP GUIDE

3.1 Initial Charging

Before first use, fully charge the device. Use the original USB Type-C charging cable provided. Connect the cable to the phone's charging port and a compatible USB power source. Ensure the side button on the phone is in the "ON" position for charging to commence.

3.2 Powering On/Off

To turn on the phone, ensure the side button is in the "ON" position, then press and hold the power button until the screen illuminates. To turn off, press and hold the power button until the power-off prompt appears, then confirm.

3.3 Screen Protective Film

A protective film is applied to the screen during manufacturing. For optimal touch screen responsiveness and clarity, gently peel off this film before use.

4. OPERATING INSTRUCTIONS

The PTHTECHUS Kids Phone Toy P1 features a user-friendly touch interface. Navigate through menus and select functions by tapping the icons on the screen.

Children's smart phone



Image: Screen display of the PTHTECHUS Kids Phone Toy P1 showing various function icons including Camera, Pedometer, Music, Game, Video, Calculator, Player, Album, Tool, Setup, Flashlight, and Recording.

4.1 Games

The phone includes 16 educational puzzle games designed to enhance children's reflexes, logical thinking, and hand-eye coordination. Tap the 'Game' icon to access the game library and select a game to play.



Image: A child engrossed in playing one of the 16 educational puzzle games on the PTHTECHUS Kids Phone Toy, illustrating the interactive and engaging nature of the device.

4.2 Camera and Video Recording

Equipped with two HD cameras, the phone allows children to capture photos and record videos. Tap the 'Camera' icon to open

the camera interface. You can switch between front and rear cameras. The device also includes 34 fun magic stickers to add creative effects to photos. Captured media can be saved on the device and transferred to a computer via the USB cable for permanent storage.



Image: The PTHTECHUS Kids Phone Toy P1 highlighting its dual HD cameras and capabilities for video recording, video playback, and photo album viewing.



Image: A selection of 34 fun and magical stickers available on the PTHTECHUS Kids Phone Toy P1, which can be used to enhance and personalize photos taken by children.

4.3 MP3 Music Player

The built-in MP3 player allows children to listen to their favorite music. Connect the provided Type-C headset to enjoy audio privately. To add music, connect the phone to a computer via the USB cable. Ensure the phone is turned off and the side button is in the "ON" position for file transfer. Copy MP3 format songs to the "My Music" folder on the phone's SD card.

MP3 music player

(headset included)



The children's phone comes with a headphone, which allows the child to enjoy the music at any time, and to transfer music to the phone via the included SUB charging cable.

Image: The PTHTECHUS Kids Phone Toy P1 displaying its MP3 music player interface, with a child happily listening to music using the included headset.

4.4 Other Functions

- **Pedometer:** Tracks steps taken, encouraging physical activity.
- **Alarm Clock:** Set alarms for reminders or waking up.
- **Calculator:** Basic arithmetic functions for learning.
- **Voice Recorder:** Record audio notes or messages.
- **Flashlight:** A convenient built-in light.
- **Calendar:** View dates and manage time.
- **Timer/Stopwatch:** For various activities and games.
- **Customizable Wallpapers:** Choose from 15+15 analog and digital desktop wallpapers to personalize the device.
- **Multiple Languages:** Supports 5 languages.



Image: Visual representation of the PTHTTECHUS Kids Phone Toy P1's utility features, including an alarm clock, calculator, flashlight, and pedometer, demonstrating its role as a helpful tool for children.



Image: A display of 16 different wallpaper options available on the PTHTTECHUS Kids Phone Toy P1, allowing children to customize their device's appearance with various themes.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and body of the phone. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in active use.
- **Water Resistance:** This device is not waterproof. Avoid exposure to water or excessive moisture.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device will not turn on.	Battery is depleted; Side power button is off; Device needs reset.	Charge the device using the original cable (ensure side button is "ON"). Check if the side power button is in the "ON" position. If still unresponsive, locate the reset button (usually a small pinhole) and press it gently with a thin object.
Insufficient memory space.	Too many photos/videos stored.	Clean up unnecessary photos and videos from the device. Connect the phone to a PC via USB cable to transfer and save files, freeing up storage.
Cannot transfer music to the phone.	Incorrect file format; Side button not "ON" during transfer; Phone not off during transfer.	Ensure music files are in MP3 format. Turn off the phone and ensure the side button is in the "ON" position before connecting to the computer for transfer. Copy files to the "My Music" folder.
Phone heats up during charging.	Normal during charging; Overheating.	A slight warmth during charging is normal. If the phone becomes excessively hot, disconnect it immediately and contact customer support. Ensure charging is done in a well-ventilated area.
No call function.	This is a toy phone.	This children's toy phone does not have a call function and does not require a SIM card. All functions are built into the product itself.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	1.57 x 0.55 x 9.05 inches
Item Weight	2.29 ounces
Item Model Number	P1
Manufacturer Recommended Age	36 months - 14 years
Batteries	1 Lithium Polymer battery (included)
Display	3.8-inch Touch Screen
Cameras	Dual HD Cameras
Games	16 Educational Puzzle Games
Music Player	MP3 format support, Type-C headphone jack

Children's smart phone




Image: A diagram illustrating the key dimensions of the PTHTECHUS Kids Phone Toy P1, including its length, width, and thickness, along with the locations of the camera, flashlight, charging port, and home button.

8. WARRANTY AND SUPPORT

PTHTECHUS is committed to providing high-quality products and excellent after-sales service. While specific warranty periods may vary by region, we encourage customers to reach out directly if they encounter any issues with their product.

If you have any problems or questions regarding your PTHTECHUS Kids Phone Toy P1, please do not hesitate to contact our customer support team. Refer to the contact information provided on the product packaging or the official PTHTECHUS website for assistance.

© 2025 PTHTECHUS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question