

[Manuals.plus](#) /

› [PTHTECHUS](#) /

› PTHTECHUS Kids Phone Toy XA35 Instruction Manual

PTHTECHUS XA35

PTHTECHUS Kids Phone Toy XA35 Instruction Manual

Model: XA35

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your PTHTECHUS Kids Phone Toy, model XA35. Please read this manual thoroughly before operating the device and retain it for future reference.

1.1 Safety Information

WARNING: CHOKING HAZARD -- Small parts. Not for children under 3 years.

Ensure adult supervision, especially for younger children, to prevent misuse or accidental ingestion of small components.

2. WHAT'S INCLUDED

Verify that all items are present in the package:

- 1 x PTHTECHUS Kids Phone Toy (XA35)
- 1 x USB Type-C Charging Cable
- 1 x User Manual (this document)



Image: The PTHTECHUS Kids Phone Toy XA35 in purple, shown with its included USB Type-C charging cable and a lanyard.

3. INITIAL SETUP

3.1 Charging the Device

1. Locate the USB Type-C charging port on the device.
2. Connect the provided USB Type-C cable to the phone and a compatible USB power source (e.g., computer USB port, wall adapter).
3. The screen will indicate charging status. Allow the device to fully charge before first use.

3.2 Powering On/Off

- To power on: Press and hold the power button (usually on the side) until the screen illuminates.

- To power off: Press and hold the power button until a power-off option appears on the screen, then confirm.

3.3 Screen Protective Film

A protective film is applied to the screen during manufacturing. For optimal touch screen responsiveness, gently peel off this film before use.

4. OPERATING INSTRUCTIONS

The PTHTECHUS Kids Phone Toy features a 3.8-inch touch screen for navigation. Swipe left or right to browse through the various functions and tap icons to select.

4.1 Main Functions Overview



Image: Screen displaying icons for Camera, Pedometer, Music, Game, Video, Calculator, Player, Album, Tool, Setup, Flashlight, and Recording.

4.2 Camera and Video Recording

The device includes dual HD cameras for taking photos and recording videos. Access the camera function from the main menu.

- **Taking Photos:** Tap the camera icon to enter camera mode. Tap the shutter button on the screen to capture an image.
- **Video Recording:** Switch to video mode within the camera interface. Tap to start and stop recording.
- **Fun Stickers:** Utilize the built-in 34 magic stickers to add creative effects to photos.
- **Transferring Media:** Photos and videos can be transferred to a computer via the USB cable for storage.



Image: A child holding the PTHTECHUS Kids Phone Toy, demonstrating the camera function with a parent.

4.3 Music Player

The integrated MP3 player allows for music playback. Connect Type-C headphones (not included in this specific package, but compatible) for private listening.

- **Adding Music:**
 - a. Ensure the phone is powered off.
 - b. Slide the side button to "ON".
 - c. Connect the phone to a computer using the USB Type-C cable.

- d. The computer will recognize the phone as an external disk.
 - e. Copy MP3 format music files to the "My Music" folder on the phone's SD card.
 - f. Safely eject the device from the computer and disconnect the cable.
- **Playback:** Navigate to the Music Player icon and select your desired song.

MP3 music player (headset included)



The children's phone comes with a headphone, which allows the child to enjoy the music at any time, and to transfer music to the phone via the included SUB charging cable.

Image: A young girl smiling while listening to music through headphones connected to the PTHTECHUS Kids Phone Toy.

Your browser does not support the video tag.

Video: This video demonstrates the process of adding music files to the PTHTECHUS Kids Phone Toy by connecting it to a computer via USB and transferring MP3 files to the designated music folder.

4.4 Educational Games

The device includes 16 pre-installed educational puzzle games designed to enhance reflexes, logical thinking, and hand-eye coordination.

16 children's favorite educational puzzle games


A young boy with brown hair, wearing a blue and white striped shirt and grey shorts, is sitting on a grassy field. He is looking down at a smartphone in his hands. Surrounding him are 16 floating bubbles, each containing a different educational icon. The bubbles are arranged in a circular pattern around the boy. The icons include: a globe with a red dot, a crown, a parachute with a Bitcoin symbol, a car, a stop sign, a rocket, a hand pointing, a clock, a lightbulb, a gear, a magnifying glass, a book, a pencil, a ruler, a compass, a protractor, and a set of scales. The background is a blurred green field with trees in the distance.

4.5 Other Utilities


The PTHTECHUS Kids Phone Toy offers several practical tools:

- **Alarm Clock:** Set alarms for reminders or wake-up times.
- **Calculator:** Perform basic arithmetic operations.
- **Pedometer:** Track steps taken, walks, and estimated calories burned.
- **Flashlight:** Activate the built-in torch for illumination.
- **Audio Recorder:** Record voice notes or sounds.
- **Calendar:** View dates and manage simple schedules.
- **Timer:** Use for timed activities.
- **Wallpapers:** Customize the device's appearance with various themes and backgrounds.

A good helper for children



Alarm clock



Calculator



Flashlight



Pedometer

Image: A collage showing children interacting with the alarm clock, calculator, flashlight, and pedometer features of the PTHTECHUS Kids Phone Toy.

Your browser does not support the video tag.

Video: This video provides a comprehensive demonstration of the various functions and features available on the PTHTECHUS Kids Phone Toy, including navigation, games, camera, music player, and utility apps.

5. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge regularly.
- **Memory Management:** If the device indicates insufficient memory, transfer photos and videos to a computer to free up space.

6. TROUBLESHOOTING

Problem	Solution
Device does not turn on.	Ensure the device is charged. Check if the "ON" button on the side of the phone is in the correct position. Press the reset button (if available, usually a small pinhole) to restart the device.
Cannot transfer music to the device.	Verify that the music files are in MP3 format. Ensure the phone is powered off and the side button is set to "ON" before connecting to a computer. Confirm the computer recognizes the device as an external drive.
"Insufficient memory" message appears.	Delete unnecessary photos or videos from the device. Connect the device to a computer and transfer media files to free up internal storage.
Device is unresponsive or frozen.	Press and hold the power button to force a restart. If unresponsive, use a small pin to press the reset button.

7. SPECIFICATIONS

Feature	Detail
Model Number	P1 (XA35)
Screen Size	3.8 inches
Product Dimensions	1.57 x 0.55 x 9.05 inches
Item Weight	2.29 ounces
Recommended Age	36 months - 14 years
Battery Type	1 Lithium Polymer battery (included)
Connectivity	USB Type-C for charging and data transfer (no Wi-Fi, Bluetooth, or cellular)
Camera	Dual HD Cameras with photo and video recording
Games	16 educational puzzle games
Audio	MP3 Music Player, Audio Recorder, Type-C headphone jack
Additional Features	Pedometer, Torch, Alarm Clock, Calculator, Calendar, Timer, Wallpapers, 5 Languages

Children's smart phone



Image: Diagram illustrating the dimensions (length, width, thickness) and key external features like camera, flashlight, charging port, and home button of the PTHTECHUS Kids Phone Toy XA35.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

PTHTECHUS is committed to providing quality products. For specific warranty details and terms, please refer to the warranty card included with your product or contact customer support.

8.2 Customer Support

If you encounter any issues or have questions not covered in this manual, please contact PTHTECHUS customer support. Contact information can typically be found on the product packaging or the official PTHTECHUS website.

We are dedicated to assisting our customers and resolving any concerns promptly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question