VAYDEER Mac Mini M1

VAYDEER Mac Mini Vertical Stand with 8-in-1 USB Hub and Power Adapter User Manual

Model: Mac Mini M1

1. Product Overview

The VAYDEER Mac Mini Vertical Stand is an 8-in-1 docking station designed to enhance the functionality and organization of your Mac Mini. It provides additional connectivity options, improves heat dissipation, and optimizes Wi-Fi and Bluetooth signal performance by holding your Mac Mini in a vertical orientation. This stand is compatible with Mac Mini M1, 2018, and newer models.
Key features include:

- **Space-Saving Design:** Holds your Mac Mini vertically to free up desk space.
- **Enhanced Connectivity:** Features 3x USB 3.0 Type-A ports, 1x USB 3.0 Type-C port (for data transfer only), 1x SD card slot, 1x TF card slot, 1x 2.5-inch SATA HDD/SSD bay, and 1x 3.5mm audio jack.
- **Improved Heat Dissipation:** Vertical orientation allows for better airflow, preventing overheating and extending the Mac Mini's lifespan.
- **Optimized Wireless Signals:** Positioning the Mac Mini vertically can improve Wi-Fi and Bluetooth signal strength and speed.
- **Stable and Protective:** Constructed from durable ABS plastic with soft rubber padding to secure and protect your Mac Mini from scratches.



Image 1.1: Front view of the VAYDEER Mac Mini Vertical Stand, highlighting the 8-in-1 front-mounted extra ports including indicator light, SD card slot, USB 3.0 ports, Type-C 3.0 port, 3.5mm audio jack, and TF card slot.

Image 1.2: Diagram illustrating the vertical storage structure of the stand, showing airflow arrows for improved heat dissipation around the Mac Mini.

Image 1.3: Illustration demonstrating how the vertical orientation of the VAYDEER stand enhances Wi-Fi and Bluetooth signal strength for the Mac Mini.

2. Package Contents

Please check the package contents upon unboxing to ensure all items are present:

- 1x VAYDEER Mac Mini Vertical Stand

- 1x Power Adapter (5V/2A)
- 1x Power Cable
- 1x Screwdriver
- 1x Quick Start Guide



Image 2.1: Contents of the VAYDEER Mac Mini Vertical Stand package, including the stand, power adapter, power cable, screwdriver, and quick start guide.

3. Setup Instructions

3.1 Installing the Mac Mini

1. Gently slide your Mac Mini into the vertical slot of the VAYDEER stand. Ensure it is seated firmly and securely. The internal rubber padding will protect your Mac Mini from scratches.
2. Connect the USB-C cable from the stand to the Mac Mini's USB-C port. This connection enables the stand's USB hub functionality.
3. Connect the provided power adapter to the stand's power input port, then plug the adapter into a wall outlet. This provides power for the hub and any installed HDD/SSD.

Image 3.1: Illustration of connecting the Mac Mini to the vertical stand via its Type-C port, ensuring the stand's hub functionality.

3.2 Installing a 2.5-inch HDD/SSD (Optional)

The stand includes a bay for a 2.5-inch SATA HDD or SSD to expand your storage capacity. Follow these steps:

1. Locate the HDD/SSD bay on the bottom of the stand.

2. Using the provided screwdriver, carefully open the bay cover.
3. Insert your 2.5-inch SATA HDD or SSD into the bay, ensuring it connects properly to the SATA interface.
4. Close the bay cover and secure it with the screws.
5. Ensure the external power adapter is connected to the stand for stable operation of the HDD/SSD.

Image 3.2: Step-by-step guide showing the installation of a 2.5-inch HDD/SSD into the dedicated bay at the bottom of the VAYDEER Mac Mini Stand, and

connecting the external power supply.

4. Operating Instructions

4.1 Using the USB Ports

The front-mounted ports provide convenient access for connecting various peripherals:

- **USB 3.0 Type-A Ports (x3):** Connect USB flash drives, external keyboards, mice, printers, or other USB 3.0/2.0 devices for high-speed data transfer.
- **USB 3.0 Type-C Port (x1):** Use this port for data transfer with compatible USB-C devices.*Note: This port does not support video output or power delivery.*

4.2 Using the Card Reader Slots

- **SD Card Slot (x1):** Insert standard SD, SDHC, or SDXC memory cards for data access.
- **TF Card Slot (x1):** Insert microSD (TF) cards for data access.

Note: Avoid inserting both SD and TF cards simultaneously into the same slot if they share a controller, as this may cause conflicts.

4.3 Using the 3.5mm Audio Jack

Connect headphones, earphones, or a microphone to the 3.5mm audio jack for audio input/output. Ensure your Mac Mini's sound settings are configured to use the external audio device.

4.4 Power Button

The Mac Mini's power button remains fully accessible in the top-left corner when installed in the stand.

5. Maintenance

To ensure the longevity and optimal performance of your VAYDEER Mac Mini Vertical Stand, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the exterior of the stand. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the finish.
- **Dust Removal:** Periodically check the ports and ventilation openings for dust accumulation. Use compressed air to gently clear any dust, ensuring proper airflow and preventing overheating.
- **Environmental Conditions:** Operate the stand in a clean, dry environment, away from direct sunlight, excessive heat, and moisture.
- **Cable Management:** Ensure all connected cables are neatly organized and not under tension to prevent damage to the ports or cables themselves.

6. Troubleshooting

If you encounter issues with your VAYDEER Mac Mini Vertical Stand, refer to the following common troubleshooting steps:

- **No Power/Indicator Light Off:**
    - Ensure the power adapter is securely connected to both the stand and a working wall outlet.
    - Verify the power cable is not damaged.

- Try a different wall outlet.

- **USB Devices Not Recognized:**
  - Ensure the USB-C cable connecting the stand to your Mac Mini is securely plugged in.
  - Try connecting the USB device directly to your Mac Mini to confirm the device is functional.
  - Restart your Mac Mini.
  - Ensure the stand's power adapter is connected, especially for power-hungry USB devices or the internal HDD/SSD.

- **SD/TF Card Not Detected:**
  - Ensure the card is fully inserted into the correct slot.
  - Try the card in another device to confirm it is functional.
  - Avoid inserting both SD and TF cards simultaneously.
  - Restart your Mac Mini.

- **Internal HDD/SSD Not Appearing:**
  - Confirm the 2.5-inch drive is correctly installed and seated in its bay.
  - Ensure the stand's external power adapter is connected and providing power.
  - Check Disk Utility on your Mac Mini to see if the drive is recognized but needs formatting or partitioning.
  - Try the drive in another enclosure or directly connected to confirm functionality.

- **Audio Jack Not Working:**
  - Check your Mac Mini's Sound Preferences to ensure the correct output/input device is selected.
  - Ensure your headphones/microphone are fully plugged into the 3.5mm jack.
  - Test your audio device directly with your Mac Mini or another device.

7. Specifications

Feature	Detail
Brand	VAYDEER
Model Number	Mac Mini M1 (VAYDEER-SZD012)
Compatible Devices	Mac Mini (M1, 2018 and newer)
Material	ABS Plastic
Color	Space Gray
Interface Hardware	USB
Total USB Ports	3x USB 3.0 Type-A, 1x USB 3.0 Type-C (Data Only)
Other Ports	1x SD Card Slot, 1x TF Card Slot, 1x 2.5-inch SATA HDD/SSD Bay, 1x 3.5mm Audio Jack
Power Input	5V/2A (via included power adapter)
Item Weight	460 Grams
Dimensions (L x W x H)	205 x 155 x 134 mm

Feature	Detail
ASIN	B0B8BYK6JR
UPC/GTIN	769044621823

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact VAYDEER customer service through the retailer where the product was purchased. Please have your model number (Mac Mini M1) and ASIN (B0B8BYK6JR) ready when contacting support.
You can also visit the official VAYDEER brand store for more information:VAYDEER Store

© 2024 VAYDEER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question