

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PTHTECHUS](#) /

› [PTHTECHUS Children's Smartwatch Phone User Manual](#)

PTHTECHUS X16GMP-Watch

PTHTECHUS Children's Smartwatch Phone User Manual

Model: X16GMP-Watch

Brand: PTHTECHUS

INTRODUCTION

This manual provides comprehensive instructions for the PTHTECHUS Children's Smartwatch Phone, model X16GMP-Watch. It covers setup, operation, maintenance, and troubleshooting to ensure optimal use of the device's various features, including two-way calling, music playback, and educational games.

SAFETY INFORMATION

WARNING:

- Do not disassemble, strike, or throw the device into fire.
- Must be connected to a power source in 5V/1A while charging.
- The battery is not replaceable.
- **CHOKING HAZARD:** Small parts. Not for children under 3 years.

Kids SmartWatch Details



This image displays the product packaging, highlighting important safety warnings, including a choking hazard for children under 3 years due to small parts.

PRODUCT FEATURES

The PTHTECHUS Children's Smartwatch Phone is designed with a variety of functions to keep children entertained and connected:

- **Two-Way Call:** Supports Nano SIM card for direct communication with pre-set contacts.
- **MP3 Music Player:** Built-in player for audio entertainment.
- **Dual Camera:** High-definition cameras for capturing photos and selfies.
- **Calculator:** Basic arithmetic functions for learning.
- **Recorder:** Voice recording capability.
- **SOS Function:** Emergency call feature for quick assistance by pressing the power button for 3 seconds.
- **Audio Books:** Pre-loaded stories for listening enjoyment.
- **Puzzle Games:** 14 educational games to train logical thinking.
- **Flashlight:** Built-in torch for illumination.
- **Alarm Clock:** Three customizable alarm settings to cultivate a sense of time.
- **Time Teacher & Pet Bobby:** Interactive features for learning time and virtual pet care.

- **Customizable Watch Faces:** 11 digital, 11 analog, and 8 replaceable wallpapers for personalization.



This image shows the smartwatch with its vibrant display, illustrating an incoming call, a key feature for two-way communication.

Phone call



This image highlights the two-way calling capability and the SOS emergency function, crucial for child safety and communication.

Dual Cameras



Camera



Video Recorder



Video Player

6 Photo Stickers



This image illustrates the dual camera functionality of the smartwatch, allowing children to capture photos and videos.

18 Puzzle Games

Exercise children's logical ability and get fun



This image showcases the 14 built-in puzzle games designed to enhance children's logical thinking and provide entertainment.



This image demonstrates the MP3 music player, interactive time teaching feature, and the virtual pet 'Pet Bobby' on the smartwatch.



Little Red Riding Hood



Rapunzel

10 Audiobooks



The Boy Who Cried Wolf



The Fox and The Crow



The Frog Prince



The Gingerbread Man



The Lion and the Mouse



The Ugly Ducking



Three little pigs



The Wolf in Sheep's Clothing



This image highlights the pre-loaded audiobooks feature, offering children a selection of stories to listen to.



This image illustrates the personalization options available, including different digital and analog clock faces and wallpapers.

SETUP GUIDE

Initial Charging

Upon receiving the watch, turn it off and charge it for at least 2 hours before first use. Use the provided USB cable.

SIM Card Installation

The smartwatch requires a Nano SIM card for call functionality. Follow these steps for proper installation:

1. Ensure the watch is powered off before inserting the SIM card.
2. Insert the Nano SIM card correctly into the designated slot. Refer to the operation diagram for proper orientation.
3. Move the button on the back of the watch to the outside.
4. Long press the power button to start the watch.

Recommended SIM Cards: Vodafone / T-Mobile / E-Plus SIM-card (for Germany). For Austria: 3-Austria / T-Mobile SIM-card.

Note: This smartwatch does not have GPS functionality and does not require an application download.



This diagram visually guides the user through the process of inserting a Nano SIM card and the steps to power on the smartwatch.

OPERATING INSTRUCTIONS

Two-Way Call

After inserting a Nano SIM card, your child can make and receive calls. You can set up contacts via the phone book function on the smartwatch for easy dialing.

Music Playback

The watch has a built-in MP3 player. To add music:

1. Connect the watch to your PC using the provided USB cable.
2. Download music files in MP3 format.
3. Transfer the MP3 files to the Micro SD card within the watch, specifically into the folder named "My Music". If the 1GB SD card was formatted, ensure this folder is created.

Camera Function

The smartwatch features dual high-definition cameras. Children can access the camera app to take photos and selfies anytime.

SOS Emergency Call

In an emergency, your child can press and hold the power button for 3 seconds to activate the SOS function. The watch will automatically dial three pre-set emergency phone numbers repeatedly until one is answered.

Games

The watch includes 14 different puzzle games. Navigate to the games section to select and play them, helping to train the child's brain.

Flashlight

Activate the flashlight function from the watch's menu to provide illumination in dark environments.

Recorder

Use the recording function to capture voice notes or short audio clips.

Alarm Clock

Set up to three alarm times through the alarm clock application to help cultivate your child's sense of time and routine.

MAINTENANCE

- Keep the watch clean by wiping it with a soft, dry cloth.
- Avoid exposing the watch to extreme temperatures or direct sunlight for prolonged periods.
- Do not immerse the watch in water. It is not waterproof.
- Charge the watch regularly to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch does not turn on	Low battery	Charge the watch for at least 2 hours.
Cannot make/receive calls	SIM card not inserted correctly or not activated; No 2G network coverage.	Ensure SIM card is correctly inserted and activated with a voice plan. Check for 2G network availability in your area.
Music not playing	Music files not in "My Music" folder or incorrect format.	Ensure MP3 files are in the "My Music" folder on the Micro SD card.
SOS function not working	Emergency numbers not set or SIM card issues.	Set up emergency contact numbers in the watch settings. Check SIM card functionality.


If issues persist, please contact customer support.

SPECIFICATIONS


Feature	Detail
Brand	PTHTECHUS
Model	X16GMP-Watch
Display	1.65 inch HD Touch Screen (240 x 240px)
Screen Size (Standing)	1.69 Inches
Battery	480 mAh Polymer Battery
Battery Life (Average)	2 days
Charging Time	2 Hours
Connectivity	GSM (2G), Bluetooth, USB
Human Interface Input	Touchscreen
Product Dimensions	3 x 1 x 6 cm; 50 g
Included Accessories	1 x charging cable, 1 x user manual, 1 x smartwatch
Supported SIM Type	Nano GSM SIM Card
Operating System	Customized
Special Features	Children's camera, Children's watch, Kids MP4, kids mp3, kids smart watch phone

Brand: PTHTECHUS® Model: X16

Product Name: Kids Smartwatch/Kinder Smartwatch/腕時計/Enfants Smartwatch/Bambini Smartwatch/Niños Relojes Inteligentes



Apex CE Specialists GmbH
Habichtweg 1, 41468, Neuss, Germany
Contact person: Wells
E-mail: Info@apex-ce.com



APEX CE SPECIALISTS LIMITED
89 Princess Street, Manchester, M1
4HT, UK
Contact person: Wells
E-mail: Info@apex-ce.com

Manufacturer Name:
yangjiangshiyangdongquzhangtongjiayuankejico.LTD.
Address: yangjiangshiyangdongquheshanzhenbinjianghuayuan
Adong401(zhusuoshenbao),guangdongsheng,529500,CN



WARNING:

- Please do not make the device disassemble, strike or throw into the fire.
- Please must be connected to a power source in 5V/1A while charging device.
- The battery is not replaceable.



- CHOKING HAZARD-Small Parts, Not for children under 3yrs
- CHOKING HAZARD-Kleinteile, Nicht für Kinder unter 3yrs
- PERICOLO DI CHOKING-Piccole parti, non per i bambini sotto i 3 anni
- Riesgo de asfixia-piezas pequeñas, no para niños menores de 3 años
- Les petites pièces présentent un risque d'étouffement et ne conviennent pas aux enfants de moins de 3 ans

Production date: 30/04/2024



MADE IN CHINA

This image provides detailed dimensions of the smartwatch, including screen size and strap length.

WARRANTY AND SUPPORT

For any questions, technical support, or warranty claims, please contact PTHTECHUS customer service. Please retain your purchase receipt as proof of purchase for warranty purposes.

Email: info@apex-ce.com

