

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro Transformers Generations Legacy Buzzworthy Bumblebee Heroic Maximal Dinobot Figure F4095 Instruction Manual

Hasbro F4095

Hasbro Transformers Generations Legacy Buzzworthy Bumblebee Heroic Maximal Dinobot Figure F4095 Instruction Manual

INTRODUCTION

This instruction manual provides essential information for the assembly, operation, and maintenance of your Hasbro Transformers Generations Legacy Buzzworthy Bumblebee Heroic Maximal Dinobot action figure. Please read these instructions carefully before use to ensure proper handling and to maximize your enjoyment of the product.

PRODUCT OVERVIEW

The Maximal Dinobot figure is a collectible action figure capable of transforming between two distinct modes: a robot mode and a Velociraptor beast mode. This figure is part of the Transformers Generations Legacy series, designed for fans and collectors.



Figure in Robot Mode: This image displays the Maximal Dinobot figure in its primary robot form, showcasing its detailed sculpt and articulation points. The figure stands approximately 18cm tall.



Figure in Beast Mode: This image shows the Maximal Dinobot figure transformed into its Velociraptor beast mode, highlighting the intricate design and transformation engineering. Note the articulation in the head, arms, and legs in this mode.

TRANSFORMATION INSTRUCTIONS (ROBOT TO BEAST MODE)

Transforming your Dinobot figure requires careful manipulation of its various parts. Follow these general steps. Refer to the included physical instructions for detailed diagrams if available.

1. **Prepare Robot Mode:** Ensure all robot mode panels and limbs are securely tabbed in place before beginning transformation.
2. **Fold Legs:** Carefully fold the robot's legs and feet to form the rear section of the dinosaur. Pay attention to hinges and rotating joints.
3. **Position Arms:** Reconfigure the robot's arms to become the dinosaur's forelimbs or integrate them into the body structure.
4. **Rotate Torso/Head:** Rotate or collapse the robot's torso and head to reveal or form the dinosaur's head and neck.

5. **Panel Alignment:** Align and tab in all panels to secure the beast mode form. Ensure no gaps or loose parts remain.

To transform from Beast Mode back to Robot Mode, reverse these steps. Always apply gentle, even pressure during transformation to avoid damage.

OPERATING AND POSING

The Dinobot figure features multiple points of articulation in both robot and beast modes, allowing for dynamic posing and display.

- **Robot Mode:** Articulation includes shoulders, elbows, hips, knees, and head rotation. Use these joints to create various action poses.
- **Beast Mode:** The dinosaur mode offers articulation in the head (up and down), arms (multiple joints), and legs. This allows for expressive dinosaur poses.
- **Accessories:** If included, attach any weapon accessories to the designated ports in robot mode.

Avoid forcing joints beyond their intended range of motion to prevent breakage.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Dinobot figure, follow these care guidelines:

- **Cleaning:** Wipe the figure gently with a soft, dry cloth to remove dust. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent material degradation and discoloration.
- **Handling:** Always handle the figure by its main body parts, avoiding excessive pressure on small or delicate components.

TROUBLESHOOTING

This section addresses common concerns you might encounter with your figure.

Discoloration

Some figures, particularly those with lighter plastic components, may exhibit discoloration over time, often appearing as yellowing. This can be influenced by environmental factors such as UV exposure and material composition.

- **Prevention:** Store the figure in a cool, dark place away from direct sunlight and fluorescent lights. Keep it in its original packaging or a display case that offers UV protection if possible.
- **Observation:** Regularly inspect your figure for any signs of discoloration. While not always preventable, early detection can help in adjusting storage conditions.
- **Note:** Discoloration is often a material property and may not be reversible.

SPECIFICATIONS

Brand:	Hasbro
Model Number:	F4095
ASIN:	B0B8CM5ZZ4

Item Weight:	7 ounces
Recommended Age:	36 months - 6 years
Figure Height (Robot Mode):	Approximately 18 cm (7 inches)

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts.

This product contains small parts and is not suitable for children under 36 months (3 years) due to potential choking hazards. Adult supervision is recommended for all children playing with this figure, especially during transformation.

WARRANTY AND CUSTOMER SUPPORT

For information regarding product warranty, returns, or technical support, please contact Hasbro customer service directly. Details can typically be found on the product packaging or on the official Hasbro website.

Hasbro Official Website: www.hasbro.com

OFFICIAL PRODUCT VIDEOS

No official seller-created product videos are available for embedding at this time. Please refer to the written instructions and images for guidance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

