1 Hora AUT114N

1 Hora Wireless Earbuds User Manual

Model: AUT114N
Brand: 1 Hora

Introduction

Thank you for choosing 1 Hora Wireless Earbuds, Model AUT114N. These earbuds are designed to provide a high-quality audio experience with convenient features such as a digital LED power display, Bluetooth 5.3 connectivity, and intuitive physical button controls. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

Safety Information

- Do not disassemble or modify the earbuds or charging case.
- Keep away from extreme temperatures, humidity, and liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Clean with a soft, dry cloth. Do not use harsh chemicals.
- Use only the provided charging cable or a compatible 2A charger.
- Dispose of the product responsibly according to local regulations.

Package Contents

Please check the package for the following items:

- 1 x Charging Case
- 2 x Wireless Earbuds (Left and Right)
- 1 x USB-C Charging Cable
- 3 x Pairs of Eartips (S, M, L)
- 1 x User Manual



Image: The 1 Hora Wireless Earbuds in their open charging case, showcasing the digital battery display and the earbuds themselves.

Product Overview

Key Features:

- **Digital LED Power Display:** Shows the remaining battery of the charging case.
- **Bluetooth 5.3:** Ensures stable and fast connection.
- **Comfortable Design:** Soft silicone eartips (3 pairs included) for a secure and comfortable fit.
- **Excellent Sound Performance:** 8mm drivers deliver clear trebles and appropriate bass.
- **Built-in Microphone:** With noise reduction for clear calls.
- **Physical Buttons:** For precise control over music and calls.



Image: The charging case with its digital LED display showing "100", indicating a full charge. This display provides real-time battery status.



Image: A close-up of an earbud highlighting its physical button, with icons illustrating functions like Play, Pause, Next Song, Volume, Answer Call, and Reject Call.

Setup Guide

1. Initial Charging

Before first use, ensure both the earbuds and the charging case are fully charged. The earbuds have a small protective plastic film on their charging contacts that must be removed before charging. This film prevents battery drain during shipping.

Your browser does not support the video tag.

Video: A detailed demonstration of unboxing the earbuds, removing the protective film from the charging contacts, and placing them into the charging case. This step is crucial for proper charging and functionality.

1. Open the charging case and remove the earbuds.
2. Carefully peel off the blue protective film from the charging contacts on each earbud.
3. Place the earbuds back into the charging case.
4. Connect the USB-C charging cable to the port on the back of the charging case and plug the other end into a 2A USB power adapter (not included).
5. The digital LED display on the case will show the charging progress. A "100" indicates a full charge.

2. Bluetooth Pairing

The earbuds will automatically enter pairing mode when removed from the charging case.

Your browser does not support the video tag.

Video: Demonstrates the easy pairing process. Simply remove the earbuds from the case, enable Bluetooth on your device, and select "1HORA-AUT114" to connect.

1. Open the charging case and take out both earbuds. They will automatically power on and enter pairing mode (indicated by flashing red and blue lights on one earbud).
2. On your smartphone, tablet, or computer, enable Bluetooth.
3. Search for available devices and select "1HORA-A8S" or "1HORA-AUT114" from the list.
4. Once connected, the earbud lights will stop flashing, and you will hear a confirmation tone.

TWS Pairing Troubleshooting:

If only one earbud connects or two "1HORA-A8S" devices appear in your Bluetooth list, follow these steps:

1. Disable Bluetooth on your device and "forget" or "unpair" any previous "1HORA-A8S" connections.
2. Manually power off both earbuds by pressing and holding their physical buttons for approximately 5 seconds until the lights turn off.
3. Press and hold the physical button on each earbud again for about 2 seconds to power them on. They will flash red and blue.
4. Double-click the physical button on the LEFT earbud. The left earbud's light will turn off, indicating it has paired with the right earbud. The right earbud will continue flashing red and blue.
5. Re-enable Bluetooth on your device and search for "1HORA-A8S". Only one device should now appear. Connect to it.

Operating Instructions

The earbuds feature physical buttons for easy control:

Music Control:

- **Play/Pause:** Press the physical button on the Left (L) earbud once.
- **Next Song:** Press the physical button on the Right (R) earbud once.
- **Volume -:** Double-press the physical button on the Left (L) earbud.
- **Volume +:** Double-press the physical button on the Right (R) earbud.

Your browser does not support the video tag.

Video: Demonstrates how to control music playback using the physical buttons on the earbuds, including play/pause and skipping tracks.

Call Control:

- **Answer/End Call:** Press the physical button on either earbud (L/R) once.
- **Reject Call:** Press and hold the physical button on either earbud (L/R) for 1.5 seconds.

Your browser does not support the video tag.

Video: Shows how to manage phone calls directly from the earbuds, including answering, ending, and rejecting incoming calls.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Eartips:** Remove and clean the silicone eartips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use.

Troubleshooting

Problem	Solution
Earbuds not charging	Ensure the protective film is removed from the earbud charging contacts. Check the charging cable and adapter. Ensure the charging case has power.
Only one earbud has sound	Follow the TWS pairing troubleshooting steps in the "Bluetooth Pairing" section to re-pair the earbuds with each other.
Earbuds not connecting to device	Ensure Bluetooth is enabled on your device. Make sure earbuds are in pairing mode. "Forget" the device on your phone and try pairing again.
Low battery warning	The earbuds will announce "Low battery" every 30 seconds when battery is low. Place them in the charging case to recharge.

Specifications

Feature	Detail
Model Name	AUT114N
Connectivity Technology	Wireless (Bluetooth 5.3)
Earbud Playtime	Up to 7 hours
Total Playtime (with case)	Over 24 hours
Charging Time (Earbuds)	1.5 hours
Charging Time (Case)	1.5 hours
Driver Size	8mm
Control Type	Physical Button Control
Weight	37 Grams
Max Operating Distance	10 Meters
Color	Black

Warranty and Support

1 Hora products come with a manufacturer's warranty. For detailed warranty information, technical support, or any inquiries, please refer to the contact information provided on the product packaging or visit the official 1 Hora website. We are committed to providing excellent customer service and support.