

[Manuals.plus](#) /

› [SoBuy](#) /

› SoBuy BZR51-W Wall Cabinet with Louvered Doors - Assembly and Care Manual

SoBuy BZR51-W

SoBuy BZR51-W Wall Cabinet with Louvered Doors

Assembly and Care Manual

INTRODUCTION

Thank you for purchasing the SoBuy BZR51-W Wall Cabinet. This manual provides detailed instructions for the safe assembly, proper use, and maintenance of your new cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This versatile wall-mounted cabinet, featuring two louvered doors, is designed for use in bathrooms or kitchens, offering practical storage solutions. Its compact dimensions (58x20x60cm) make it suitable for various spaces.



Image: The SoBuy BZR51-W wall cabinet, white, with louvered doors, mounted above a toilet in a modern bathroom.

SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Contact customer service if any parts are missing or defective.
- Do not overtighten screws, as this may damage the material.
- For wall mounting, use appropriate hardware for your wall type (e.g., drywall, concrete, wood studs). If unsure, consult a professional.
- Keep small parts away from children during assembly to prevent choking hazards.
- Do not exceed the maximum weight capacity of 25 kg.

PARTS LIST

Please verify that all components listed below are included in your package:

- Cabinet panels (top, bottom, sides, back)
- Louvered doors (2 units)
- Adjustable shelf (1 unit)
- Hinges and door handles
- Assembly hardware (screws, dowels, shelf pins, wall mounting anchors)
- Instruction manual




Image: A diagram illustrating the different components and hardware included for assembly.

SETUP AND ASSEMBLY

Assembly is required for this wall cabinet. Follow these steps carefully:

1. Step 1: Prepare the Panels

Unpack all components and lay them out on a clean, soft surface. Identify each panel and piece of hardware using the provided diagram.

2. Step 2: Assemble the Main Frame

Attach the side panels to the bottom panel using the designated screws and dowels. Ensure they are securely fastened.

3. Step 3: Install the Back Panel

Slide or nail the back panel into the grooves or attach it to the rear of the assembled frame.

4. Step 4: Attach the Top Panel

Secure the top panel to the assembled frame.

5. Step 5: Install the Adjustable Shelf

Insert the shelf pins into the desired holes inside the cabinet. Place the adjustable shelf on top of the pins.

6. Step 6: Attach the Doors

Mount the hinges to the doors and then attach the doors to the cabinet frame. Adjust hinges as needed for proper alignment. Install door handles.

7. Step 7: Wall Mounting

Choose a suitable location on your wall. Mark the drilling points for the wall mounting hardware. Drill pilot holes and insert appropriate wall anchors. Securely attach the cabinet to the wall using the provided screws. Ensure the cabinet is level and firmly attached before placing items inside.



Image: An illustration showing the final step of wall mounting the cabinet, indicating where to secure it to the wall.

OPERATING INSTRUCTIONS

The SoBuy BZR51-W Wall Cabinet is designed for straightforward use:

- **Door Operation:** Open and close the louvered doors gently using the handles.
- **Adjustable Shelf:** The internal shelf can be adjusted to three different heights to accommodate items of varying sizes. To adjust, remove the shelf, reposition the shelf pins to the desired height, and then place the shelf back on the pins.
- **Storage:** Utilize the enclosed compartments and the open bottom shelf for storing bathroom essentials, kitchen items, or decorative objects.



Image: Inside the cabinet, showing a roll of toilet paper on the adjustable shelf.



Image: Inside the cabinet, showing a woven basket on the adjustable shelf.

MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood material.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Environment:** Avoid exposing the cabinet to excessive moisture or direct sunlight for prolonged periods, which can cause warping or discoloration.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cabinet feels wobbly after assembly.	Screws are not fully tightened; uneven wall surface.	Ensure all assembly screws are tightened. Check wall mounting for secure attachment and use shims if the wall is uneven.
Doors do not align properly.	Hinges are not adjusted correctly; cabinet frame is not square.	Adjust the screws on the hinges to align the doors. Recheck the main frame assembly for squareness.
Missing parts or damaged components.	Packaging error or transit damage.	Contact SoBuy customer support with your purchase details for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	SoBuy
Model Number	BZR51-W
Color	White
Material	Engineered Wood (MDF E1)
Product Dimensions (DxWxH)	20P x 58I x 60H cm (7.9 x 22.8 x 23.6 inches)
Item Weight	Approximately 8.9 kg (19.6 lbs)
Maximum Weight Capacity	25 kg (55 lbs)
Number of Doors	2
Special Features	Adjustable Shelf, Wall Mountable
Assembly Required	Yes




Image: A detailed diagram showing the dimensions of the SoBuy BZR51-W wall cabinet.

WARRANTY AND SUPPORT

SoBuy products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty information provided at the time of purchase or visit the official SoBuy website. If you encounter any issues or have questions regarding your SoBuy BZR51-W Wall Cabinet, please do not hesitate to contact SoBuy customer service.

Contact Information:

- Refer to your purchase documentation for direct contact methods.
- Visit the [SoBuy Store on Amazon](#) for more information and support options.

© 2026 SoBuy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question