Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nespresso ENV90.A

Nespresso Vertuo Pop ENV90.A Coffee Machine User Manual

Model: ENV90.A

1. Introduction

Welcome to the Nespresso Vertuo Pop experience. This automatic coffee machine is designed to deliver a perfect coffee experience with every cup, utilizing innovative Centrifusion technology and smart connectivity. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new coffee machine.



Figure 1.1: Nespresso Vertuo Pop ENV90.A Coffee Machine in Pacific Blue.

The Vertuo Pop machine is compact and stylish, fitting seamlessly into any kitchen. It offers versatility with four cup sizes, from a short espresso to a large mug, automatically adjusting brewing parameters based on the capsule's barcode.

2. Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- **Electrical Safety:** Ensure the voltage specified on the appliance matches your local mains voltage. Do not immerse the appliance, cord, or plug in water or other liquids.
- **Hot Surfaces:** The machine contains hot water and steam. Avoid contact with hot surfaces during and immediately after brewing.
- **Children:** This appliance is not intended for use by children. Keep the machine and its cord out of reach of children.
- **Maintenance:** Do not attempt to repair the appliance yourself. Contact Nespresso Customer Service for any repairs.

3. Setup and First Use

3.1 Unpacking

Carefully remove the coffee machine and all accessories from the packaging. Check for any damage. Retain packaging for future transport or storage.

3.2 Initial Cleaning

1. Rinse the water tank, cup support, and used capsule container with fresh drinking water.
2. Place the drip tray and cup support back onto the machine.

3.3 Filling the Water Tank

Fill the water tank with fresh drinking water up to the 'MAX' level. Place the water tank back onto the machine.





Figure 3.1: Water tank on the Nespresso Vertuo Pop machine.

3.4 First Rinse Cycle

Before first use, perform a rinse cycle to clean the internal system:

1. Plug the machine into a grounded power outlet.
2. Press the button to turn on the machine. It will blink white while heating up.
3. Once stable white, open the head of the machine and close it without inserting a capsule.
4. Place a container (at least 0.5L) under the coffee outlet.
5. Press the button to start the rinse cycle. Water will flow through the machine.
6. The machine will stop automatically. Empty the container. Your machine is now ready for use.

4. Operating Instructions

4.1 Brewing Coffee

1. Ensure the water tank is filled with fresh water.
2. Turn on the machine by pressing the button. Wait for the light to turn steady white.
3. Lift the lever to open the machine head.
4. Insert a Nespresso Vertuo capsule into the capsule holder. The machine automatically reads the barcode on the capsule to adjust brewing parameters.
5. Close the machine head by pushing down the lever until it locks.
6. Place a cup of appropriate size on the cup support.
7. Press the button to start brewing. The machine will automatically stop when the coffee is ready.
8. After brewing, lift the lever to open the machine head. The used capsule will be automatically ejected into the used capsule container.



Figure 4.1: Inserting a Nespresso Vertuo capsule.

FÜR 4 TASSENGRÖßEN

ESPRESSO



40 ml

80 ml

COFFEE



150 ml

230 ml

Figure 4.2: Vertuo capsule sizes and coffee volumes (Espresso: 40ml, 80ml; Coffee: 150ml, 230ml).

4.2 Connectivity (Bluetooth & Wi-Fi)

Your Vertuo Pop machine features Bluetooth and Wi-Fi connectivity for automatic software updates and enhanced features via the Nespresso app. Refer to the Nespresso app for detailed instructions on connecting your machine.

5. Maintenance

Regular cleaning and descaling ensure optimal performance and longevity of your Nespresso machine.

5.1 Daily Cleaning

- Empty and rinse the used capsule container and drip tray daily.
- Wipe the machine exterior with a damp cloth.

5.2 Descaling

Descaling is crucial to remove mineral deposits and maintain coffee quality. The machine will indicate when descaling is needed (refer to the Nespresso app or machine indicator lights for specific signals).

1. Refer to the Nespresso descaling kit instructions for proper usage.
2. Ensure the machine is empty of capsules and the water tank is filled with the descaling solution and water mixture.
3. Place a large container (at least 1L) under the coffee outlet.
4. Follow the descaling procedure as outlined in the Nespresso app or the machine's full user manual.

6. Troubleshooting

If you encounter issues with your Nespresso Vertuo Pop machine, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No coffee flow	Water tank empty; machine not heated; descaling needed.	Fill water tank; wait for steady light; perform descaling.
Leaking water	Water tank not properly seated; drip tray full.	Ensure water tank is correctly positioned; empty drip tray.
Coffee is cold	Machine not preheated; cold cup.	Allow machine to fully heat; pre-warm cup with hot water.
Machine not turning on	Not plugged in; power outage.	Check power connection; verify power supply.

For more complex issues or if the problem persists, please contact Nespresso Customer Service.

7. Specifications

Feature	Specification
Brand	Nespresso
Model Number	ENV90.A
Color	Pacific Blue
Dimensions (L x W x H)	42.6 x 13.6 x 25 cm
Weight	4 kg
Voltage	120 Volts
Special Features	App Control, Centrifusion Technology




Figure 7.1: Product Dimensions.

8. Warranty and Support

Your Nespresso Vertuo Pop machine comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical assistance, troubleshooting, or to order Nespresso capsules and accessories, please contact Nespresso Customer Service or visit the official Nespresso website.



Figure 8.1: Vertuo capsules are exclusively for Vertuo machines; Original capsules are not compatible.

8.1 Nespresso Recycling Program

Nespresso is committed to sustainability. You can recycle your used Nespresso aluminum capsules through their dedicated recycling program. Collect your used capsules in the provided recycling bag and return them to a Nespresso boutique or designated collection point.



Figure 8.2: Nespresso capsule recycling program.

© 2024 Nespresso. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B8DT2JXT

More documents and user manuals: **https://manuals.plus/**