

[Manuals.plus](#) /

> [ONN](#) /

> ONN 32-Inch Class HD (720P) LED Smart TV Instruction Manual, Model 100012589

ONN 100012589

ONN 32-Inch Class HD (720P) LED Smart TV Instruction Manual

Model: 100012589

INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your ONN 32-Inch Class HD (720P) LED Smart TV. This television integrates Roku TV for access to a wide range of streaming services and features a 720p HD LED display. Please read this manual thoroughly before using your TV to ensure safe and efficient operation.



Figure 1: Front view of the ONN 32-Inch Roku TV with streaming service logos.

SAFETY INFORMATION

To reduce the risk of electric shock, fire, or damage, please observe the following safety precautions:

- Do not expose the TV to rain or moisture.
- Do not remove the back cover. Refer servicing to qualified personnel.
- Ensure proper ventilation. Do not block ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Protect the power cord from being walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.

WHAT'S IN THE BOX

Verify that all components are present upon unboxing:

- ONN 32-Inch Class HD (720P) LED Smart TV
- Roku TV Remote Control
- TV Stand Legs (if not wall-mounted)
- Power Cord
- Quick Start Guide
- DVD (Included Components: dvd)



Figure 2: ONN Roku TV remote control.

SETUP

1. Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, clean surface to prevent damage.
2. Align the stand legs with the screw holes on the bottom of the TV.
3. Secure the legs with the provided screws.

Alternatively, the TV supports VESA wall mounts (wall mount not included). Ensure the wall mount is compatible with the TV's VESA pattern and weight.

2. Connecting Power

Plug the power cord into the TV's power input, then into a wall outlet. The TV is not battery-powered and requires a direct power connection.

3. Connecting External Devices

Your TV includes multiple ports for connecting external devices:

- **HDMI:** Connect Blu-ray players, gaming consoles, cable boxes, etc. (HDMI 1, HDMI 2, HDMI 3 (ARC)).
- **USB:** For media playback from USB drives.
- **AV:** For older devices using composite video and stereo audio.
- **Headphone:** For private listening.
- **Antenna/Cable:** For over-the-air broadcasts or cable TV.

4. Initial Setup (Roku TV Guided Setup)

1. Power on the TV using the remote control.
2. Follow the on-screen instructions to select your language and country.
3. Connect to your home Wi-Fi network by selecting your network and entering the password.
4. Activate your Roku TV account. You will need a computer or smartphone to complete this step.
5. The TV will then guide you through adding streaming channels and customizing settings.

OPERATING THE TV

1. Remote Control Functions

The Roku TV remote provides intuitive control over your television:

- **Power Button:** Turns the TV on/off.
- **Directional Pad (Purple Cross):** Navigates menus and selects items.
- **OK Button:** Confirms selections.
- **Home Button:** Returns to the Roku TV home screen.
- **Back Button:** Returns to the previous screen.
- **Volume Up/Down:** Adjusts the TV volume (located on the side of the remote).
- **Mute:** Mutes/unmutes audio (located on the side of the remote).
- **Quick Access Buttons:** Dedicated buttons for popular streaming services like Netflix, Disney+, Apple TV, and Hulu.

2. Navigation and Inputs

From the Roku TV Home screen, you can access:

- **Streaming Channels:** Browse and launch your installed apps.
- **TV Inputs:** Switch between connected devices (HDMI 1, HDMI 2, AV, etc.).
- **Live TV:** Access over-the-air or cable channels.
- **Search:** Find movies, TV shows, actors, and channels across various services.
- **Settings:** Customize your TV's picture, sound, network, and other preferences.

America's #1 TV streaming platform built in

Stream what you love with a massive selection
of free, live, and premium TV channels.*

Based on hours streamed. -Hypothesis Group.



Figure 3: The ONN Roku TV home screen.

3. Smart TV Features

Your ONN Roku TV offers advanced smart features:

- **Streaming Services:** Enjoy instant access to Netflix, Disney+, YouTube, Apple TV, and many more.
- **Voice Assistants:** Compatible with Alexa and Google Assistant for voice control of your TV and content.
- **Roku Mobile App:** Control your TV, search for content, use voice control, enjoy private listening through headphones, or cast photos/videos from your phone.
- **Apple AirPlay & HomeKit:** Seamlessly stream content from Apple devices and integrate with your HomeKit ecosystem.

onn.™ • Roku TV

Control your onn.™ Roku TV with the free
Roku mobile app for iOS or Android™

Quickly search for your favorite movie or show using voice control, enjoy private listening through headphones, or cast photos or videos from your phone.

Limitations apply to the mobile app. See support.roku.com for device compatibility information.
Voice search only supports English, French, Spanish, Portuguese, and German languages.



Figure 4: Roku mobile app for controlling your TV.

Works With Popular Voice Assistants

Easily control your TV, play entertainment, and more with hands-free voice commands.



Apple, Apple Home, AirPlay, HomeKit and Siri are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Alexa enabled device is required to work with Alexa. Google and Google Home are trademarks of Google LLC. Third party features and services may be subject to change or removal without notice.

Figure 5: Voice assistant and smart home compatibility.

4. Picture and Audio Settings

Customize your viewing and listening experience via the Settings menu:

- **Picture Settings:** Adjust brightness, contrast, color, and other display options.
- **Audio Settings:** Control volume modes, audio effects, and digital audio output. The TV features Dolby Audio for clear sound.




Figure 6: Dolby Audio for enhanced sound quality.

5. Parental Controls

Set up parental controls to restrict access to certain content based on ratings or channels.

6. Guest Mode

Enable Guest Mode for temporary users, allowing them to sign in to their own streaming accounts which are automatically removed upon checkout.

7. Theme and Screensaver Customization

Personalize your Roku TV experience by choosing different themes, wallpapers, and screensavers from the Settings menu.

MAINTENANCE

1. Cleaning the TV

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, dampen the cloth with water or a screen cleaner. Do not use harsh chemicals or abrasive materials.

2. Software Updates

Your ONN Roku TV automatically receives software updates over the internet. Ensure your TV is connected to the

internet to receive the latest features and improvements.

TROUBLESHOOTING

If you encounter issues with your TV, try the following solutions:

- **No Power:** Check if the power cord is securely plugged into the TV and the wall outlet. Try a different outlet.
- **No Picture/Sound:** Ensure the correct input source is selected. Check all cable connections to external devices.
- **Remote Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV.
- **Network Connection Issues:** Restart your router and modem. Re-enter your Wi-Fi password in the TV's network settings.
- **Poor Picture Quality:** Adjust picture settings in the TV menu. Ensure your content source is providing a high-quality signal.

SPECIFICATIONS

Feature	Specification
Brand	ONN
Model Number	100012589
Screen Size	32 Inches
Display Technology	LED
Resolution	720p
Refresh Rate	60 Hz
Special Feature	Smart TV
Connectivity Technology	Wi-Fi, HDMI, USB, Headphone, Component
Product Dimensions	37"D x 9"W x 23"H
Item Weight	12.92 pounds



Figure 7: Energy Guide for Model 100012589.

WARRANTY AND SUPPORT

This product is sold as 'Amazon Renewed'. For specific warranty details and support, please refer to the Amazon Renewed program terms and conditions or contact Amazon customer service directly. General product support may be available through the ONN brand's official channels.

© 2023 ONN. All rights reserved.

Roku, the Roku logo, Roku TV, and the Roku TV logo are trademarks and/or registered trademarks of Roku, Inc. in the United States and other countries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question