T4TREAM BDC5DRSC-LRO

T4TREAM Farmhouse 5-Drawer Dresser Instruction Manual

Model: BDC5DRSC-LRO | Brand: T4TREAM

1. Product Overview

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your T4TREAM Farmhouse 5-Drawer Dresser. Designed with a rustic aesthetic, this tall chest offers ample storage for your bedroom, living room, or hallway, blending modern and farmhouse styles seamlessly.



Image 1: The T4TREAM Farmhouse 5-Drawer Dresser in Light Rustic Oak, showcasing its rustic design and five spacious drawers.

Key features include:

- **Sturdy & Durable Construction:** Made from FSC-Certified wood, optimal MDF, and P2 engineered wood for long-term use and scratch resistance. Features widened 2"x2" dresser legs for enhanced stability.
- **Spacious Storage:** Five deep drawers (26.9"W x 11.4"D x 8.2"H each) provide significant storage capacity, capable of holding 20-25 T-shirts or 15-20 pairs of jeans per drawer.
- **Smooth Operation:** Drawers slide easily on ball bearings, complemented by double-coated metal handles for effortless opening and closing.
- **Farmhouse Design:** Rustic wooden design with barn door style elements and metal decor, adding character to any room.
- **Anti-Tipping Device:** Includes a safety device to prevent accidental tipping, ensuring the safety of your family.

Your browser does not support the video tag.

Video 1: An overview of the T4TREAM Farmhouse 5-Drawer Dresser, demonstrating its design, storage capacity, and smooth drawer operation.

2. Safety Information

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tipping Device:** It is crucial to install the included anti-tipping device to prevent the dresser from falling over, especially in households with children. Securely fasten the device to a wall stud.
- **Weight Limits:** Do not exceed the specified weight limits for the dresser top (150 lbs) and individual drawers (50 lbs). Overloading can compromise stability and cause damage.
- **Level Surface:** Always place the dresser on a flat, level surface to ensure stability and prevent wobbling.
- **Children Safety:** Do not allow children to climb on or play with the dresser. Keep heavy items in lower drawers to reduce the risk of tipping.
- **Assembly:** Assemble the dresser according to the instructions provided. Ensure all screws and fasteners are tightened securely before use.




Image 2: Illustration demonstrating the importance and proper installation of the anti-tipping device to ensure family safety.

3. Package Contents

Before beginning assembly, verify that all parts and hardware are present. Refer to the detailed installation instructions included in your package for a complete list and identification of components. All parts and accessories are coded for easy identification.

Typical contents include:

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts, sides, backs, bottoms)
- Metal sliding rails
- Vintage metal handles
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tipping device
- Instruction manual

4. Setup and Assembly Instructions

Assembly is required for this product. Please follow the step-by-step instructions provided in the separate installation manual included with your purchase. Precise holes and coded parts are designed to make the assembly process accurate and faster.

General Assembly Tips:

- Clear a spacious area for assembly to avoid damaging components.
- Lay out all parts and hardware, matching them to the provided diagrams.
- Use a Phillips head screwdriver (not included) for assembly.
- Do not overtighten screws to prevent stripping or damaging the wood.
- It is recommended to have two people for assembly, especially for larger components, to ensure stability and ease of handling.
- Ensure the anti-tipping device is securely installed to a wall stud after assembly is complete.



Image 3: Detailed views of dresser components, including widened legs, metal corner decorations, side panel design, and vintage metal handles.

5. Operating Instructions

Your T4TREAM dresser is designed for convenient and efficient storage. To ensure optimal performance and longevity, please observe the following:

- **Drawer Usage:** Gently pull and push the drawers using the metal handles. The ball-bearing slides ensure smooth operation. Avoid forcing drawers open or closed.
- **Load Distribution:** Distribute items evenly within the drawers. Avoid placing all heavy items in one drawer, especially upper ones, to maintain balance and prevent strain on the slides.

- **Capacity:** Each drawer is designed to hold a significant amount of clothing, such as 20-25 T-shirts or 15-20 pairs of jeans. Do not overload drawers beyond their capacity.
- **Top Surface:** The dresser top has a weight capacity of 150 lbs. It is suitable for decorative items, lamps, or small electronics. Avoid placing excessively heavy objects on the top surface.



Image 4: View of the dresser with drawers open, illustrating the large storage capacity suitable for various clothing items.

6. Maintenance

Proper care will help maintain the appearance and functionality of your dresser for years to come.

- **Cleaning:** Wipe the dresser surfaces with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the distressed finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration of the wood finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

- **Drawer Slides:** If drawer slides become stiff, a small amount of silicone lubricant can be applied to the rails.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Dresser wobbles or is unstable.	Uneven floor; loose fasteners; improper assembly.	Ensure the dresser is on a level surface. Check and tighten all assembly fasteners. Verify assembly steps were followed correctly.
Drawers do not slide smoothly.	Misaligned drawer slides; debris in tracks; overloaded drawer.	Check if drawer slides are properly aligned and secured. Clean any debris from the tracks. Reduce the weight in the drawer. Apply silicone lubricant to the slides if needed.
Missing hardware or damaged parts upon arrival.	Shipping damage; packaging error.	Contact T4TREAM customer support immediately with details of the missing or damaged items. Provide part codes if available.
Finish bubbling or peeling.	Exposure to moisture or extreme temperatures.	Avoid placing hot or wet items directly on the surface. Use coasters or protective mats. Ensure the room environment is stable.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	T4TREAM
Model Name	BDC5DRSC-LRO
Product Dimensions	15.75"D x 31.25"W x 48"H
Color	Light Rustic Oak
Item Weight	112.4 Pounds
Mounting Type	Floor Mount
Room Type	Bedroom, Living Room
Special Feature	5 Storage Drawers, Farmhouse Style, Metal Decor
Furniture Finish	Distressed finish
Drawer Type	European Slide
Product Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes
Dresser Top Weight Capacity	150 lbs
Drawers Weight Capacity	50 lbs (each)



Image 5: Detailed dimensions of the Farmhouse 5-Drawer Dresser, including overall size and individual drawer measurements.

9. Warranty and Support

T4TREAM stands behind the quality of its products. This dresser comes with a**Lifetime Warranty**, ensuring peace of mind regarding manufacturing defects and material quality.

For any questions, concerns, or assistance with assembly, missing parts, or product issues, please do not hesitate to contact our customer support team. We are committed to providing a satisfactory answer within 24 hours.

Contact Information:

- Refer to the contact details provided in your product packaging or on the official T4TREAM website.
- When contacting support, please have your model name (BDC5DRSC-LRO) and purchase date ready.

© 2025 T4TREAM. All rights reserved.