

[Manuals.plus](#) /

› [ONN](#) /

› ONN 24-Inch Class HD LED Smart TV User Manual

ONN ONN2022

ONN 24-Inch Class HD LED Smart TV User Manual

Model: ONN2022 (100012590)

1. PRODUCT OVERVIEW

The ONN 24-Inch Class HD LED Smart TV offers a vibrant 720p resolution display with a 60 Hz refresh rate, providing clear and smooth visuals. This DLED display ensures excellent color range and sharp contrasts for an immersive viewing experience. As a Smart TV, it provides instant access to popular streaming services like Netflix, YouTube, and many more, directly from your television. It also features wireless streaming capabilities and is compatible with voice assistants such as Alexa and Google Assistant, allowing for convenient control of your entertainment.



Figure 1.1: Front view of the ONN 24-inch Smart TV with Roku TV interface.

2. WHAT'S IN THE BOX

Please check the contents of your product packaging. The following items should be included:

- ONN 24-Inch Class HD LED Smart TV Unit
- Remote Control
- TV Stands (2)
- Screws for TV Stands
- Power Cable
- Quick Start Guide
- Optical-out Cable (as specified)



Figure 2.1: Included Remote Control.

3. SETUP GUIDE

3.1 Attaching the TV Stands

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align each stand with the corresponding screw holes on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.




Figure 3.1: Side view of the TV with stand.

3.2 Connecting Power and Initial Setup

1. Plug the power cable into the TV's power input, then into a wall outlet.
2. Press the Power button on the remote control or on the TV itself.
3. Follow the on-screen instructions to complete the initial setup, including language selection, time zone, and channel scanning.

3.3 Network Connection

To access Smart TV features and streaming services, connect your TV to the internet:

- During initial setup, select your Wi-Fi network and enter the password.
- Alternatively, navigate to **Settings > Network > Wireless** to connect or change networks.

4. OPERATING YOUR TV

4.1 Using the Remote Control

The included remote control allows you to navigate menus, adjust volume, change channels, and access Smart TV features. Familiarize yourself with the buttons for power, input selection, volume, channel, and the directional pad for menu navigation.

4.2 Smart TV Features and Streaming

Your ONN Smart TV provides access to a wide range of streaming applications. Once connected to the internet, you can:

- Browse and launch pre-installed apps like Netflix, YouTube, and more.
- Download additional apps from the app store (if available on your specific Roku TV interface).
- Utilize the search function to find content across various streaming platforms.

4.3 Voice Assistant Integration

This TV is compatible with Alexa and Google Assistant. To use voice commands:

- Ensure your TV is connected to the same network as your voice assistant device.
- Follow the instructions in your voice assistant app to link your ONN Smart TV.
- You can then use voice commands to play movies, TV shows, adjust volume, and more.

4.4 Connecting External Devices

The TV features multiple input ports for connecting external devices:

- **HDMI:** Connect Blu-ray players, gaming consoles, cable boxes, etc.
- **USB:** Play media files from a USB drive.
- **Optical-out:** Connect to a soundbar or home theater system for enhanced audio.




Figure 4.1: Rear view of the TV showing connectivity ports.

5. MAINTENANCE

5.1 Cleaning the Screen

To clean the TV screen:

- Turn off the TV and unplug it from the power outlet.
- Gently wipe the screen with a soft, dry microfiber cloth.
- For stubborn marks, lightly dampen the cloth with water or a screen-specific cleaning solution (do not spray directly onto the screen).
- Avoid using harsh chemicals, abrasive cleaners, or paper towels, as these can damage the screen.

5.2 General Care

- Keep the TV away from direct sunlight, heat sources, and excessive dust.

- Ensure proper ventilation around the TV to prevent overheating.
- Do not place heavy objects on top of the TV.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Ensure the power cable is securely plugged into both the TV and the wall outlet. Try a different outlet.
No Picture / No Sound	Check the input source (HDMI, AV, etc.) is correctly selected. Verify external devices are powered on and connected properly.
Cannot Connect to Wi-Fi	Ensure your Wi-Fi router is on and working. Re-enter the Wi-Fi password carefully. Try restarting both the TV and the router.
Remote Control Not Working	Check and replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Apps Not Loading / Slow Performance	Check your internet connection speed. Try restarting the TV. Clear app cache if the option is available in settings.

7. SPECIFICATIONS

Feature	Specification
Brand	ONN
Model Number	ONN2022 (100012590)
Screen Size	24 Inches
Display Technology	LED, DLED
Resolution	720p (HD)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Connectivity Technology	Wireless
Voice Assistants	Works with Alexa & Google Assistant
Product Dimensions (D x W x H)	23" x 5" x 16"
Item Weight	6.78 pounds
Voltage	110 Volts



Figure 7.1: Product Dimensions.

Federal law prohibits removal of this label before consumer purchase.

ENERGY GUIDE

Television

VARIETY PRODUCTS
Model 100012590

Estimated Yearly Energy Cost

\$5

Cost Range of Similar Models (24" – 29")

\$7
—
—
—
\$4

- Based on 12 cents per kWh and 5 hours use per day
- Estimated yearly electricity use of this model: 39 kWh
- Your cost depends on your utility rates and use.

Visit ftc.gov/energy

8. WARRANTY AND SUPPORT

This product is offered as an Amazon Renewed item. As such, it has been professionally inspected and tested to function and appear like new. If you are not satisfied with your purchase, renewed products are eligible for replacement or refund under the [Amazon Renewed Guarantee](#). Please refer to the Amazon Renewed Guarantee for specific terms and conditions regarding returns and replacements.

For further assistance or technical support, please refer to the contact information provided with your purchase or visit the official ONN support website.