Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CADA C81008W

CADA 359PC MICRO UZI Instruction Manual

Brand: CADA | **Model:** C81008W

1. Introduction

Thank you for choosing the CADA 359PC MICRO UZI building set. This manual provides essential information for assembling, operating, and maintaining your model. This set allows you to build a classic Micro UZI SMG replica styled military toy pistol using high-quality interlocking ABS plastic bricks and blocks.
The assembled model features a realistic design and functional elements, providing an engaging building and play experience.



Figure 1: CADA 359PC MICRO UZI building set and packaging.

This image displays the complete CADA 359PC MICRO UZI building set, including the assembled model and its retail packaging. The packaging highlights key features such as the piece count and recommended age.

2. Safety Information

WARNING: CHOKING HAZARD - SMALL PARTS MAY BE GENERATED.

This product contains many small parts and is not suitable for children under 8 years of age due to potential choking hazards. Adult supervision is recommended during assembly and play.

The assembled toy pistol fires plastic rod bullets at a low velocity. However, never aim at eyes or face. Use only the plastic rod bullets provided with this product. Do not modify the product or the bullets.

- Keep small parts away from young children and pets.
- Ensure all parts are securely connected during assembly to prevent detachment during play.
- Do not ingest any parts of the product.
- Dispose of packaging materials properly.

3. Package Contents

Please verify that all components are present in your package before beginning assembly:

- Approximately 359 quality interlocking ABS plastic bricks and blocks.
- 6 plastic bullet rods.
- Detailed step-by-step easy-to-follow picture instructions manual.
- Retail picture box.

If any parts are missing or damaged, please contact customer support for assistance.

4. Setup and Assembly

The CADA 359PC MICRO UZI is a building set designed for self-assembly. Follow the included detailed picture instructions carefully to construct your model.

1. **Unpack:** Carefully remove all components from the retail box.
2. **Organize:** Sort the building blocks by type or color as suggested in the instruction manual to facilitate assembly.
3. **Follow Instructions:** Refer to the step-by-step picture instructions provided. Each step illustrates the specific blocks required and their placement.
4. **Secure Connections:** Ensure that all bricks are firmly pressed together to create stable connections. Cada bricks are made from quality ABS plastic with smooth edges and are burr-free, ensuring a precise fit.
5. **Verify Assembly:** After completing each major section, compare your build with the illustrations in the manual to ensure accuracy.

Construction bricks and play building blocks stimulate imagination and enhance brain development. Take your time and enjoy the building process.



Figure 2: Assembled CADA 359PC MICRO UZI toy pistol.

This image shows the fully assembled CADA 359PC MICRO UZI toy pistol from a side view, highlighting its detailed construction and realistic appearance.

5. Operating Instructions

Once assembled, your CADA Micro UZI model features a working trigger and firing mechanism. It is designed to fire the included plastic rod bullets.

1. **Load Bullets:** The bullet clip can be disassembled and accommodates the plastic bullet rods. Insert the 6 plastic bullet rods into the designated loading position, typically within the magazine or firing mechanism.
2. **Prepare for Firing:** Ensure the firing mechanism is in the ready position. The gun has multiple movable parts for play, including an upper movable part for height reduction and simulation functions.
3. **Launch Function:** To launch a bullet, pull the trigger. The firing mechanism will propel the plastic rod bullet.

The toy block gun has a length of 23.2cm when assembled and can fire plastic rod toy bullets with a range of up to 3 metres. Always ensure a clear firing path and never aim at people or animals.

6. Maintenance

To ensure the longevity and proper function of your CADA Micro UZI model, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the model with a soft, dry cloth to remove dust. For stubborn dirt, a slightly damp cloth can be used,

but avoid excessive moisture. Do not use harsh chemicals or abrasive cleaners.

- **Storage:** Store the model in a cool, dry place away from direct sunlight and extreme temperatures. This will help prevent discoloration and deformation of the plastic bricks.
- **Handling:** Handle the model with care, especially the movable parts and firing mechanism, to prevent damage.
- **Part Integrity:** Periodically check for any loose or damaged bricks. Re-attach or replace as necessary to maintain the model's structural integrity.

7. Troubleshooting

If you encounter any issues with your CADA Micro UZI model, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Firing mechanism not working.	Incorrect assembly of internal components; obstruction in the firing path; damaged part.	Review the assembly instructions for the firing mechanism. Ensure no blocks are obstructing the path of the bullet. Check for any broken or bent parts.
Bullets do not launch or launch weakly.	Bullets not loaded correctly; mechanism not fully engaged; worn parts.	Ensure bullets are fully inserted into the loading position. Confirm the trigger is pulled completely. If parts are worn, contact support.
Model feels unstable or parts fall off.	Bricks not fully connected; incorrect brick placement.	Press all bricks firmly together to ensure a secure connection. Refer to the instruction manual to verify correct brick placement.

If the problem persists after attempting these solutions, please refer to the "Warranty and Support" section for further assistance.

8. Specifications

Feature	Detail
Model Number	C81008W
Brand	CADA
Number of Pieces	359
Material	ABS Plastic
Assembled Product Length	Approximately 23.2 cm
Bullet Type	Plastic Rod Bullets (6 included)
Maximum Bullet Range	Up to 3 metres
Recommended Age	8 years and up
Item Dimensions (Box) L x W x H	35 x 24.5 x 6 centimetres

9. Warranty and Support

Information regarding specific warranty terms or spare part availability for the CADA 359PC MICRO UZI is not provided in

the product details. For any inquiries regarding product support, missing parts, or operational issues not covered in this manual, please contact the retailer or the manufacturer directly.
Manufacturer: DOUBLE EAGLE INDUSTRY (CHINA) LIMITED
Please retain your proof of purchase for any support inquiries.

© 2024 CADA. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B8H6P6GT

More documents and user manuals: **https://manuals.plus/**