

[Manuals.plus](#) /

› [Caffitaly](#) /

› Caffitaly System Volta S35 Coffee Machine User Manual

Caffitaly S35R

Caffitaly System Volta S35 Coffee Machine

USER MANUAL



Product Overview

The Caffitaly System Volta S35 is a compact, fast, and quiet multi-beverage coffee machine designed for use with original Caffitaly capsules. It features an integrated system that combines advanced technology with high-quality coffee preparation, ensuring an optimal taste experience with every cup. The machine includes automatic dosing, quick ignition, and an auto-cleaning suggestion function.



Image: The Caffitaly Volta S35 coffee machine in black, actively dispensing espresso into a clear glass cup. The machine's sleek design and compact footprint are visible.

Safety Warnings


Please read all instructions carefully to avoid risks of injury and damage to the appliance. This appliance is intended for domestic use only. Do not use in areas such as kitchens in shops, offices, hotels, motels, B&Bs, or other residential environments. Any use other than that specified in these instructions may cause damage to the person and/or the machine itself and will void the warranty. The manufacturer is not responsible for damages caused by improper use of the appliance.

- After unpacking, ensure the integrity of the appliance. In case of damage, or at the first sign of defects (noises or unusual odors), or for any problem found inside the appliance, do not use it and contact an Authorized Service Center.
- Keep all packaging materials (plastic bags, etc.) out of reach of children as they are potential sources of danger.
- Do not use the appliance if the power cord is damaged. For replacement, contact an Authorized Service Center. Risk of fatal electric shock.

- Store the appliance in dry indoor locations. Ensure that electrical components are not wet. Never immerse the appliance. Protect the appliance from splashes and humidity. Electricity and water together pose a risk of fatal electric shock.
- Connect the appliance only to a properly grounded power outlet. Ensure that the mains voltage corresponds to the voltage indicated on the appliance's bottom label.
- The surface on which the machine is installed must be level, stable, firm, and resistant to heat. The appliance should not be tilted more than 12°.
- This appliance can be used by children aged 8 years and above, and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance.
- Do not leave the power cord hanging over sharp edges, corners, or hot surfaces.
- Keep hands away from the capsule insertion opening. Risk of injury.
- Always remove the plug from the power outlet before cleaning.
- Do not insert any objects into the openings. This could cause electric shock. Any intervention not described in these instructions must only be performed by an Authorized Service Center!
- Do not unplug the appliance by pulling the cord; always grasp the plug to avoid damage.
- Proceed with descaling at regular intervals, as indicated in the instructions. Failure to do so could damage the appliance.
- Always unplug and regularly clean the appliance. If the appliance is stored for a long period, unplug it and clean it thoroughly before storage.
- Do not use the appliance for long periods (vacations, etc.) without unplugging it from the power outlet.

COME ATTIVARE LA MACCHINA AL PRIMO UTILIZZO O DOPO UN LUNGO PERIODO DI INUTILIZZO

UTILIZZARE ESCLUSIVAMENTE LE “CAPSULE ORIGINALI CAFFITALY SYSTEM”



- 1**
- Riempire il serbatoio con acqua fresca non gasata (Fig.1).
 - Inserire la spina nella presa di corrente. L'apparecchio si accende.
 - Assieme ai tasti A-B-C, lampeggia alternativamente in ROSSO anche la spia D (Fig.2).



- 2**
- Posizionare un contenitore capiente (almeno 250ml) sotto all'erogatore, rimuovendo prima la vaschetta raccogli gocce se necessario (Fig.3).
 - Premere uno dei tasti A-B-C. Attendere che la macchina termini il ciclo di caricamento del circuito idraulico. La spia D si spegne.

NOTA BENE: nel caso in cui al termine del caricamento, i tasti A-B-C e la spia D continuino a lampeggiare, ripetere le operazioni del punto precedente.



- 3**
- I tasti A-B-C lampeggiano contemporaneamente; la macchina é in fase di riscaldamento.
 - Quando i tasti A-B-C si accendono in modo fisso, l'apparecchio é pronto per l'utilizzo.

Image: A page from the instruction manual showing safety warnings and initial setup steps, originally in Italian. This diagram illustrates the process of preparing the machine for first use.

Setup and First Use

Follow these steps to activate your Caffitaly Volta S35 machine for the first time or after a long period of inactivity. Remember to use only original Caffitaly System capsules.

1. **Fill Water Tank:** Fill the water tank with fresh, non-carbonated water.
2. **Power On:** Insert the plug into the power outlet. The appliance will turn on.
3. **Indicator Lights:** Along with buttons A-B-C, indicator D will also flash RED alternately.
4. **Place Container:** Position a large container (at least 250ml) under the dispenser. Remove the drip tray first if necessary.
5. **Start Loading Cycle:** Press one of the A-B-C buttons. Wait for the machine to complete the hydraulic circuit loading cycle. Indicator D will turn off.

Note: If, after loading, buttons A-B-C and indicator D continue to flash, repeat the previous steps.

6. **Heating Up:** Buttons A-B-C will flash simultaneously; this indicates the machine is heating up.
7. **Ready for Use:** When buttons A-B-C light up steadily, the appliance is ready for use.



Image: A side view of the Caffitaly Volta S35 coffee machine, highlighting the transparent water tank at the back, which needs to be filled for operation.

Operating Instructions

The Caffitaly Volta S35 machine is designed for ease of use with its automatic capsule recognition and multi-beverage system. It ensures an ideal dosage and brewing method for each type of blend or beverage.

Brewing a Beverage:

1. Ensure the machine is powered on and has completed its heating cycle (buttons A-B-C are steadily lit).
2. Lift the lever to open the capsule compartment.
3. Insert an original Caffitaly capsule into the compartment. Each capsule contains 8 grams of blend, the ideal dose for an authentic Italian espresso.

4. Close the lever firmly.
5. Place your cup on the drip tray under the dispenser.
6. The machine will automatically recognize the capsule and suggest the appropriate dispensing mode and dosage. Press the corresponding button (e.g., for espresso, long coffee, tea, or infusions).
7. The machine will begin the brewing process, utilizing its double infusion system:
 - **Pre-infusion:** Prepares the ground coffee in the capsule by uniformly wetting it.
 - **Pressure Infusion:** Completes the operation, resulting in coffee with a high and thick crema.
8. Once the brewing is complete, the machine will stop automatically.
9. Lift the lever to eject the used capsule into the internal collection bin.

Italiano



Avvertenze di sicurezza

Leggere con **ATTENZIONE** le seguenti istruzioni!
Eviterete così i rischi di infortuni e danni all'apparecchio.

- Questo apparecchio è destinato ad essere utilizzato in applicazioni domestiche e similari. Non è ammesso l'utilizzo nelle seguenti aree: aree cucina per il personale di negozi, uffici e altri ambienti di lavoro, in alberghi, agriturismo, motel, Bed & Breakfast e altri ambienti di tipo residenziale.
- Qualsiasi altro utilizzo non previsto da queste istruzioni può essere causa di danni a persone e/o cose oltreché alla macchina stessa e fa decadere la garanzia. Il costruttore non risponde per danni derivanti da un uso improprio dell'apparecchio.
- Dopo aver tolto l'imballaggio, assicuratevi dell'integrità dell'apparecchio. In caso di presenza di danni, o al primo segnale di difettosità (rumori o odori insoliti), o per qualsiasi problema riscontrato all'interno dell'apparecchio, non utilizzarlo e rivolgersi ad un Centro Assistenza Autorizzato.
- Gli elementi dell'imballaggio (sacchetti in plastica, ecc.) non devono essere lasciati alla portata dei bambini in quanto potenziali fonti di pericolo.
- Utilizzare l'apparecchio solo se il cavo di alimentazione è intatto. Per la sostituzione del cavo, se danneggiato, rivolgersi esclusivamente ad un Centro Assistenza Autorizzato. Pericolo di morte per scosse elettriche.
- Conservare ed utilizzare l'apparecchio solo in locali interni. Assicurarsi che gli elementi elettrici, spine e cavi siano asciutti. Mai immergere l'apparecchio. Proteggere l'apparecchio da schizzi o gocciolamenti. Elettricità e acqua insieme provocano pericolo di morte per scariche elettriche.
- Collegare l'apparecchio solo a prese di corrente a norma di legge. Assicurarsi che la tensione della rete elettrica corrisponda a quella indicata nella targhetta dati situata sul fondo dell'apparecchio.
- Il piano sul quale viene installata la macchina deve essere livellato, solido, fermo e resistente al calore; il piano d'appoggio non deve superare i 2° d'inclinazione.
- Non consentire l'uso dell'apparecchio a bambini (anche di età superiore agli 8 anni), a persone con ridotte capacità psico-fisico-sensoriali, o con esperienza e conoscenze insufficienti, a meno che non siano attentamente sorvegliate e istruite da una persona responsabile della loro incolumità. Sorvegliare i bambini, assicurandosi che non giochino con l'apparecchio!
- Non lasciare il cavo di alimentazione vicino a superfici calde, a spigoli o oggetti taglienti.
- Mai mettere le mani dentro il vano portacapsule. Pericolo di lesioni.
- Richiudere sempre la leva. Mai aprire la leva durante l'erogazione di un prodotto.
- Mai rimuovere parti della macchina, salvo quelle indicate per la pulizia giornaliera.
- Non inserire alcun oggetto nelle aperture. Questo potrebbe causare scosse elettriche! Qualsiasi intervento non illustrato in queste istruzioni deve essere eseguito solo da un Centro Assistenza Autorizzato!
- Non staccare il cavo di alimentazione tirandolo, ma estrarlo impugnando la spina per evitare di danneggiarlo.
- Procedere con la decalcificazione ad intervalli regolari, come indicato dalle istruzioni. In caso contrario l'apparecchio potrebbe danneggiarsi.
- Pulire scrupolosamente e regolarmente l'apparecchio. Il deposito che si crea in caso di mancata pulizia, potrebbe essere dannoso per la salute. Scollegare l'apparecchio e lasciarlo raffreddare prima di procedere alla pulizia.
- Nel caso si preveda di non utilizzare l'apparecchio per lunghi periodi (vacanze, ecc.), scollegare la spina dalla presa elettrica.

9

Image: A close-up view of the top panel of the Caffitaly Volta S35, showing the three illuminated beverage selection buttons and the 'CLEAN' indicator.

Maintenance and Cleaning

Regular maintenance ensures the longevity and optimal performance of your Caffitaly Volta S35 coffee machine. The machine is designed with a 'clean' function to simplify maintenance.

Daily Cleaning:

- **Drip Tray:** Empty and clean the drip tray regularly, especially after each use or when it's full. Wash it with warm, soapy water and rinse thoroughly.
- **Used Capsule Container:** Empty the used capsule container when full. Wash it with warm, soapy water and rinse.
- **Water Tank:** Rinse the water tank daily and refill with fresh water. Clean it thoroughly with warm, soapy water once a week to prevent mineral buildup.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

'Clean' Function:

The S35 machine recognizes original Caffitaly capsules and, thanks to its 'clean' function, suggests a washing cycle after dispensing beverages other than coffee. This helps maintain optimal taste and hygiene.

- When the 'CLEAN' indicator lights up, it suggests a cleaning cycle.
- Place a large empty container under the dispenser.
- Press the 'CLEAN' button (often indicated by a cup with steam icon). The machine will perform a rinsing cycle.
- Discard the water collected in the container.

Descaling:

Regular descaling is crucial to prevent limescale buildup, which can affect machine performance and beverage quality. The frequency depends on water hardness and usage. Refer to the full manual for specific descaling instructions and recommended descaling solutions.

Troubleshooting

If you encounter issues with your Caffitaly Volta S35, refer to the common problems and solutions below. If the problem persists, contact an authorized service center.

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply; power cord damaged.	Check if the plug is properly inserted into a working outlet. Ensure the power cord is not damaged. If damaged, contact service.
No coffee is dispensed or only a few drops.	Water tank empty; machine not primed; clogged dispenser; machine needs descaling.	Fill the water tank. Perform the initial setup/priming cycle. Clean the dispenser outlet. Perform a descaling cycle.
Water leaks from the machine.	Water tank not properly seated; drip tray full; internal leak.	Ensure the water tank is correctly positioned. Empty the drip tray. If leaking persists, contact service.
Coffee is not hot enough.	Machine not fully heated; cups are cold; machine needs descaling.	Wait for the machine to fully heat up (steady lights). Preheat cups with hot water. Perform a descaling cycle.
Used capsules are not ejected.	Lever not fully lifted; capsule jammed.	Lift the lever completely and firmly. If a capsule is jammed, carefully remove it after unplugging the machine.

Specifications

Feature	Detail
---------	--------

Feature	Detail
Brand	Caffitaly
Model Number	S35R
Color	Black
Product Dimensions (L x W x H)	37 x 11 x 23.5 cm
Weight	8 Grams
Power	1450 Watts
Voltage	240 Volts
Material	Stainless Steel
Auto Shut-off Function	Yes (after 10 minutes of inactivity)
Energy Class	A+
Special Feature	Automatic Stop, Quick Ignition (24 seconds)
Coffee Maker Type	Espresso Machine
Filter Type	Filterless (Capsule System)
Specific Uses	Espresso, Long Coffee, Tea, Infusions

Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. Caffitaly System products are designed for durability and performance.

If you require technical assistance, spare parts, or have questions not covered in this manual, please contact Caffitaly customer support or an authorized service center. Information regarding spare parts availability is not provided in this manual.

For more information, visit the official Caffitaly website or refer to the contact details provided in your product packaging.