

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GoSports](#) /
- › [GoSports Golf Simulator Impact Screen 9 ft x 7 ft Instruction Manual](#)

GoSports GOLF-SIMSCREEN-ELITE-10x7

GoSports Golf Simulator Impact Screen

Model: GOLF-SIMSCREEN-ELITE-10x7 (9 ft x 7 ft)

Brand: GoSports

1. INTRODUCTION AND OVERVIEW

The GoSports Golf Simulator Impact Screen is designed to enhance your indoor or outdoor golf simulation experience. Made from high-density woven polyester, this screen provides a durable and high-definition projection surface compatible with real golf balls. It is specifically sized to fit the GoSports 10 x 7 ft ELITE Golf Net, offering a seamless setup for golf enthusiasts.

9 FT GOLF PROJECTOR SCREEN

SET UP YOUR OWN HOME GOLF SIMULATOR BAY!



SIZED TO FIT GOSPORTS® 10 X 7 FT ELITE GOLF NET

Image: GoSports Golf Simulator Impact Screen (9 ft x 7 ft) set up with a golfer preparing to hit a ball, displaying a virtual golf course scene.

2. PRODUCT FEATURES

- **Dimensions:** 108 x 82.5 inches (9 ft x 7 ft) impact screen.
- **Material:** High-density woven polyester for durability.
- **Compatibility:** Designed for use with golf simulators and projectors (not included). Sized to fit GoSports 10 x 7 ft ELITE Golf Net.
- **Mounting:** Features 4 grommets at each corner for hanging or mounting. Seamlessly connects to the GoSports ELITE Golf Hitting Net (sold separately).
- **Image Quality:** Provides a high-detail projector backdrop for clear visuals.
- **Versatility:** Can also be used for home movie nights, indoors or outdoors.

**Premium Polyester
for an HD Picture**




Image: Detailed diagram illustrating the physical dimensions of the impact screen, including overall height and width, and the active display area.

3. SETUP INSTRUCTIONS

1. **Unpack the Screen:** Carefully remove the impact screen from its packaging. Note that the screen may have creases due to folding.
2. **Prepare the Mounting Area:** Ensure your chosen mounting area (e.g., a frame, wall, or GoSports ELITE Golf Net) is clear and stable.
3. **Attach the Screen:**
 - **Using Grommets:** The screen features 4 grommets at each corner. Use the included shock cords or other suitable fasteners (bungees, hooks, ropes) to secure the screen to your frame or mounting

points.

- **With GoSports ELITE Golf Net:** If using with the GoSports ELITE Golf Net, align the screen with the net's frame. The screen is designed to seamlessly connect using its proprietary quick-connect design, often involving Velcro strips along the top edge and grommets for additional securing.
4. **Ensure Proper Tension:** Stretch the screen taut to minimize wrinkles and provide a flat surface for optimal projection and ball impact. You may need to adjust the tension at various points. Placing weights along the bottom edge can help keep the screen flat and prevent balls from rolling underneath.
 5. **Remove Creases (Optional):** For a smoother projection surface, gently steam the screen with a low-temperature hand steamer to remove any remaining creases. Alternatively, hitting golf balls into the screen over time can also help reduce creases.



Image: A close-up view of a reinforced grommet on the screen, demonstrating how it can be used for secure attachment.

COMPATIBLE WITH GOSPORTS® 10' x 7' ELITE GOLF NET

WITH PROPRIETARY QUICK-CONNECT DESIGN



Image: The impact screen seamlessly integrated with a GoSports ELITE Golf Hitting Net, showcasing a complete simulator setup.

Setup Demonstration Video

Your browser does not support the video tag.

Video: A seller demonstrates the installation process of a golf simulator impact screen, highlighting the ease of setup and secure attachment points.

Your browser does not support the video tag.

Video: A short demonstration by a seller showing the installation and initial use of an indoor golf simulator impact screen.

Your browser does not support the video tag.

Video: A seller's detailed video showcasing the unboxing, features, installation, and practical use of a premium golf simulator impact screen.

Your browser does not support the video tag.

Video: A seller demonstrates the screen as an 'awesome addition' to a GoSports practice net, showing its installation and use in a home golf setup.

4. OPERATING INSTRUCTIONS

1. **Projector Placement:** Position your projector at a suitable distance to fill the screen area. Ensure a minimum distance of 5 feet from the screen to the hitting surface for safety and optimal projection.
2. **Simulator Software:** Connect your golf simulator launch monitor and software to the projector. Adjust the software settings to match the screen's aspect ratio for a full and undistorted image.
3. **Hitting Area:** Place your hitting mat at the recommended distance from the screen.
4. **Enjoy Your Game:** Begin your golf simulation session. The screen is designed to withstand impacts from real golf balls, providing a realistic and immersive experience.
5. **Movie Nights:** For movie nights, simply connect your media device to the projector and enjoy your favorite content on the large, high-definition screen.

HD QUALITY SCREEN

REINFORCED FOR USE WITH REAL GOLF BALLS



Image: A close-up of the screen's material, emphasizing its HD quality and reinforced construction for durability.

5. MAINTENANCE

- **Cleaning:** Light stains can be gently brushed off. For tougher stains, use a mild soap and water solution with a soft cloth. Avoid harsh chemicals or abrasive cleaners.
- **Ball Cleanliness:** Keep your golf balls clean to prevent dirt and marks from transferring to the screen.
- **Storage:** When not in use for extended periods, it is recommended to carefully fold or roll the screen and store it in a dry, cool place to prevent damage and prolong its lifespan.
- **Crease Management:** If creases appear, gentle steaming can help smooth them out.

6. TROUBLESHOOTING

- **Wrinkles/Creases:** If the screen appears wrinkled, ensure it is stretched taut during installation. Gentle steaming can also help. Over time, repeated impacts can also help flatten the screen.
- **Poor Image Quality:** Ensure your projector is correctly aligned and focused. Check the projector's resolution and aspect ratio settings to match the screen. Ensure the screen is uniformly taut.
- **Ball Rebound:** If balls are rebounding excessively, ensure the screen is properly tensioned and has some give. Adding weights or securing the bottom edge can help absorb impact and prevent balls from rolling underneath.
- **Screen Damage:** While durable, continuous impact in the exact same spot or with damaged balls can cause wear. Inspect the screen periodically for any signs of damage.

Screen Durability and Potential Wear Video

Your browser does not support the video tag.

Video: A seller's video highlighting a tear in the screen, providing insight into potential wear and tear over time with heavy use.

7. SPECIFICATIONS

| Feature | Detail |
|---------------------|--|
| Model Name | Golf Simulator Impact Screens |
| Part Number | GOLF-SIMSCREEN-ELITE-10x7 |
| Style | 9 ft x 7 ft |
| Display Dimensions | 108 inches x 82.5 Inches |
| Product Dimensions | 114"W x 92"H |
| Material | Polyester |
| Color | White |
| Item Weight | 9.9 Pounds |
| Mounting Type | Wall Mount |
| Included Components | (1) Golf Projector Screen, (4) Shock Cords |

8. WARRANTY INFORMATION

P&P IMPORTS, LLC warrants its Products to be free from defects in material and workmanship for a period of six (6) months from the date of delivery to the consumer. Please retain your original delivery receipt, as it will be required for any warranty claim. This warranty is not transferable and does not apply to merchandise purchased "as is" (e.g., floor samples or clearance center items). This warranty does not apply to P&P IMPORTS, LLC goods purchased from a non-authorized P&P IMPORTS, LLC dealer or reseller. Please follow all instructions regarding your Product, as failure to do so will void this warranty.

All claims must be directed to the P&P IMPORTS, LLC retail dealer from whom the merchandise was originally purchased, along with the original delivery receipt.

9. CUSTOMER SUPPORT

For further assistance, questions, or to make a warranty claim, please contact the GoSports customer support team or the retail dealer from whom you purchased the product. Ensure you have your original delivery receipt and product model information readily available.

Visit the [GoSports Store](#) for more information and products.