Ebarsenc B0B8MCW1MQ

Ebarsenc 4K UHD WiFi Mini Spy Camera User Manual

Model: B0B8MCW1MQ
Brand: Ebarsenc

1. Introduction

Thank you for choosing the Ebarsenc 4K UHD WiFi Mini Spy Camera. This compact and versatile device is designed to provide reliable surveillance for your home, office, or any indoor space. With its high-definition video, wide-angle view, night vision, and motion detection capabilities, it helps you monitor your surroundings and ensure safety. Please read this manual carefully to understand the product's features and ensure proper operation.

2. Package Contents

Please verify that all items are present in your package:

- Ebarsenc 4K UHD WiFi Mini Spy Camera
- USB Charging Cable
- Mounting Bracket
- User Manual
- Adhesive Pads (2)

Image: Contents of the Ebarsenc Mini Spy Camera package, showing the camera, charging cable, user manual, and mounting accessories.

3. Setup Guide

3.1. Charging the Camera

Before first use, fully charge the camera. Connect the camera to a 5V 1A USB power adapter (not included) using the provided USB charging cable. A full charge typically takes a few hours. The camera features a 1400 mAh rechargeable battery, offering 8-10 hours of standby time.

Image: Illustration of the camera's internal battery and its long-lasting power, highlighting the 1400 mAh capacity and up to 8 hours of operation on a full charge.

3.2. App Installation

Download the "HIDVCAM" app from your smartphone's app store (compatible with Android and iOS devices). This app is essential for controlling the camera, viewing live feeds, and accessing recorded footage.

3.3. Wi-Fi Connection

The camera supports 2.4Ghz Wi-Fi networks only. 5G Wi-Fi is not supported.

1. **Step 1: Turn on the Camera.** Power on the camera using its power button.
2. **Step 2: Connect to Camera's Hotspot.** On your smartphone, go to Wi-Fi settings and connect to the camera's unique Wi-Fi hotspot (usually starts with "HIDVCAM-").
3. **Step 3: Connect Camera to Home Wi-Fi.** Open the HIDVCAM app. Follow the in-app instructions to connect the camera to your home's 2.4Ghz Wi-Fi network.

Image: Visual guide for the simple Wi-Fi connection process, illustrating the three steps from camera power-on to connecting to your home network via the app.

3.4. SD Card Insertion

Insert a MicroSD card (up to 256GB, not included) into the camera's slot for local video storage. Format the SD card through the HIDVCAM app for optimal performance.

4. Operating Instructions

4.1. Live View

Once connected to Wi-Fi, open the HIDVCAM app to access the live video feed from your camera. You can view the scene in real-time from anywhere with an internet connection.

Image: The compact Ebarsenc Mini Spy Camera held in a hand, with a smartphone screen showing the live video feed from the camera, demonstrating its discreet monitoring capability.

4.2. Video Recording

The camera records in 4K UHD resolution. The default real-time video mode is FHD (1080P); you may need to manually switch to UHD (4K) mode within the app to view video in 4K quality. The camera supports loop recording, automatically overwriting the oldest files when the SD card is full.

Image: A visual comparison demonstrating the superior clarity of 4K UHD video captured by the Ebarsenc camera compared to 1080P, as seen on a smartphone display.

4.3. Night Vision

Equipped with 6 invisible 940nm infrared lights and an IR-CUT dual filter, the camera provides clear night vision up to 30 feet without color distortion. It automatically switches between day and night modes based on ambient light.

Image: A split image illustrating the camera's enhanced 4K UHD night vision, showing a clear view of a sleeping baby in both bright (day) and dark (night) conditions.

4.4. Motion Detection

The camera utilizes advanced motion detection technology. When movement is detected in the monitored area, the camera automatically records a short video and sends an instant alert message to your smartphone.

Image: A smartphone screen showing a "Motion Detection" alert from the camera, with a dog and cat near a refrigerator, demonstrating the camera's ability to detect and notify users of activity.

4.5. Multi-Camera & Multi-User Viewing

The HIDVCAM app allows you to view up to 4 scenes simultaneously from different Ebarsenc spy cameras. You can also share camera access with multiple users, making it ideal for family monitoring.

Image: An illustration of the easy connection process and the app's capability to display multiple camera feeds simultaneously, allowing comprehensive monitoring of different areas.

4.6. Placement and Mounting

The camera's compact size (3.55 cm) allows for discreet placement. It can be easily hidden in drawers, on bookshelves, or within closets. The included mounting bracket allows for installation on walls, balconies, or porches, with adjustable rotation for various viewing angles.

Image: Examples of how the camera can be discreetly hidden in various spots within a room, such as behind objects or on shelves, to expand the field of view without being noticed.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid extreme temperatures and do not leave the camera fully discharged for extended periods. Charge regularly.
- **Storage:** When not in use for a long time, store the camera in a cool, dry place.

6. Troubleshooting

- **Camera Offline:** If the camera goes offline, check your 2.4Ghz Wi-Fi connection. Ensure the camera is within range of your router. Try restarting the camera and your router.
- **Poor Video Quality:** Ensure you have manually switched to 4K UHD mode in the app if you desire the highest resolution. Check your network speed, as a slow connection can affect live view quality.
- **Motion Detection Not Working:** Verify that motion detection is enabled in the app settings. Ensure the camera's view is clear and not obstructed.
- **Battery Drains Quickly:** Ensure the camera is fully charged. Continuous recording or frequent motion detection events can consume more power. Consider plugging the camera into a power source for 24/7 operation.
- **Cannot Connect to Wi-Fi:** Double-check that you are connecting to a 2.4Ghz Wi-Fi network. Ensure the Wi-Fi password is correct. Try resetting the camera to factory settings and re-attempting the setup process.

7. Specifications

Feature	Specification
Video Resolution	4K UHD
Lens Angle	160° Wide-angle
Battery Capacity	1400 mAh
Standby Time	8-10 hours
Night Vision Range	Up to 30 feet (940nm IR lights)
Wi-Fi Connectivity	2.4Ghz (IEEE 802.11b/g/n)
Storage	MicroSD card (up to 256GB, not included)
Power Input	5V 1A (USB)
Dimensions	Approx. 3.55 cm (cube)
Weight	180 g
Color	Black
Recommended Use	Baby monitor, Home security
Installation Type	Surface-Mounted

8. Warranty and Support

Ebarsenc is committed to customer satisfaction. Your product comes with the following:

- **1-Year Free Exchange and Refund:** If you encounter any issues within one year of purchase, you are eligible for a free exchange or refund.
- **Lifetime After-Sales Service:** Ebarsenc provides lifetime technical support and customer service for your product.

For any inquiries or support needs, please contact Ebarsenc customer service through the platform where you purchased the product.

Image: A badge indicating 100% Satisfaction Guarantee, symbolizing the product's warranty and support.

© 2023 Ebarsenc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question