

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [YUSONIC](#) /

› YUSONIC Cat Ear Bluetooth Headphones STN-26 User Manual

YUSONIC STN-26

YUSONIC Cat Ear Bluetooth Headphones STN-26 User Manual

INTRODUCTION

This manual provides detailed instructions for the YUSONIC Cat Ear Bluetooth Headphones, Model STN-26. Please read this manual thoroughly before using the product to ensure proper operation and to maintain the device's longevity. Keep this manual for future reference.



Image: YUSONIC Cat Ear Bluetooth Headphones STN-26 with packaging.

PACKAGE CONTENTS

Verify that all items are present in the package:

- YUSONIC Cat Ear Bluetooth Headphones (STN-26)
- USB Charging Cable
- 3.5mm Audio Cable
- User Manual



Image: Front view of the YUSONIC Cat Ear Bluetooth Headphones STN-26.

Controls and Ports

The main controls are located on the earcup:

- **Power Button:** Used to power on/off the headphones.
- **Volume Up (+):** Short press for volume up, long press for next track. Double press to toggle LED lights.
- **Volume Down (-):** Short press for volume down, long press for previous track.
- **Multi-function Button:** Play/Pause, Answer/End calls.
- **3.5mm Audio Jack:** For wired connection.
- **USB Charging Port:** For charging the internal battery.
- **Microphone:** For hands-free calls.



SETUP

Charging the Headphones

1. Connect the USB charging cable to the charging port on the headphones.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging.
4. Charging typically takes approximately 1.5 hours. The indicator light will change or turn off once fully charged.

Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the Power Button until the LED indicator flashes, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "STN-26" from the list of found devices.
5. Once connected, the LED indicator will stop flashing or show a steady light, and a voice prompt may confirm the connection.
6. The headphones will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the Power Button for a few seconds until the indicator light turns on.
- **Power Off:** Press and hold the Power Button for a few seconds until the indicator light turns off.

Music Playback

- **Play/Pause:** Short press the Multi-function Button.
- **Next Track:** Long press the Volume Up (+) button.
- **Previous Track:** Long press the Volume Down (-) button.
- **Volume Up:** Short press the Volume Up (+) button.
- **Volume Down:** Short press the Volume Down (-) button.

Call Functions

- **Answer/End Call:** Short press the Multi-function Button.
- **Reject Call:** Long press the Multi-function Button.

LED Light Control

The cat ears and earcups feature LED lights that can blink and change color.

- **Toggle LED Lights:** Double press the Volume Up (+) button to turn the lights on or off. This feature helps conserve battery life when lights are not desired.



Image: Headphones with illuminated cat ears and earcups.

WIRED MODE

The headphones can be used in wired mode even if the battery is depleted.

1. Connect one end of the 3.5mm audio cable to the audio jack on the headphones.
2. Connect the other end of the 3.5mm audio cable to your audio source (e.g., smartphone, tablet, computer).
3. The headphones will function as standard wired headphones. Bluetooth features and LED lights will not operate in wired mode if the battery is off or depleted.

MAINTENANCE AND CARE

- Clean the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Do not immerse the headphones in water, as they are not water-resistant.
- Store the headphones in a cool, dry place. The foldable design allows for compact storage.



Image: Folded YUSONIC Cat Ear Bluetooth Headphones STN-26.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Headphones do not power on.	Ensure the headphones are charged. Connect to a power source using the USB cable.
Cannot pair with a device.	Ensure headphones are in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Move closer to the device.
No sound in Bluetooth mode.	Check device volume and headphone volume. Ensure headphones are correctly paired and selected as the audio output on your device.
LED lights are not working.	Double press the Volume Up (+) button to toggle the LED lights on. Ensure the battery is not critically low.
Sound quality is poor.	Ensure there are no obstructions between the headphones and the paired device. Move away from sources of interference. Try a different audio source.

SPECIFICATIONS

Feature	Detail
Model	STN-26
Bluetooth Version	5.3
Bluetooth Range	Up to 10 meters (33 feet)
Audio Driver Size	40 mm
Frequency Response	20 Hz - 20,000 Hz
Sensitivity	105 dB
Impedance	32 Ohm
Battery Life	Approximately 6 hours (with Bluetooth and LED lights on)
Charging Time	Approximately 1.5 hours
Connectivity	Wireless (Bluetooth), Wired (3.5mm audio jack)
Microphone	Built-in
Special Features	Foldable design, Cat ear LED lights, Sound Isolation
Material	Plastic
Dimensions	8.66 x 6.69 x 3.54 inches
Weight	250 grams (8.8 ounces)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact YUSONIC customer

service through the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B8N6G8PP>

More documents and user manuals: <https://manuals.plus/>