Rowenta RO6136EA

Rowenta RO6136 Green Force Max Silence Bagged Vacuum Cleaner

Model: RO6136EA

User Manual

1. Introduction

This manual provides essential information for the safe and efficient use of your Rowenta RO6136 Green Force Max Silence bagged vacuum cleaner. Please read these instructions carefully before using the appliance and keep them for future reference.



The Rowenta RO6136 Green Force Max Silence vacuum cleaner, showcasing its compact design and included accessories.

2. Setup

2.1 Unpacking and Component Check

Carefully remove all components from the packaging. Ensure all parts are present and undamaged. The package should contain:

- Main vacuum cleaner unit
- Flexible hose
- Telescopic tube
- Floor nozzle

- Crevice nozzle
- Upholstery nozzle
- One Hygiene+ dust bag (pre-installed or separate)

2.2 Assembly

1. Insert the flexible hose into the suction inlet on the main unit until it clicks into place.
2. Attach the telescopic tube to the handle of the flexible hose. Adjust the length of the telescopic tube to a comfortable height.
3. Connect the desired floor nozzle or accessory to the end of the telescopic tube.



The vacuum cleaner fully assembled and ready for use.

3. Operating Instructions

3.1 Powering On/Off

Plug the power cord into a suitable electrical outlet. Press the On/Off button located on the main unit to start or stop the vacuum cleaner.

3.2 Suction Power Adjustment

The vacuum cleaner features a rotary knob for adjusting suction power. Turn the knob to increase or decrease suction as needed for different surfaces.

3.3 Using Accessories

- **Floor Nozzle:** Use for general cleaning of hard floors and carpets.
- **Crevice Nozzle:** Ideal for reaching narrow spaces, corners, and edges.
- **Upholstery Nozzle:** Designed for cleaning furniture, curtains, and other fabric surfaces.

3.4 Key Features

The Rowenta RO6136 is designed for powerful and quiet cleaning:

- **Powerful Suction:** Equipped with a 900W motor for effective cleaning on all floor types.
- **Low Noise Level:** Operates at a quiet 65 dB(A), making cleaning less disruptive.
- **Large Action Radius:** A 12-meter operating radius allows for extensive cleaning without frequent unplugging.



Illustration of the powerful 900W motor and strong suction capability.

BESONDERS LEISE



The vacuum cleaner's exceptionally quiet operation, allowing for cleaning without disturbing others.



The extensive 12-meter action radius provides wide coverage for cleaning large areas.

3.5 Product Overview Video

Your browser does not support the video tag.

Watch this official video for a comprehensive overview of the Rowenta RO6136 Green Force Max Silence vacuum cleaner's features and benefits.

4. Maintenance

4.1 Dust Bag Replacement

The Hygiene+ dust bag system ensures hygienic disposal without contact with dust. Replace the dust bag when the indicator shows it is full or when suction power decreases significantly.

1. Open the dust bag compartment cover.
2. Carefully remove the full Hygiene+ dust bag by pulling the collar. The bag automatically seals to prevent dust

leakage.

3. Insert a new Hygiene+ dust bag, ensuring it is correctly seated in the holder.
4. Close the dust bag compartment cover securely.



The Hygiene+ dust bag system allows for clean and easy disposal of collected dust.

4.2 HEPA Filter Maintenance

The HEPA filter captures fine dust particles, ensuring high air quality. Regularly check and clean or replace the HEPA filter as per the instructions below to maintain optimal performance.

1. Locate the HEPA filter compartment, usually at the rear or side of the vacuum cleaner.
2. Remove the filter. Depending on the filter type, it may be washable or require replacement.
3. If washable, rinse under cold water and allow to air dry completely before reinserting. If not washable, replace with a new HEPA filter.
4. Ensure the filter is dry and correctly positioned before closing the compartment.



The advanced filtration system, including the Hygiene+ dust bag and HEPA filter, ensures 99.98% filtration of fine particles.

4.3 General Cleaning

Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the appliance is unplugged before cleaning.

5. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord not plugged in; no power at outlet; thermal cut-out activated.	Check power connection; test outlet; allow unit to cool down for 30 minutes.

Problem	Possible Cause	Solution
Low suction power	Dust bag full; filter clogged; hose/nozzle blocked.	Replace dust bag; clean/replace filter; check and clear blockages.
Unusual noise	Foreign object in brush/hose; motor issue.	Inspect and remove foreign objects; if noise persists, contact support.

If the problem persists after trying these solutions, please contact Rowenta customer support.

6. Specifications

- **Model Number:** RO6136EA
- **Power:** 900 W max
- **Dust Bag Capacity:** 4.5 liters
- **Filter Type:** HEPA Filter
- **Noise Level:** 65 dB(A)
- **Action Radius:** 12 meters
- **Product Dimensions:** 44.36 x 28.5 x 25.53 cm
- **Weight:** 4.7 Kilograms
- **Form Factor:** Upright
- **Included Components:** Crevice nozzle, Floor vacuum cleaner, Upholstery nozzle
- **Material:** Up to 70% recycled plastic

7. Warranty and Support

Rowenta is committed to the longevity of its products. This appliance is designed for repairability for up to 15 years, with access to 6200 recognized repair workshops worldwide.



Rowenta's commitment to 15-year repairability.

For further assistance, spare parts, or to locate a repair center, please visit the official Rowenta store or contact customer support:

Visit the Rowenta Store on Amazon

© 2024 Rowenta. All rights reserved.