

BLACK+DECKER BCKM101SP

BLACK+DECKER Kitchen Wand 2-in-1 Salt and Pepper Grinder Attachment (BCKM101SP) Instruction Manual

Model: BCKM101SP

INTRODUCTION

This manual provides instructions for the safe and efficient use of your BLACK+DECKER Kitchen Wand 2-in-1 Salt and Pepper Grinder Attachment. This attachment is designed to be used with the BLACK+DECKER Kitchen Wand system (wand base, charging dock, and cord sold separately). It features two spice containers for salt and pepper or other hard spices, allowing for quick switching between grinding options and adjustable coarseness.

IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using this attachment. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This attachment is intended for household use only.
- Ensure the Kitchen Wand base is fully charged and properly connected before attaching or detaching the grinder.
- Keep fingers and foreign objects away from the grinding mechanism during operation.
- Do not immerse the attachment in water or other liquids. Refer to the 'Maintenance and Cleaning' section for cleaning instructions.
- Do not attempt to grind substances other than dry spices as specified in this manual.
- Always place the protective cap on the attachment when not in use to prevent accidental activation and spillage.
- Keep out of reach of children.

PRODUCT OVERVIEW AND COMPONENTS

The BLACK+DECKER Kitchen Wand 2-in-1 Salt and Pepper Grinder Attachment is designed for convenience and versatility.

Included Components:

- 1 x BLACK+DECKER Kitchen Wand 2-in-1 Salt and Pepper Grinder Attachment
- 1 x Protective Lid

Note: The Kitchen Wand base, charging dock, and power cord are sold separately and are required for operation.



Image: The BLACK+DECKER Kitchen Wand 2-in-1 Salt and Pepper Grinder Attachment, showing its compact design.



Image: A detailed view of the grinder attachment, highlighting the two spice compartments and the collar.

SETUP

Follow these steps to prepare your grinder attachment for use:

1. **Attach to Kitchen Wand Base:** Align the grinder attachment with the BLACK+DECKER Kitchen Wand base (sold separately) and twist until it securely locks into place.
2. **Load Spices:** The attachment features two side doors for convenient loading. Open one door at a time and carefully pour your desired spice (e.g., salt crystals, peppercorns, fennel seeds, coriander seeds) into the compartment. Close the door securely. Repeat for the second compartment with a different spice if desired.



Image: A person demonstrating how to load spices into one of the side compartments of the grinder attachment.



Image: A person demonstrating the attachment of the grinder to the main Kitchen Wand unit.

OPERATING INSTRUCTIONS

Using the 2-in-1 Salt and Pepper Grinder Attachment is straightforward:

1. **Select Spice:** Rotate the collar located on the attachment to align with the desired spice compartment. You will feel a click when it's in position.
2. **Adjust Coarseness:** On the bottom of the attachment, locate the coarseness adjustment dial. Rotate the dial to select your preferred grind size, from fine to coarse.
3. **Grind Spices:** With the attachment securely connected to the Kitchen Wand base, press and hold the power button on the wand base to begin grinding. Release the button to stop.
4. **Prevent Spillage:** When not in use, place the protective lid onto the grinding end of the attachment to prevent any residual spice spillage onto your countertop.



Image: A hand rotating the collar on the grinder attachment to switch between spice compartments.




Image: The bottom of the grinder attachment, illustrating the dial for adjusting spice coarseness.



Image: A person holding the Kitchen Wand with the grinder attachment over a bowl of salad, demonstrating its use.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your grinder attachment.

- **Cleaning:** The grinder attachment should be hand washed only. Do not place it in a dishwasher. Use a damp cloth to wipe the exterior. For the grinding mechanism, a small brush can be used to remove spice residue.
- **Drying:** Ensure all parts are completely dry before reassembling or storing.
- **Storage:** Store the attachment in a clean, dry place. Always use the protective lid when storing to prevent dust accumulation and accidental spillage.



Image: The grinder attachment with its protective lid removed, showing the grinding outlet.

TROUBLESHOOTING

If you encounter issues with your grinder attachment, please refer to the following common solutions:

Problem	Possible Cause	Solution
Grinder does not operate.	Kitchen Wand base is not charged or not properly attached.	Ensure the Kitchen Wand base is fully charged. Verify the grinder attachment is securely locked onto the wand base.
Spices are not grinding or grinding slowly.	Spice compartments are empty or clogged.	Refill spice compartments. Clean the grinding mechanism to remove any blockages.
Inconsistent grind size.	Coarseness dial not set correctly.	Adjust the coarseness dial on the bottom of the attachment to your desired setting.
Spice leakage when not in use.	Protective lid not in place.	Always place the protective lid on the attachment when not in use.

If the problem persists after attempting these solutions, please contact BLACK+DECKER customer support.

SPECIFICATIONS

- **Brand:** BLACK+DECKER
- **Model Name:** BCKM101SP
- **Product Dimensions:** 9.57"D x 4.45"W x 3.27"H
- **Color:** Black
- **Special Feature:** Modular Kitchen Wand System, Adjustable Coarseness
- **Recommended Uses:** Kitchen (grinding salt, pepper, fennel seeds, coriander seeds, etc.)
- **Product Care Instructions:** Hand Wash
- **Power Source:** Battery Powered (via Kitchen Wand base, sold separately)
- **UPC:** 885911836210
- **ASIN:** B0B8QSFWT1

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your original purchase of the BLACK+DECKER Kitchen Wand system or visit the official BLACK+DECKER website. You can also contact their customer service directly for assistance with your BCKM101SP attachment.

Online Support: www.blackanddecker.com/support

© 2023 BLACK+DECKER. All rights reserved.