

## LAATOOREE LLH

# LAATOOREE Laundry Hamper User Manual

Brand: LAATOOREE | Model: LLH

## 1. INTRODUCTION

Thank you for choosing the LAATOOREE Laundry Hamper. This manual provides detailed instructions for assembly, operation, and maintenance to ensure you get the most out of your product. This two-compartment laundry basket features a versatile top shelf and removable bags, designed to simplify your laundry sorting and enhance your living space.

### Key Features:

- **Bicolor Top Storage Shelf:** Features a reversible rustic brown and black wood panel, offering extra storage space for various items.
- **2 Compartment Laundry Basket:** Equipped with two Oxford fabric bags for convenient sorting of laundry by color or type.
- **Pull-out & Removable Bags:** Bags slide out for easy transport to the laundry room and are removable for cleaning. Includes a bottom panel to prevent sagging.
- **Multipurpose Design:** Can be used as a laundry hamper, toy basket, or nightstand, suitable for laundry rooms, bedrooms, and bathrooms.
- **Sturdy & Stable Construction:** Built with a durable metal frame and high-quality particleboard for enhanced stability.



Figure 1.1: The LAATOOREE Laundry Hamper, showcasing its two compartments and top shelf.

## 2. PACKAGE CONTENTS

Please verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.



Figure 2.1: All components included in the package for assembly.

### List of Components:

- Metal Frame (various pieces for base, sides, and top support)
- Wooden Top Shelf Panels (2 pieces, reversible rustic brown/black)
- Removable Oxford Fabric Laundry Bags (2 pieces, with handles and bottom panels)
- Assembly Hardware (screws, bolts, Allen wrench)
- Adjustable Feet (pre-attached or separate for leveling)

### 3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your LAATOOREE Laundry Hamper. It is recommended to assemble on a soft, clean surface to prevent scratches.

1. **Step 1: Assemble the Base Frame.** Connect the horizontal metal bars to the vertical side frames using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten.
2. **Step 2: Attach Top Support Bars.** Secure the upper horizontal metal bars to the top of the vertical side frames. These bars will support the top shelf and the laundry bags.
3. **Step 3: Install Top Shelf Panels.** Place the two wooden panels onto the top frame. You can choose either the rustic brown or black side facing up. Secure them with the designated screws.
4. **Step 4: Insert Laundry Bags.** Slide each Oxford fabric laundry bag into its respective compartment within the frame. Ensure the handles are facing outwards for easy access. The bottom panel of each bag should rest securely.
5. **Step 5: Adjust Leveling Feet.** If your hamper has adjustable feet, turn them clockwise or counter-clockwise to level the unit on uneven floors.



Figure 3.1: Visual guide for assembling the metal frame and attaching the top shelf.




Figure 3.2: Detail of the adjustable leveling foot for stability.

## 4. OPERATING INSTRUCTIONS

The LAATOOREE Laundry Hamper is designed for ease of use in managing your laundry.

### **Sorting Laundry:**

Utilize the two separate compartments to sort your laundry. Common sorting methods include separating lights from darks, or delicates from regular items. This helps streamline your laundry process.

### **Removing and Transporting Bags:**

To remove a laundry bag, simply pull it forward from its compartment. The bags are designed to slide out smoothly. Use the integrated handles to carry the bag to your laundry area. When finished, slide the bag back into its designated slot.



Figure 4.1: Demonstrating the easy pull-out feature of the laundry bags.



Figure 4.2: The laundry bag fully removed from the hamper for convenient transport.

### Using the Top Shelf:

The top shelf provides additional storage or display space. It can hold folded towels, laundry detergents, decorative items, or serve as a temporary surface for various household necessities.



Figure 4.3: The hamper in a bathroom setting, illustrating the utility of the top shelf.

## 5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your laundry hamper.

### **Cleaning the Laundry Bags:**

The Oxford fabric laundry bags are removable and washable. It is recommended to hand wash or machine wash on a gentle cycle with cold water. Air dry the bags completely before reinserting them into the frame to prevent mildew.

### **Cleaning the Frame and Shelf:**

Wipe the metal frame and wooden top shelf with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish. Dry thoroughly after cleaning.

## 6. TROUBLESHOOTING

If you encounter any issues with your LAATOOREE Laundry Hamper, please refer to the following common solutions:

Problem	Possible Cause	Solution
Hamper is wobbly or uneven.	Uneven floor surface or loose connections.	Adjust the leveling feet at the bottom of the frame. Ensure all assembly screws are tightened securely.
Laundry bags do not slide smoothly.	Obstruction in the sliding mechanism or bent metal track.	Check for any items obstructing the bag's path. Gently inspect the metal tracks for any bends and carefully adjust them if necessary to allow smooth movement.
Top shelf panels are not flush.	Screws overtightened or misaligned during assembly.	Loosen the screws slightly, adjust the panels to be flush, then retighten carefully without overtightening.

## 7. PRODUCT SPECIFICATIONS

Attribute	Detail
Product Dimensions	28.4"L x 12.7"W x 28.7"H
Brand	LAATOOREE
Model Number	LLH
Color	Rustic Brown (with reversible black top shelf option)
Material	Engineered Wood, Metal, Oxford Fabric
Style	2bags-Rustic Brown
Special Features	Removable Liner, Washable Bags
Capacity	96 Liters (2 x 48L bags)
Item Weight	15.83 Pounds
Number of Compartments	2
Mounting Type	Floor Mount
Manufacturer	Linlai
Date First Available	September 21, 2022



Figure 7.1: Dimensional overview of the laundry hamper and its components.

## 8. WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty claims, please contact LAATOOREE customer service.

Refer to your purchase documentation for specific warranty terms and contact information.

You can also visit the official LAATOOREE store on Amazon for more information and support: [LAATOOREE Store](#)