Tefal FV8064

Tefal Puregliss FV8064 Steam Iron User Manual

Model: FV8064 | Brand: Tefal

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Tefal Puregliss FV8064 Steam Iron. Please read these instructions carefully before first use and keep them for future reference.



Image: The Tefal Puregliss FV8064 Steam Iron, showcasing its sleek black and gold design with the Durilium AirGlide Autoclean soleplate visible.

Safety Instructions

- Always ensure the voltage indicated on the iron's rating plate corresponds to your mains voltage.
- Do not leave the iron unattended when it is connected to the mains supply.
- Keep the iron and its cord out of reach of children when it is switched on or cooling down.
- Never immerse the iron, cord, or plug in water or any other liquid.
- Unplug the iron before filling with water, cleaning, or after each use.
- Do not operate the iron if it has been dropped, if there are visible signs of damage, or if it is leaking.
- Use the iron only for its intended purpose, which is ironing clothes.

Setup

1. Unpacking and Initial Inspection

Carefully remove the iron and all accessories from the packaging. Inspect the iron for any signs of damage. Retain the packaging for future storage or transport if needed.

2. Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Open the water tank inlet cover, usually located at the front of the handle.
3. Fill the water tank with tap water up to the 'MAX' level indicator. For optimal performance and to prolong the life of your iron, it is recommended to use demineralized or distilled water, especially in areas with hard water.
4. Close the water tank inlet cover securely.






Image: Front view of the Tefal Puregliss FV8064 Steam Iron, highlighting the water tank and filling port.

Operating Instructions

1. Powering On and Temperature Setting

- Place the iron on its heel rest on a stable, heat-resistant surface.
- Plug the power cord into a suitable electrical outlet. The iron will begin to heat up.
- The Tefal Puregliss FV8064 features an automatic temperature setting, eliminating the need for manual temperature adjustment for different fabric types. This ensures optimal heat for all ironable fabrics.

2. Steam Ironing

- Once the iron has reached its operating temperature (indicator light turns off), you can begin steam ironing.
- The iron provides a continuous steam output of up to 50 g/min, ideal for efficient wrinkle removal.

- For stubborn creases, press the steam boost button to activate an extra powerful shot of steam up to 280 g/min.



Image: The Tefal Puregliss FV8064 Steam Iron in action, showing steam being emitted from the soleplate, indicating its powerful steam capabilities.

3. Vertical Steaming

The vertical steam function is perfect for refreshing hanging garments, curtains, or delicate fabrics without direct contact. Hold the iron vertically a few centimeters away from the fabric and press the steam boost button intermittently.



Image: A person demonstrating the vertical steaming function of the Tefal Puregliss FV8064 Steam Iron on a hanging shirt, effectively removing wrinkles.

4. Dry Ironing

For dry ironing, ensure the steam control is set to the 'no steam' position. This is suitable for fabrics that do not require steam or for finishing touches.

5. Auto-Off Safety Feature

For enhanced safety, your iron is equipped with an auto-off feature. If left unattended on its heel rest, it will automatically switch off after a certain period. If left flat on the soleplate or on its side, it will switch off even faster. To restart, simply move the iron.

Maintenance

1. Cleaning the Soleplate

The Durilium AirGlide Autoclean soleplate is designed for excellent glide and scratch resistance. To clean it, allow the iron to cool

down completely. Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary. Do not use abrasive pads or metallic objects.



Image: A detailed view of the Durilium AirGlide Autoclean soleplate of the Tefal Puregliss FV8064, showing its smooth surface and steam holes.

2. Cleaning the Micro-Calc Filter

Your iron is equipped with a patented Micro-Calc filter system to prevent limescale stains. For optimal performance, clean the filter regularly:

1. Ensure the iron is unplugged and completely cool.
2. Locate the Micro-Calc filter, typically at the rear of the iron.
3. Remove the filter by pulling it out.
4. Empty any accumulated calc deposits and rinse the filter thoroughly under running water.
5. Reinsert the clean filter back into the iron until it clicks into place.



Image: The Micro-Calc filter of the Tefal Puregliss FV8064 iron, shown removed from the unit with visible limescale deposits, illustrating the cleaning process.

3. Storage

After use, unplug the iron and allow it to cool down completely. Empty any remaining water from the tank. Store the iron upright on its heel rest in a safe, dry place, away from direct sunlight and moisture.

Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet issue; auto-off activated.	Check power connection; try another outlet; move the iron to reactivate auto-off.
No steam or insufficient steam.	Water tank empty; iron not hot enough; steam control set to 'no steam'; calc build-up.	Fill water tank; wait for iron to heat up; adjust steam control; clean Micro-Calc filter.
Water leaking from soleplate.	Temperature too low for steam; overfilled water tank; calc build-up.	Allow iron to reach full temperature before using steam; do not overfill; clean Micro-Calc filter.
Brown stains on fabric.	Limescale deposits; dirty soleplate.	Clean Micro-Calc filter; clean soleplate. Use distilled water if tap water is very hard.

If the problem persists after attempting these solutions, please contact Tefal customer support or an authorized service center.

Specifications

Model: FV8064 Puregliss

Power: 3000 Watts

Continuous Steam Output: Up to 50 g/min

Steam Boost: Up to 280 g/min

Water Tank Capacity: 270 ml

Soleplate: Durilium AirGlide Autoclean

Anti-Calc System: Patented Micro-Calc Filter

Safety Features: Auto-Off

Color: Black/Gold

Dimensions (L x W x H): Approximately 34 x 14 x 0.1 cm (Note: 0.1cm height seems incorrect from source, likely product dimensions not iron height)

Weight: Approximately 1.3 Kilograms

Warranty and Support

Tefal products are designed for durability and performance. This product is backed by Tefal's commitment to quality.

Spare Parts Availability

Spare parts for the Tefal Puregliss FV8064 are available for a period of 15 years from the date of purchase. This ensures long-term support for your product.




Image: A logo indicating 15 years of repairability, emphasizing the long-term support for spare parts.

Customer Support

For further assistance, product registration, or to locate an authorized service center, please visit the official Tefal website or contact their customer service department. Refer to the product packaging or the official Tefal website for specific contact details in your region.
You can also visit the Tefal Brand Store on Amazon for more information and products.

© 2024 Tefal. All rights reserved.
This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question